

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [IKEA](#) /

› [IKEA TROFAST Storage Combination with Boxes, 46x30x145 cm, White/White Instruction Manual](#)

IKEA TROFAST

IKEA TROFAST Storage Combination with Boxes Instruction Manual

Model: TROFAST | Dimensions: 46x30x145 cm

INTRODUCTION

This manual provides essential information for the assembly, safe use, and maintenance of your IKEA TROFAST Storage Combination with Boxes. Please read these instructions carefully before beginning assembly or use to ensure proper function and longevity of the product.

PRODUCT OVERVIEW

The IKEA TROFAST storage combination is designed to provide a sturdy and versatile solution for organizing toys and other items. It features a durable frame and includes multiple storage boxes that slide into designated rails. The modular design allows for flexible arrangement and easy access to contents.



Image 1: The IKEA TROFAST Storage Combination with Boxes, shown in a room setting, demonstrating its use for organizing toys.

ASSEMBLY INSTRUCTIONS

Assembly of the TROFAST storage combination is required. Detailed assembly instructions are provided by the manufacturer within the product packaging. Please follow these instructions step-by-step to ensure correct and safe assembly.

- **Unpack all components:** Verify that all parts listed in the manufacturer's guide are present before starting.
- **Follow the sequence:** Adhere strictly to the assembly sequence outlined in the provided manual.
- **Use appropriate tools:** Ensure you have the necessary tools as specified in the assembly guide.
- **Secure all fasteners:** Tighten all screws and connectors firmly, but do not overtighten.
- **Wall attachment:** For safety, it is highly recommended to secure the unit to a wall using the anti-tip hardware provided, especially in households with children.




Image 2: A technical diagram illustrating the dimensions of the TROFAST frame and a single storage box, crucial for assembly and planning.

USAGE

The TROFAST storage combination is designed for organizing various items, particularly toys and children's belongings. The included boxes slide smoothly into the frame's rails, allowing for easy access and removal. The open design promotes visibility and encourages children to participate in tidying up.

- **Load distribution:** Distribute weight evenly across the boxes and shelves to maintain stability.
- **Box placement:** Ensure boxes are fully inserted into their rails to prevent accidental falls.
- **Intended use:** This unit is primarily for storage. Avoid climbing or standing on the unit.



Image 3: A close-up view of a TROFAST storage box, demonstrating its capacity and suitability for storing small items like toy cars.

CARE AND MAINTENANCE

To keep your TROFAST storage combination in optimal condition, follow these care guidelines:

- **Cleaning:** Wipe the unit and boxes with a damp cloth. Use a mild cleaner if necessary, then wipe dry with a clean cloth.
- **Avoid harsh chemicals:** Do not use abrasive cleaners or strong chemical solvents, as these can damage the finish and materials.
- **Regular inspection:** Periodically check all fasteners and connections to ensure they remain tight. Retighten if necessary.
- **Environmental conditions:** Avoid placing the unit in direct sunlight or near heat sources to prevent material degradation.

SPECIFICATIONS

Brand	IKEA
Model Name	TROFAST
Model Number	IK.992.284.76
Dimensions (W x D x H)	46 cm x 30 cm x 145 cm (18.11"D x 11.81"W x 57.09"H)
Color	White
Material	Engineered Wood (Frame), Plastic (Boxes)
Assembly Required	Yes
Mounting Type	Floor Mount (Wall attachment recommended)
Recommended Use	Storage for clothes, toys

TROUBLESHOOTING

If you encounter any issues with your TROFAST storage combination, consider the following common solutions:

- **Unit instability:** Ensure all fasteners are securely tightened. Verify the unit is placed on a flat, level surface. If applicable, ensure the unit is properly anchored to the wall.
- **Boxes not sliding smoothly:** Check for any obstructions in the rails. Ensure the boxes are correctly aligned with the rails. Clean the rails and box edges if dust or debris is present.
- **Missing parts:** Refer to the assembly manual's parts list. Contact IKEA customer service if parts are missing or damaged upon delivery.

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or additional support, please refer to the documentation included with your purchase or visit the official IKEA website. Keep your proof of purchase for any warranty claims.

Important Note: For customers ordering from outside of the EU, please be aware that you may be subject to import duty and tax. Please check with your local postal or tax office regarding import regulations and safety standards for this product.

