

[Manuals.plus](#) /

> [Ikea](#) /

> [IKEA GUNNÖN Gazebo User Manual](#)

Ikea GUNNÖN

IKEA GUNNÖN Gazebo User Manual

Model: GUNNÖN

INTRODUCTION

The IKEA GUNNÖN Gazebo is designed to provide a versatile outdoor shelter solution. Its adaptable design allows for various configurations, whether freestanding, positioned against a wall, or combined with another unit for extended coverage. This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your GUNNÖN Gazebo.



Figure 1: The IKEA GUNNÖN Gazebo in its standard freestanding configuration.

SETUP AND ASSEMBLY

Carefully unpack all components and verify against the parts list provided in the separate assembly instructions. Assembly typically requires two people. Ensure all connections are secure before use.

Component Identification

Before starting assembly, identify all frame pieces, fabric canopy, and fasteners. Refer to the detailed assembly guide for specific part numbers and diagrams.

Canopy Attachment

The fabric canopy attaches to the frame using integrated straps and corner pockets. Ensure the canopy is taut and evenly distributed to prevent water pooling.



Figure 2: Attaching the canopy fabric to the frame using a velcro strap.



Figure 3: Detail of the canopy corner pocket securely fitted over the frame.

OPERATING AND USAGE

The GUNNÖN Gazebo is designed for outdoor use, providing shade and shelter. It can be used in various configurations:

- **Freestanding:** Position the gazebo anywhere in your outdoor space.
- **Against a Wall:** Place one side of the gazebo against an existing wall for a semi-enclosed space.
- **Combined Units:** Two gazebos can be positioned adjacent to each other to cover a larger area.



Figure 4: The gazebo providing shade over a patio seating area.



Figure 5: The gazebo creating an inviting outdoor space, suitable for evening use with additional lighting.




Figure 6: The gazebo provides a comfortable gathering space for social activities.

MAINTENANCE

Regular maintenance will extend the life of your GUNNÖN Gazebo.

- **Cleaning:** Clean the fabric canopy with a mild soap solution and water. Rinse thoroughly and allow to air dry completely before storage. Do not use harsh chemicals or abrasive cleaners.
- **Frame Care:** Inspect the metal frame periodically for any signs of rust or damage. Clean with a damp cloth. If necessary, touch up any scratches with rust-inhibiting paint.
- **Fasteners:** Periodically check all bolts and screws to ensure they are tight. Retighten as needed.
- **Seasonal Storage:** During periods of strong winds, heavy rain, or snow, it is recommended to remove the canopy to prevent damage. For long-term storage, disassemble the gazebo and store all components in a dry, protected area.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Canopy sags or collects water.	Canopy not taut enough; uneven tension.	Re-adjust canopy straps and corner pockets to ensure even tension across the frame.
Frame feels unstable.	Loose fasteners; uneven ground.	Check and tighten all bolts and screws. Ensure the gazebo is placed on a level surface. Use ground stakes if provided or recommended.
Difficulty with assembly.	Incorrect part orientation; missing steps.	Refer to the detailed assembly instructions. Ensure parts are oriented correctly as per diagrams. Do not force components.

SPECIFICATIONS

Attribute	Detail
Model Name	GUNNÖN Gazebo
Dimensions (Length x Width x Max Height)	238 cm (93 ¾") x 233 cm (91 ¾") x 235 cm (92 ½")
Canopy Material	Polyester (150 g/m²)
Frame Material	Alloy Steel
Color	Dark Grey/Grey
Manufacturer	IKEA
ASIN	B0BW8SB CDN



Figure 7: Detailed dimensions of the GUNNÖN Gazebo frame.

WARRANTY AND SUPPORT

For information regarding warranty coverage, spare parts, or further assistance, please contact IKEA customer service or visit your local IKEA store. Keep your proof of purchase for warranty claims.

Note: This product may be subject to import duties and taxes when shipped outside the EU. Please check with your local postal or tax office for regulations in your country.