#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Jkea /
- > Ikea ENHET Wall Cabinet with 1 Shelf (60x30x60 cm, White) Instruction Manual

#### Ikea IK.904.404.29

# Ikea ENHET Wall Cabinet with 1 Shelf (60x30x60 cm, White) - Instruction Manual

Model: IK.904.404.29

### 1. Introduction

This manual provides essential instructions for the assembly, installation, operation, and maintenance of your Ikea ENHET Wall Cabinet with 1 Shelf. Please read this manual thoroughly before beginning assembly or use to ensure safe and correct installation and to maximize the product's lifespan.

# **Key Features:**

- Designed for mounting above a wall-mounted range hood.
- Aligns seamlessly with other ENHET wall cabinets (75 cm height) for a cohesive kitchen design.
- Offers convenient storage for bottles, jars, and frequently used kitchen items.
- Optimizes unused space above your range hood.
- Features unique wedge dowels for simplified assembly and nearly invisible fittings.
- Closed storage design contributes to a calm and uniform kitchen aesthetic.
- Part of the versatile ENHET series, suitable for kitchens, bathrooms, or laundry rooms.

## 2. SAFETY INFORMATION

**WARNING:** Serious or fatal crushing injuries can occur from furniture tip-over. To prevent tip-over, this furniture must be permanently fixed to the wall.

- · Always follow the assembly instructions carefully.
- Use appropriate tools for assembly.
- Ensure the wall material is suitable for mounting and use appropriate wall plugs and screws (sold separately, unless specified).
- Do not overload the cabinet. Distribute weight evenly on the shelf.
- · Keep small parts out of reach of children during assembly.

#### 3. PACKAGE CONTENTS

Your Ikea ENHET Wall Cabinet package includes all necessary components for assembly, including panels, a shelf, hinges, and unique wedge dowels. Please refer to the detailed graphical instructions provided in the separate assembly guide for a complete list of parts and quantities.

# 4. SETUP AND ASSEMBLY

Assembly of the ENHET wall cabinet is designed to be straightforward, utilizing unique wedge dowels for easy construction.

- 1. Unpack: Carefully unpack all components and verify against the parts list in the separate assembly guide.
- 2. **Assemble Cabinet Frame:** Follow the step-by-step graphical instructions to connect the side panels, top, and bottom panels using the wedge dowels. Ensure all connections are secure.
- 3. **Install Shelf:** Insert the shelf supports into the pre-drilled holes at your desired height and place the shelf onto the supports.
- 4. **Attach Hinges (if applicable):** If you are adding an ENHET door (sold separately), attach the hinges to the cabinet frame according to the door's instructions.

#### 5. Wall Mounting:

- o Identify a suitable wall location, preferably above a range hood, ensuring it is structurally sound.
- Use a spirit level to mark the drilling points for the wall mounting brackets.
- Drill holes and insert appropriate wall plugs for your wall type (e.g., plasterboard, concrete, wood).
  Wall plugs and screws are typically sold separately.
- Securely attach the mounting rail or brackets to the wall.
- Lift the assembled cabinet onto the mounting rail/brackets and secure it in place as per the assembly guide.



Image 1: The interior of the Ikea ENHET Wall Cabinet, showing the adjustable shelf and pre-drilled holes for hinge installation. This image illustrates the basic structure before a door is added.

# 5. OPERATING INSTRUCTIONS

Once assembled and securely mounted, your ENHET wall cabinet is ready for use.

- **Storage:** Place items such as bottles, jars, and other kitchen essentials on the shelf. Ensure weight is distributed evenly to maintain stability.
- **Door Operation (if installed):** If an ENHET door has been installed, open and close it gently using the handle. The hinges allow for smooth operation.
- Adjusting Shelf Height: The shelf can be repositioned by removing it, moving the shelf supports to different pre-drilled holes, and then re-inserting the shelf.



Image 2: The Ikea ENHET Wall Cabinet shown installed above a kitchen range hood, demonstrating its practical use for storing various kitchen items.

# 6. MAINTENANCE

Regular cleaning and maintenance will help keep your ENHET cabinet in good condition.

- Cleaning: Wipe clean with a cloth dampened in a mild cleaner. Wipe dry with a clean cloth.
- Avoid: Do not use abrasive cleaners, scouring pads, or chemical solvents as these can damage the surface.
- **Check Fasteners:** Periodically check all screws and fittings to ensure they are tight. Retighten if necessary to maintain stability and safety.

# 7. TROUBLESHOOTING

If you encounter any issues with your ENHET wall cabinet, consider the following:

- Cabinet feels wobbly: Ensure all assembly screws and wall mounting fasteners are securely tightened. Recheck the wall mounting for stability.
- **Door does not close properly:** Check hinge alignment and adjustment. Refer to the door's specific assembly instructions for hinge adjustment details.

• **Shelf sags:** Ensure the shelf is not overloaded and that shelf supports are correctly seated in the pre-drilled holes.

For persistent issues or if you require further assistance, please contact lkea customer support.

# 8. Specifications

Brand:	Ikea
Model Number:	IK.904.404.29
Dimensions:	60x30x60 cm (Width x Depth x Height)
Color:	White
Assembly Required:	Yes (User assembly)
Date First Available:	January 31, 2023

## 9. WARRANTY AND SUPPORT

This Ikea ENHET Wall Cabinet is covered by a **10-year warranty**. Please refer to the separate warranty brochure for full terms and conditions.

For customer support, spare parts, or further inquiries, please visit the official Ikea website or contact your local Ikea store. Ensure you have your model number (IK.904.404.29) and proof of purchase available when contacting support.

#### Related Documents - IK.904.404.29



