

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave L-Shaped Quad Bunk Bed with Slide Instruction Manual

Bellemave YYF-GX0615AAB-OR

Bellemave L-Shaped Quad Bunk Bed with Slide

Model: YYF-GX0615AAB-OR

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions and safety warnings before assembling and using this bunk bed. Failure to follow these instructions can result in serious injury.

- **Supervision:** Always supervise children when using the slide.
- **Weight Capacity:** Do not exceed the maximum weight capacity of **250 lbs (113 kg)** for the upper bunk and **350 lbs (159 kg)** for the lower bunk.
- **Slide Safety:** Be cautious of the slide's height and ensure the landing area is clear to prevent injuries.
- **Guardrails:** The upper bunk is equipped with a 13-inch high full-length guardrail for safety. Ensure it is always properly installed.
- **Headboard/Footboard:** The bottom bunk includes a headboard and footboard for added security.
- **Sturdy Construction:** This bed features a sturdy metal frame, heavy-duty safeguards, and a robust ladder. Regularly check all connections to ensure they remain tight.
- **Mattress Thickness:** Use only mattresses with the recommended thickness to maintain proper guardrail height.

SETUP AND ASSEMBLY

Assembly of the Bellemave L-Shaped Quad Bunk Bed is required. It is recommended that two adults assemble this product. All necessary parts, tools, and an installation manual are included in the packaging.

Before You Begin:

- **Unpacking:** This item comes in two separate boxes, which may not be delivered simultaneously. Please ensure you have received all packages before starting assembly.
- **Check Contents:** Verify all parts against the included parts list in the installation manual. If any parts are missing or damaged, contact customer service immediately.
- **Workspace:** Clear a spacious area for assembly, preferably on a soft surface like a carpet to prevent scratching the bed components.

Assembly Steps:

1. Follow the step-by-step instructions provided in the separate Installation Manual.
2. Ensure all bolts and screws are tightened securely at each stage of assembly. Do not overtighten until instructed to do so, as this may damage components.
3. The bed frame includes a slat kit, eliminating the need for a box spring. Ensure all slats are properly installed and secured.
4. Once fully assembled, double-check all connections for tightness and stability.



Image: Fully assembled Bellemave L-Shaped Quad Bunk Bed with Slide, showcasing its configuration.

OPERATING INSTRUCTIONS

This L-shaped bunk bed is designed to accommodate four twin-size mattresses. Please adhere to the following guidelines for safe operation:

- **Mattress Placement:** Place a standard twin-size mattress on each bed frame.
- **Mattress Thickness:** For the upper bunk, use a mattress with a maximum thickness of **6 inches**. For the lower bunks, use mattresses with a thickness between **8-10 inches**. This ensures the safety guardrails on the upper bunk remain effective.
- **Ladder Use:** Always use the provided ladder for accessing the upper bunk. Do not climb on the bed frame structure.
- **Slide Use:** The slide is intended for descent only. Ensure the area at the bottom of the slide is clear before use.
- **No Jumping:** Do not jump on the bed or slide.

MAINTENANCE

Regular maintenance will help prolong the life and ensure the safety of your Bellemave bunk bed.

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as this may damage the rust-proof finish.

- **Tighten Connections:** Periodically (e.g., every 3-6 months) check all bolts, screws, and connections to ensure they are tight. Loose connections can lead to instability and noise.
- **Inspect for Damage:** Regularly inspect the bed frame, ladder, and guardrails for any signs of wear, damage, or structural fatigue. Discontinue use if any damage is found and contact customer service for replacement parts or advice.

TROUBLESHOOTING

If you encounter any issues with your bunk bed, please refer to the following common solutions:

- **Wobbling/Instability:** If the bed feels unstable or wobbles, re-check all assembly connections. Ensure every bolt and screw is securely tightened. Uneven flooring can also contribute to wobbling; consider using furniture pads to level the bed.
- **Squeaking Noises:** Squeaking often indicates loose connections. Re-tighten all bolts and screws. Applying a small amount of lubricant (e.g., silicone spray) to metal-on-metal contact points can also help.
- **Missing Parts:** If you find that parts are missing upon unpacking, do not proceed with assembly. Contact Bellemave customer service with your product model number and a description of the missing parts.
- **Difficulty with Slide:** If the slide seems obstructed or difficult to use, ensure it is correctly installed according to the manual and that no bed components are interfering with its path.

SPECIFICATIONS

Feature	Detail
Model Number	YYF-GX0615AAB-OR
Material	Alloy Steel, Metal
Color	Black
Overall Product Dimensions (L x W x H)	117.1" x 100" x 57.1" (with Slide)
Upper/Down Bed Dimensions (L x W)	74.8" x 38.9"
Total Height	57.1"
Number of Upper Bed Slats	21 pcs
Number of Down Bed Slats	21 pcs
Recommended Upper Mattress Thickness	6"
Recommended Down Mattress Thickness	8-10"
Upper Bed Weight Capacity	250 lbs (113 kg)
Down Bed Weight Capacity	350 lbs (159 kg)
Product Weight	165 lbs (75 kg)
Assembly Required	Yes



Image: Detailed dimensional drawing of the bunk bed, showing length, width, and height measurements.

WARRANTY AND SUPPORT

Warranty Information:

This Bellemave L-Shaped Quad Bunk Bed comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper assembly, misuse, abuse, accidents, or normal wear and tear.

Customer Support:

For any questions regarding assembly, missing parts, warranty claims, or general inquiries, please contact Bellemave customer service. Have your model number (YYF-GX0615AAB-OR) and purchase information ready for faster assistance.

You can typically find contact information on the Bellemave official website or through your original retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BW8SQKVN>

More documents and user manuals: **<https://manuals.plus/>**