

IKEA GRIMO

IKEA GRIMO Hinged Door 50 x 195 cm White - Instruction Manual

1. INTRODUCTION AND OVERVIEW

This manual provides essential information for the installation, operation, maintenance, and troubleshooting of your IKEA GRIMO hinged door. The GRIMO door, measuring 50 x 195 cm and finished in white, is designed to complement various interior styles, particularly the IKEA PAX wardrobe system.

The GRIMO door combines classic panel door aesthetics with a clean, bold frame, offering a modern yet traditional design. It is equipped with features for enhanced functionality and durability.


2. KEY FEATURES

- **10-Year Guarantee:** This product is covered by a 10-year guarantee. Refer to the guarantee brochure for detailed terms and conditions.
- **Reversible Hanging:** The door can be hung with the opening to either the right or the left, offering flexibility in installation.
- **Integrated Soft-Closing Hinges:** Equipped with hinges that feature integrated dampers, ensuring the door closes slowly, silently, and softly.
- **Two-Panel Design:** Features thick, wide frames with an inner beveled edge, maintaining minimal details and focusing on clean lines.
- **White Foil Finish:** Covered with white foil on both the front and back surfaces, designed to perfectly match white IKEA PAX wardrobe frames.

3. SETUP AND INSTALLATION

The IKEA GRIMO hinged door is designed for user-friendly assembly. While professional assembly is not strictly required, careful attention to the provided assembly instructions is crucial for proper function and longevity. The door includes necessary hinges for mounting.

Important: Always follow the detailed assembly guide included with your product for step-by-step instructions specific to your GRIMO door and PAX wardrobe frame. Ensure all components are securely fastened before use.






Image 1: The IKEA GRIMO hinged door, showcasing its two-panel design and white finish.



Image 2: Multiple GRIMO hinged doors installed on a white PAX wardrobe, demonstrating their integration into a room.



Image 3: A close-up of the GRIMO door's edge, highlighting the thick frame and inner beveled detail.

4. OPERATING INSTRUCTIONS

Operating the GRIMO hinged door is straightforward. Simply pull or push the door to open or close it. The integrated soft-closing hinges will ensure a gentle and quiet closing motion, preventing slamming and reducing wear.

Ensure that the path of the door is clear of obstructions when opening or closing to prevent damage to the door or surrounding furniture.

5. MAINTENANCE

Regular maintenance helps preserve the appearance and functionality of your GRIMO door.

- **Cleaning:** Wipe the door surfaces clean with a damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Dry immediately with a clean cloth. Avoid using harsh chemicals, abrasive cleaners, or scouring pads, as these can

damage the foil finish.

- **Hinge Check:** Periodically check the hinge screws to ensure they are tight. If the door sags or does not close properly, gently tighten the hinge screws. Do not overtighten.
- **Avoid Moisture:** Protect the door from excessive moisture and direct water exposure, which can cause damage to the material.

6. TROUBLESHOOTING

If you encounter issues with your GRIMO door, consider the following troubleshooting steps:

- **Door Not Closing Properly:**
 - Check if the wardrobe frame is level and square.
 - Inspect hinges for any loose screws or misalignment. Adjust as necessary.
 - Ensure no items inside the wardrobe are obstructing the door's closing path.
- **Door Squeaks:**
 - Apply a small amount of silicone-based lubricant to the hinge pivot points. Avoid oil-based lubricants that can attract dust.
- **Door Feels Loose:**
 - Tighten all hinge mounting screws on both the door and the wardrobe frame. Do not overtighten.

If problems persist after attempting these steps, please contact IKEA customer support.

7. SPECIFICATIONS

Feature	Specification
Model Name	GRIMO
Dimensions (Width x Height)	50 x 195 cm
Color	White
Material	Foil finish (front and back)
Style	Classic, Modern
Hinges	Integrated soft-closing hinges included
Manufacturer	IKEA
Manufacturer Product ID	IK.991.835.81
Assembly Required	User assembly expected (mounting to frame)

8. WARRANTY AND SUPPORT

Your IKEA GRIMO hinged door comes with a **10-year guarantee**, covering defects in materials and workmanship under normal domestic use. Please retain your proof of purchase for warranty claims.

For detailed information regarding the guarantee terms, or if you require assistance with installation, troubleshooting, or have any other product-related inquiries, please contact IKEA customer service. You can find contact information on the official IKEA website or in your local IKEA store.

For further support, visit the official IKEA website:www.ikea.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question