Ikea IK.304.289.01

IKEA EKET Transparent Glass Door

Model: IK.304.289.01

User Manual

1. Product Overview

The IKEA EKET Transparent Glass Door is designed to transform an open EKET storage cube into a functional display cabinet. This door helps protect your cherished items from dust and damage while allowing them to remain visible. It features toughened glass for enhanced durability and ease of cleaning.




Figure 1: The IKEA EKET Transparent Glass Door, showcasing the clear glass panel and pre-attached hinges.

2. Safety Information

- Always handle glass components with care to prevent breakage and injury.
- Ensure all screws and fittings are securely tightened before use to prevent the door from detaching.
- Do not hang or apply excessive force to the door, as this may damage the hinges or the EKET unit.
- Keep small parts out of reach of children during assembly.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. The package should contain:

- 1x Transparent Glass Door (32 x 32 cm)
- 2x Hinges (pre-attached to the glass door)
- 1x Door Knob/Handle
- Screws and fittings for attachment to EKET cabinet

If any parts are missing or damaged, please contact IKEA customer service.

4. Setup and Assembly

This section provides step-by-step instructions for attaching the glass door to your IKEA EKET open storage cube.

Tools Required:

- Phillips head screwdriver

Assembly Steps:

1. **Prepare the EKET Unit:** Ensure your EKET open storage cube is assembled and securely placed. Identify the pre-drilled holes on the side of the EKET unit where the hinges will attach.
2. **Attach the Hinges:** The hinges are pre-attached to the glass door. Align the hinges with the pre-drilled holes on the side of the EKET unit.



Figure 2: Close-up view of the hinge mechanism, showing how it connects to the EKET unit.

3. **Secure the Door:** Using the provided screws, firmly attach the hinges to the EKET unit. Tighten all screws until the door is securely mounted and swings smoothly. Do not overtighten.
4. **Install the Door Knob:** Attach the door knob to the designated hole on the glass door. Secure it with the provided screw from the inside of the door.
5. **Test Operation:** Gently open and close the door to ensure it operates smoothly and closes flush with

the EKET unit. Adjust hinge screws slightly if necessary to achieve proper alignment.

5. Operating Instructions

The EKET Transparent Glass Door is designed for simple operation.

- To open the door, gently pull the door knob.
- To close the door, gently push it until it aligns with the EKET unit. The hinges are designed to hold the door in a closed position.



Figure 3: An EKET unit with the glass door installed, used as a bedside cabinet to display items.



Figure 4: An EKET unit with the glass door installed, used in a hallway for organized storage and display.

6. Maintenance and Care

Proper care will ensure the longevity and appearance of your glass door.

- **Cleaning the Glass:** Wipe clean with a damp cloth and a mild cleaner. Dry with a clean cloth. Avoid abrasive cleaners or scouring pads, as they can scratch the glass.
- **Cleaning the Hinges:** Wipe metal parts with a dry or slightly damp cloth. Do not use harsh chemicals.
- **Regular Inspection:** Periodically check that all screws are tight. Retighten if necessary, but do not overtighten.

7. Troubleshooting

Problem	Possible Cause	Solution
Door does not close flush.	Hinges are misaligned or loose.	Adjust the hinge screws to realign the door. Ensure the EKET unit is level.
Door feels wobbly.	Hinge screws are loose.	Tighten all hinge screws. Do not overtighten.

Problem	Possible Cause	Solution
Scratches on glass.	Abrasive cleaning materials used.	Use only soft cloths and mild glass cleaner. Scratches cannot be removed.

8. Specifications

- **Brand:** Ikea
- **Model Number:** IK.304.289.01
- **ASIN:** B0BW8TH3PX
- **Dimensions:** 32 x 32 cm (approximate, to fit EKET cube)
- **Material:** Toughened glass, Metal hinges
- **First Available:** October 24, 2023

9. Warranty and Support

For information regarding warranty coverage, spare parts availability, or further product support, please refer to the official IKEA website or contact IKEA customer service directly. Keep your proof of purchase for warranty claims.

IKEA Official Website: www.ikea.com

© 2023 Ikea. All rights reserved.
This manual is for informational purposes only. Ikea is not responsible for any damages or injuries resulting from improper assembly or use.