

[Manuals.plus](#) /

> [IKEA](#) /

> IKEA HAUGA High Cabinet with 2 Doors User Manual

IKEA IK.204.150.46

IKEA HAUGA High Cabinet with 2 Doors User Manual

Model: IK.204.150.46

INTRODUCTION

Thank you for choosing the IKEA HAUGA High Cabinet with 2 Doors. This versatile and stylish storage solution is designed to help you organize your home efficiently. With its clean white finish and thoughtful design, it seamlessly integrates into various room settings, from living rooms to hallways. This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your new cabinet.





Image: The IKEA HAUGA high cabinet, showcasing its full height with two lower doors and three open shelves above, in a clean white finish.

SETUP AND ASSEMBLY

The IKEA HAUGA High Cabinet is designed for self-assembly. Please follow the detailed instructions provided in the separate assembly guide that came with your product. Ensure you have all components and the necessary tools before beginning. It is recommended to assemble the cabinet on a soft, clean surface to prevent scratches.

Safety Information:

- Always secure the cabinet to the wall using the included anti-tip device. This prevents the cabinet from tipping over, which can cause serious injury.
- Use appropriate screws and wall plugs for your wall type. If you are unsure, seek professional advice.
- Do not overload shelves. Adhere to the maximum weight capacity specified in the 'Specifications' section.



Image: The HAUGA cabinet integrated into a living room, demonstrating its functional and aesthetic placement.

OPERATING INSTRUCTIONS

The HAUGA cabinet offers versatile storage with its open shelves and two lower doors. The doors are equipped with handles for easy opening and closing. The cabinet also features a lockable mechanism for securing contents within the lower section.

Storage and Organization:

- Use the open shelves for displaying books, decorative items, or frequently accessed belongings.
- The lower cabinet with doors is ideal for concealing items you prefer to keep out of sight, such as documents, electronics, or personal effects.
- To lock the lower doors, ensure they are fully closed and engage the locking mechanism (if applicable, based on specific model features).



Image: Interior view of the upper shelves, demonstrating storage for various items.



Image: Interior view of the lower cabinet, illustrating storage capacity for larger items or kitchenware.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your IKEA HAUGA cabinet.

- **Cleaning:** Wipe clean with a cloth dampened in a mild cleaner. Then wipe dry with a clean cloth.
- **Dusting:** Regularly dust the surfaces with a soft, dry cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong solvents, or polishes that may damage the finish.
- **Moisture:** Protect the cabinet from excessive moisture and direct heat sources.
- **Hardware:** Periodically check and tighten all assembly fittings to ensure stability.

TROUBLESHOOTING

If you encounter any issues with your HAUGA cabinet, please refer to the following common solutions:

Problem	Possible Cause	Solution
Cabinet feels wobbly or unstable.	Loose fittings or uneven floor.	Check and tighten all screws and fittings. Ensure the cabinet is placed on a level surface. Use shims if necessary. Verify wall anchoring.
Doors do not close properly or are misaligned.	Hinges are loose or improperly adjusted.	Adjust the hinges according to the assembly instructions. Tighten hinge screws.
Lock mechanism is not functioning.	Misalignment or obstruction.	Ensure doors are fully closed and aligned. Check for any obstructions around the lock. Refer to assembly guide for lock installation.

If the problem persists, please contact IKEA customer service for further assistance.

SPECIFICATIONS

Detailed specifications for the IKEA HAUGA High Cabinet:

Attribute	Value
Brand	IKEA
Model Number	IK.204.150.46
Colour	White
Overall Dimensions (Height x Width x Depth)	199 cm (H) x 70 cm (W) x 46 cm (D at base), 36 cm (D at top)
Item Weight	70 kg
Maximum Weight Capacity (per shelf)	18 Kilograms
Special Features	Lockable
Mounting Type	Floor Mount (with wall anchoring)
Room Type Recommendation	Living Room, Hallway, Dining Room




Image: Technical drawing illustrating the precise dimensions of the HAUGA cabinet.

WARRANTY AND SUPPORT

IKEA products are designed for quality and durability. For specific warranty information regarding your HAUGA cabinet, please refer to the purchase receipt or visit the official IKEA website for the most up-to-date warranty terms and conditions.

For customer support, spare parts, or further assistance, please contact IKEA customer service through their official channels. You can find contact information on the IKEA website or in your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BW8TR5ZT>

More documents and user manuals: <https://manuals.plus/>