

[Manuals.plus](#) /

› [IKEA](#) /

› IKEA GODMORGON Wash-Stand User Manual

IKEA GODMORGON 100x47x58 cm Kasjön light grey

IKEA GODMORGON Wash-Stand User Manual

Model: GODMORGON 100x47x58 cm Kasjön light grey

INTRODUCTION

This user manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your IKEA GODMORGON wash-stand. Please read this manual thoroughly before beginning assembly or use to ensure proper installation and long-term performance of your product.

The IKEA GODMORGON wash-stand is designed for bathroom environments, offering practical storage with its two spacious drawers. It features a matte finish that helps hide fingerprints and splash marks, and its solid wood drawers are equipped with smooth-running, soft-closing mechanisms.

IMPORTANT SAFETY INFORMATION

Always follow local building and plumbing regulations. If you are uncertain, contact a professional. Secure the wash-stand to the wall according to the assembly instructions to prevent tipping. Different wall materials require different types of fastening devices. Use fastening devices suitable for the walls in your home (not included).

- Ensure all connections are watertight to prevent water damage.
- Do not overload drawers; distribute weight evenly.
- Keep small children away during assembly.
- Always use appropriate tools and wear protective gear during assembly.

SETUP AND ASSEMBLY

The GODMORGON wash-stand requires assembly. It is recommended that two people assemble this product. Ensure you have all parts and tools listed in the assembly instructions before starting.

Unpacking and Inspection

Carefully unpack all components and check against the parts list provided in the separate assembly guide. Report any missing or damaged parts immediately to IKEA customer service.

Tools Required (Not Included)

- Screwdriver (Phillips head)
- Hammer
- Drill (for wall mounting)
- Level
- Measuring tape

Assembly Steps Overview

1. Assemble the main frame of the wash-stand according to the detailed diagrams in the assembly guide.
2. Install the drawer runners onto the frame.
3. Assemble the drawers, ensuring the scratch-resistant melamine bottom is correctly seated.
4. Insert the assembled drawers into the frame, testing the smooth-running and soft-closing mechanism.
5. Secure the wash-stand to the wall using appropriate fastening devices (sold separately) to prevent tipping. Use a level to ensure it is straight.
6. Install the sink (if applicable, sold separately) and connect plumbing according to local codes.



Figure 1: Front view of the IKEA GODMORGON wash-stand, showing its two closed drawers and light grey finish. This image illustrates the product's appearance prior to installation of a sink or plumbing.

OPERATING INSTRUCTIONS

The GODMORGON wash-stand is designed for easy and functional use in a bathroom setting.

Drawer Operation

The drawers feature a smooth-running and soft-closing mechanism. To open, gently pull the handle. To close, push the drawer until the soft-closing mechanism engages, allowing it to close quietly and completely.

- **Full Pull-Out:** The drawers pull out fully, allowing easy access to contents at the back.

- **Adjustable Dividers:** The internal dividers can be moved to customize the size of compartments within the drawers, optimizing storage for various items.



Figure 2: The IKEA GODMORGON wash-stand with both drawers open, revealing organized storage for bathroom essentials like towels and bottles. A double sink is installed on top, demonstrating typical usage.

CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your GODMORGON wash-stand.

Cleaning

- Wipe clean with a cloth dampened in a mild cleaner.
- Wipe dry with a clean cloth.
- Do not use abrasive cleaners, scouring pads, or chemical solvents as they can damage the surface.
- Promptly wipe away any water spills to prevent moisture damage, especially around seams and edges.

General Care

- Regularly check all screws and fittings to ensure they are tight. Retighten if necessary.
- Avoid placing extremely hot or cold items directly on the surface without protection.
- Ensure adequate ventilation in the bathroom to minimize humidity, which can affect wood products over time.

TROUBLESHOOTING

This section addresses common issues you might encounter with your wash-stand.

Problem	Possible Cause	Solution
Drawers do not close smoothly or soft-closing mechanism fails.	• Drawer runners are dirty or obstructed. • Drawer is overloaded or weight is unevenly distributed. • Screws on runners or drawer slides are loose.	• Clean drawer runners with a damp cloth. • Reduce weight or redistribute items in the drawer. • Tighten all screws on drawer runners and slides.
Wash-stand feels wobbly or unstable.	• Not properly secured to the wall. • Assembly screws are loose. • Uneven floor surface.	• Ensure the wash-stand is securely fastened to the wall using appropriate wall anchors. • Check and tighten all assembly screws. • Use shims under the feet if the floor is uneven.
Water stains or swelling on surfaces.	• Prolonged exposure to water. • Leaking plumbing.	• Wipe up spills immediately. • Check plumbing connections for leaks and repair as necessary. • Ensure proper ventilation in the bathroom.

SPECIFICATIONS

Attribute	Detail
Model Name	GODMORGON
Dimensions (W x D x H)	100 x 47 x 58 cm (approximately 39.4 x 18.5 x 22.8 inches)
Color	Kasjön light grey
Number of Drawers	2
Material	Solid wood drawers, scratch-resistant melamine bottom, matte finish.
Features	Smooth-running, soft-closing drawers with pull-out stop; customizable drawer size with dividers.

Attribute	Detail
Assembly Required	Yes
Mounting Type	Wall-mounted (fastening devices not included)

WARRANTY AND SUPPORT

The IKEA GODMORGON wash-stand comes with a **10-year guarantee**. This guarantee covers defects in material and workmanship in the GODMORGON series. Please refer to the separate guarantee brochure available at IKEA stores or on the IKEA website for full terms and conditions.

For customer support, missing parts, or warranty claims, please contact IKEA customer service through their official website or visit your nearest IKEA store. Keep your proof of purchase for warranty purposes.

IKEA Official Website: www.ikea.com