

IKEA IK.200.452.05

IKEA SNIGLAR Changing Table Instruction Manual

Model: IK.200.452.05

1. INTRODUCTION

Thank you for choosing the IKEA SNIGLAR Changing Table. This manual provides important information for the safe assembly, use, and maintenance of your changing table. Please read these instructions carefully before assembly and keep them for future reference. Proper assembly and adherence to safety guidelines are crucial for the well-being of your child.



Figure 1: The IKEA SNIGLAR Changing Table in a typical nursery setting.

2. SAFETY INFORMATION

Your child's safety is paramount. Always follow these safety guidelines:

- **Never leave your child unattended** on the changing table. Always keep one hand on your child.
- The changing table is designed for children up to 12 months old and a maximum weight of 11 kg (24.25 lbs).
- Ensure the changing table is placed on a flat, stable surface.
- Keep all assembly hardware tightened. Regularly check for loose screws or fittings and tighten them as needed.
- Keep small parts, plastic bags, and packaging materials away from children to prevent choking hazards.
- Do not use the changing table if any parts are broken, torn, or missing.
- Keep the changing table away from open flames, heaters, and other strong heat sources.

3. SETUP AND ASSEMBLY

Assembly of the IKEA SNIGLAR Changing Table requires careful attention to detail. It is recommended that two adults assemble this product for safety and ease.

1. **Unpack all components:** Carefully remove all parts from the packaging. Verify that all components listed in the included assembly diagram are present and undamaged.
2. **Prepare your workspace:** Assemble the changing table on a soft, clean surface to prevent scratches.
3. **Follow the included graphical instructions:** Refer to the detailed step-by-step diagrams provided with your product for precise assembly. Ensure all screws and fasteners are securely tightened. Do not overtighten.
4. **Check stability:** Once assembled, gently shake the changing table to ensure it is stable and all connections are secure.




Figure 2: Assembly diagram and key dimensions of the changing table.

4. OPERATING INSTRUCTIONS

Using the SNIGLAR Changing Table correctly ensures both convenience and safety.

- **Placement:** Position the changing table in a safe, accessible area, away from windows, cords, and hazards.
- **Changing Pad:** Always use a properly sized changing pad with raised sides to help keep the baby centered. Ensure the pad is securely placed and does not slide.
- **Supplies:** Keep all necessary changing supplies (diapers, wipes, creams, fresh clothes) within arm's reach but out of the baby's reach. The lower shelf provides convenient storage.
- **Changing Process:** Lay your baby gently on the changing pad. Always maintain physical contact with your baby while they are on the table.



Figure 3: A parent safely changing a baby on the SNIGLAR table, maintaining contact.



Figure 4: The lower shelf provides practical storage for baby essentials, keeping them within reach.

5. MAINTENANCE AND CARE

Regular maintenance will prolong the life and safety of your changing table.

- **Cleaning:** Wipe the changing table clean with a damp cloth and a mild cleaner. Dry thoroughly with a clean cloth. Avoid using abrasive cleaners or strong chemicals, as they can damage the finish.
- **Fastener Checks:** Periodically check all assembly fasteners (screws, bolts) to ensure they are tight.

Re-tighten as necessary to maintain stability.

- **Damage Inspection:** Regularly inspect the changing table for any signs of wear, damage, or loose parts. Discontinue use if any damage is found and contact customer support.

6. TROUBLESHOOTING

If you encounter any issues with your SNIGLAR Changing Table, consider the following:

- **Wobbling or Instability:** This is most commonly caused by loose fasteners. Re-check all screws and bolts and tighten them firmly. Ensure the table is on a level surface.
- **Missing Parts:** If you discover missing parts during assembly, do not attempt to use the product. Contact IKEA customer service for replacement parts.
- **Damaged Components:** If any part is damaged, do not proceed with assembly or use. Contact IKEA customer service for assistance.

7. SPECIFICATIONS

Feature	Specification
Brand	IKEA
Model Number	IK.200.452.05
Product Dimensions (L x W x H)	72 cm x 53 cm x 87 cm (28 3/8" x 20 7/8" x 34 1/4")
Material	Solid Beech, Fibreboard
Maximum Load	11 kg (24.25 lbs)
Recommended Age	0-12 months

8. WARRANTY AND SUPPORT

IKEA products are designed with quality and safety in mind. For information regarding warranty coverage, spare parts, or customer support, please refer to the warranty card included with your purchase or visit the official IKEA website for your region. You can also contact IKEA customer service directly for assistance with any product-related inquiries.