

- Manuals.plus /
- > [Ikea](#) /
 - > IKEA HEMNES Glass-door Cabinet with 3 Drawers, 90 x 197 cm, White Stained User Manual

Ikea IK.503.717.72

IKEA HEMNES Glass-door Cabinet with 3 Drawers

Model: IK.503.717.72

- [Introduction](#)
- [Safety Warnings](#)
- [Setup & Assembly](#)
- [Operating](#)
- [Instructions](#)
- [Maintenance](#)
- [Troubleshooting](#)
- [Specifications](#)
- [Warranty & Support](#)

1. INTRODUCTION

The IKEA HEMNES glass-door cabinet with 3 drawers is a versatile furniture piece designed to provide ample storage and display space. Crafted from solid wood, it offers a natural feel and durable construction. This manual provides essential information for assembly, safe use, and maintenance of your new cabinet.





Figure 1.1: Front view of the IKEA HEMNES Glass-door Cabinet. This image shows the cabinet's overall design, featuring two glass-panel doors on the upper section and three solid drawers below, all in a white stained finish with black knobs.

2. SAFETY WARNINGS

Please read and adhere to all safety warnings to prevent injury or damage to the product.

- **Maximum Load Capacity:** Do not exceed the maximum load of **30 kg (66 lbs) per shelf**. Overloading shelves can lead to structural failure and potential injury.
- **Package Inspection:** **NEVER accept or sign for a package before inspecting it in front of the carrier.** If the package is dropped without your signature, exercise your right to return it to the post office within the grace period and refuse its return.
- **Handling Precautions:** Exercise caution when handling and inspecting the package and its contents to avoid personal injury or damage to the product.
- **Tip-over Prevention:** For safety, it is highly recommended to secure the cabinet to the wall using the anti-tip

hardware provided (if applicable) to prevent tip-over accidents, especially in homes with children.

3. SETUP & ASSEMBLY

This cabinet requires assembly. Follow the steps below carefully. It is recommended to have two people for assembly.

3.1 Unpacking and Preparation

1. Choose a clean, flat, and spacious area for assembly to prevent scratching the furniture.
2. Carefully open the packaging and remove all components. Check the parts list against the included hardware to ensure all pieces are present.
3. Keep small parts, such as screws and dowels, in a separate container to prevent loss.

3.2 Assembly Steps (General Guidance)

While specific step-by-step instructions are typically provided in the manufacturer's included manual, the general assembly process for this type of cabinet involves:

- Assembling the main frame: Attach side panels to the top and bottom panels.
- Installing back panels: Slide or nail the back panels into place for structural integrity.
- Assembling drawers: Construct the drawer boxes and attach drawer slides.
- Installing drawer runners: Secure the runners inside the cabinet frame.
- Attaching glass doors: Mount hinges to the doors and then to the cabinet frame. Adjust hinges for proper alignment.
- Inserting shelves: Place adjustable shelves at desired heights using shelf pins.
- Attaching knobs/handles: Secure the black knobs to the doors and drawers.
- Securing to wall: Use the provided anti-tip hardware to anchor the cabinet to a wall stud. This is a critical safety step.




Figure 3.1: Detailed dimensions of the IKEA HEMNES Glass-door Cabinet. This diagram provides precise measurements for width, depth, and height, as well as internal shelf and drawer spacing, which are crucial for planning placement and understanding internal capacity.

4. OPERATING INSTRUCTIONS

The HEMNES cabinet is designed for easy and functional use.

4.1 Using the Glass Doors

- Gently pull the black knobs to open the glass doors.
- To close, push the doors until they click securely into place.
- The glass doors allow for display of items while protecting them from dust.

4.2 Using the Drawers

- Pull the black knobs to open the drawers.
- Push the drawers firmly to close them completely.
- The three drawers provide concealed storage for various items.

4.3 Adjusting Shelves

- The shelves inside the glass-door section are adjustable.
- To adjust, remove all items from the shelf, lift the shelf, remove the shelf pins, reposition the pins to the desired height, and then place the shelf back on the pins.



Figure 4.1: Close-up view of the black knobs on the IKEA HEMNES Glass-door Cabinet. This image highlights the simple, functional design of the hardware used for opening and closing the glass doors and drawers.



Figure 4.2: The IKEA HEMNES Glass-door Cabinet utilized in a dining room setting. This image demonstrates the cabinet's capacity to store and display dinnerware, glassware, and other kitchen or dining essentials, showcasing its practical application.

5. MAINTENANCE

Proper care will ensure the longevity and appearance of your HEMNES cabinet.

- **Cleaning:** Wipe clean with a damp cloth. For glass surfaces, use a glass cleaner. Avoid abrasive cleaners or harsh chemicals that can damage the finish.
- **Drying:** Wipe dry with a clean cloth.
- **Dusting:** Regularly dust the surfaces with a soft, dry cloth.
- **Hardware Check:** Periodically check all screws and fittings to ensure they are tight. Retighten if necessary to maintain stability.
- **Sunlight Exposure:** Avoid placing the cabinet in direct sunlight for prolonged periods, as this can cause fading or discoloration of the wood finish.
- **Humidity Control:** Maintain a stable room temperature and humidity level to prevent wood from warping or cracking.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Doors or drawers do not close properly.	Loose hinges/runners, uneven assembly, obstruction.	Check and tighten all hinge and runner screws. Ensure the cabinet is on a level surface. Remove any obstructions. Adjust hinges if necessary.
Cabinet feels wobbly or unstable.	Loose fittings, not secured to wall, uneven floor.	Retighten all assembly screws. Ensure the cabinet is anchored to the wall using anti-tip hardware. Use furniture glides or shims to level the cabinet on uneven floors.
Shelves sag or bow.	Overloaded shelves.	Reduce the weight on the shelves. Ensure weight is distributed evenly. Remember the 30 kg (66 lbs) per shelf limit.
Scratches or minor damage to finish.	Accidental impact, abrasive cleaning.	For minor scratches, use a furniture repair pen or touch-up paint matching the white stained finish. Avoid abrasive materials for cleaning.

7. SPECIFICATIONS

Detailed technical specifications for the IKEA HEMNES Glass-door Cabinet.

Brand: Ikea

Model Number: IK.503.717.72

Color: White Stained

Material: Solid wood (main components), Glass (door panels)

Dimensions (Assembled):

- **Width:** 90 cm (35.4 inches)
- **Depth:** 37 cm (14.6 inches)
- **Height:** 197 cm (77.6 inches)

Maximum Load per Shelf: 30 kg (66 lbs)

Features: 2 Glass-panel doors, 3 Drawers, Adjustable shelves

Assembly Required: Yes

ASIN: B0BW8VYGWN

First Available: April 30, 2023



Figure 7.1: The IKEA HEMNES Glass-door Cabinet integrated into a living room environment. This image illustrates the cabinet's aesthetic appeal and how it can complement various interior designs, providing both storage and display functionality.



Figure 7.2: Two IKEA HEMNES Glass-door Cabinets placed side-by-side in a living room. This demonstrates the modularity and scalability of the design, allowing for extended storage and display solutions in larger spaces or for more extensive collections.

8. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the official IKEA website or contact their customer service directly.

- **Warranty:** IKEA products typically come with a limited warranty. Please retain your proof of purchase for any warranty claims. Specific warranty details can be found on IKEA's official website or by contacting their customer service.
- **Missing Parts:** If any parts are missing or damaged upon delivery, contact the seller or IKEA customer service immediately.
- **Assembly Assistance:** For detailed assembly instructions or assistance, refer to the manual included in your product packaging or visit the IKEA website for digital versions and assembly videos.
- **Contact Information:**
 - **IKEA Official Website:** www.ikea.com
 - **Customer Service:** Refer to the "Contact Us" section on the IKEA website for phone numbers and support options specific to your region.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BW8VYGWN>

More documents and user manuals: **<https://manuals.plus/>**