

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Ikea](#) /
- > [Ikea HJÄLPA Clothes Rail, 60 x 40 cm - User Manual](#)

Ikea IK.604.501.27

Ikea HJÄLPA Clothes Rail, 60 x 40 cm

Model: IK.604.501.27 | Brand: Ikea

1. INTRODUCTION

The Ikea HJÄLPA Clothes Rail is an interior organizer designed to maximize and customize storage space within the PLATSA storage system. This rail allows you to hang clothes facing forward in a shallow wardrobe frame, making it easier to access and organize your garments. This manual provides essential information for the safe assembly, operation, and maintenance of your HJÄLPA clothes rail.

2. SAFETY INFORMATION

- Ensure all mounting hardware is securely fastened before use.
- Do not exceed the maximum weight recommendation of **24 kilograms (53 lbs)** for the clothes rail. Overloading can cause damage to the product or the wardrobe frame.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Always follow the assembly instructions carefully.

3. PACKAGE CONTENTS

Please check that all components are present before beginning assembly:

- 1 x HJÄLPA Clothes Rail (60 x 40 cm, white)
- Required mounting hardware (screws, brackets, etc.)

4. SETUP AND ASSEMBLY

Assembly of the HJÄLPA clothes rail requires basic tools (e.g., screwdriver) and should be performed according to the detailed instructions provided with your PLATSA storage solution. The clothes rail is designed for easy integration into the pre-drilled holes of the PLATSA frame.

1. Identify the desired height and position for the clothes rail within your PLATSA wardrobe frame.
2. Attach the support brackets to the inside walls of the PLATSA frame using the provided screws. Ensure

they are level and securely tightened.

3. Insert the HJÄLPA clothes rail into the attached brackets. Ensure it clicks into place or is firmly seated.
4. Verify that the rail is stable and can support weight before hanging clothes.



Figure 1: The HJÄLPA clothes rail installed in a white wardrobe, with several shirts hanging on wooden hangers, demonstrating the forward-facing hanging feature.



Figure 2: The HJÄLPA clothes rail installed in a white wardrobe, with a patterned shirt hanging on a white hanger, illustrating the rail's integration into the storage system.

5. OPERATING INSTRUCTIONS

Once assembled, the HJÄLPA clothes rail is ready for use. Simply hang your clothes on hangers and place them on the rail. Ensure the weight is distributed evenly and does not exceed the maximum load capacity of 24 kg.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the clothes rail clean with a damp cloth. Use a mild cleaner if necessary, then wipe dry with a clean cloth.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.

7. TROUBLESHOOTING

- **Rail feels loose:** Check that all mounting screws are securely tightened. Ensure the rail is properly seated in its brackets.
- **Rail sags or bends:** Reduce the weight on the rail. Ensure the total weight of clothes does not exceed 24 kg.
- **Difficulty installing:** Refer to the detailed assembly instructions provided with your PLATSA storage system. Ensure you are using the correct hardware for your specific PLATSA frame.

8. SPECIFICATIONS

Model Number	IK.604.501.27
Dimensions (W x D)	60 x 40 cm
Material	Engineered wood
Color	White
Maximum Weight Load	24 kg (53 lbs)
Assembly Required	Yes
Compatibility	Ikea PLATSA storage system

9. WARRANTY AND SUPPORT

For information regarding warranty, returns, or further product support, please refer to the documentation provided at the time of purchase or visit the official Ikea website. You can also contact Ikea customer service directly for assistance with your HJÄLPA clothes rail or PLATSA storage system.