

[Manuals.plus](#) /

› [IKEA](#) /

› IKEA PAX 4 Wardrobe Frames User Manual

IKEA PAX 4

IKEA PAX 4 Wardrobe Frames User Manual

Model: PAX 4 (200x35x201 cm, White)

WELCOME TO YOUR IKEA PAX WARDROBE SYSTEM

This manual provides essential information for the assembly, use, and maintenance of your new IKEA PAX 4 wardrobe frames. Please read these instructions carefully to ensure proper installation and long-lasting enjoyment of your product. For additional support, please visit the official IKEA website or contact customer service.

KEY FEATURES

- **Customizable Interior:** Designed to be complemented with interior organizers from the KOMPLEMENT series, allowing for personalized storage solutions.
- **Adjustable Stability:** Equipped with adjustable feet to compensate for any irregularities in the floor, ensuring a stable and level installation.
- **Durable Construction:** Built to last for years, providing reliable storage for your belongings.
- **Flexible Design:** Choose the width and depth of the frames according to your available space, then customize with doors and interior organizers (sold separately).
- **Extended Guarantee:** Comes with a 10-year guarantee, covering defects in materials and workmanship. Refer to the guarantee brochure for full terms.

PRODUCT OVERVIEW

The IKEA PAX 4 wardrobe frames provide the foundational structure for a versatile and customizable storage system. These frames are designed to be robust and adaptable, forming the core of your wardrobe solution. The image below shows the four individual wardrobe frames assembled together, ready for interior fittings and doors.



Image: Four white IKEA PAX wardrobe frames, assembled and ready for customization.

SETUP AND ASSEMBLY

Assembly of the IKEA PAX wardrobe frames requires careful attention to detail. It is recommended to have at least two people for assembly. Always follow the detailed assembly instructions provided in the packaging. Ensure you have all necessary tools before

beginning.

General Assembly Steps:

1. **Unpack Components:** Carefully unpack all boxes and lay out components on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in your assembly guide to identify all screws, dowels, panels, and other hardware.
3. **Assemble Frames:** Follow the step-by-step diagrams to connect the side panels, top, and bottom panels for each frame.
4. **Attach Back Panels:** Secure the back panels to the assembled frames.
5. **Connect Frames:** If assembling multiple frames, connect them securely using the provided hardware.
6. **Adjust Feet:** Use the adjustable feet to level the wardrobe frames on uneven floors.
7. **Secure to Wall:** For safety, it is crucial to secure the wardrobe frames to the wall using the anti-tip hardware provided. This prevents tipping accidents.



Image: Dimensions of the IKEA PAX 4 wardrobe frames: 78.74 inches wide, 13.78 inches deep, and 79.13 inches high.

OPERATING INSTRUCTIONS

The IKEA PAX wardrobe frames serve as the structural foundation for your clothing and storage needs. Once assembled and secured, you can begin to customize the interior with KOMPLEMENT series organizers such as shelves, drawers, clothes rails, and wire baskets. Doors can also be added to enclose the contents.

- **Interior Customization:** Install KOMPLEMENT interior fittings according to your storage requirements. Ensure fittings are securely attached to the pre-drilled holes.
- **Door Installation:** If adding doors, follow the specific instructions provided with the door sets for proper alignment and hinge installation.
- **Weight Distribution:** Distribute weight evenly within the wardrobe. Avoid overloading shelves or drawers to prevent damage or

instability.

- **Regular Checks:** Periodically check that all screws and fittings are tight, especially after initial use.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your IKEA PAX wardrobe frames.

- **Cleaning:** Wipe clean with a cloth dampened in a mild cleaner. Wipe dry with a clean cloth. Avoid abrasive cleaners or harsh chemicals.
- **Dusting:** Regularly dust surfaces with a soft, dry cloth.
- **Hardware Check:** Periodically check all assembly fittings and re-tighten if necessary to ensure stability.
- **Avoid Moisture:** Protect the wardrobe from excessive moisture and direct sunlight, which can cause warping or discoloration.

TROUBLESHOOTING

Here are some common issues and their potential solutions:

- **Wobbly Frame:** Ensure all assembly screws are tightened. Use the adjustable feet to level the wardrobe on uneven floors. Verify that the wardrobe is securely anchored to the wall.
- **Doors Not Aligning (if installed):** Check hinge adjustments. Ensure the frame itself is level and plumb.
- **Difficulty Installing Interior Fittings:** Ensure you are using the correct KOMPLEMENT series fittings for your PAX frame depth. Verify that the pre-drilled holes are clear.
- **Missing Parts:** If you discover missing parts during assembly, contact IKEA customer service with your product information and part numbers.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	13.78 x 78.74 x 79.13 inches (Depth x Width x Height)
Manufacturer	IKEA
ASIN	B0BW8W832R
Date First Available	February 15, 2023
Brand	IKEA
Material	Engineered Wood
Number of Drawers	4 (Note: This refers to the capacity for drawers, not that drawers are included with the frames.)

WARRANTY INFORMATION

Your IKEA PAX wardrobe frames are covered by a **10-year guarantee**. This guarantee covers defects in material and workmanship under normal domestic use. Please retain your proof of purchase. For full terms and conditions of the guarantee, refer to the guarantee brochure included with your product or visit the official IKEA website.

CUSTOMER SUPPORT

Should you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact IKEA customer service. You can find contact information on the official IKEA website or by visiting your local IKEA store. Please have your product model (PAX 4) and ASIN (B0BW8W832R) ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question