

[Manuals.plus](#) /

› [IKEA](#) /

› IKEA BEKANT Desk User Manual

IKEA IK.390.063.55

IKEA BEKANT Desk User Manual

Model: IK.390.063.55 | Brand: IKEA

INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your IKEA BEKANT Desk (140x60 cm, White). Please read these instructions carefully before beginning assembly or use to ensure safe and proper functionality.

Safety Warning: This desk is not designed for heavy or difficult use. Please exercise caution during use to prevent damage or injury.

SETUP AND ASSEMBLY

The IKEA BEKANT Desk requires assembly. Ensure all components are present before starting. The package includes the desktop surface, adjustable legs, and two drawers.

- Unpack Components:** Carefully remove all parts from the packaging. Verify against the included parts list (not provided in this manual, refer to original packaging).
- Attach Legs:** Securely attach the adjustable legs to the desktop surface. Follow the specific instructions provided in the original IKEA assembly guide for correct orientation and fastening.
- Install Drawers:** Assemble and install the two drawers according to the manufacturer's instructions. Ensure they slide smoothly.
- Cable Management:** Utilize the integrated cable management net under the desk to organize power cords and cables, maintaining a tidy workspace.



Image: The IKEA BEKANT Desk set up in a room, demonstrating its appearance in a typical home or office environment. Note the spacious desktop and clean lines.



Image: A view of the underside of the BEKANT desk, highlighting the practical cable management net designed to keep wires organized and out of sight.

OPERATING INSTRUCTIONS

The IKEA BEKANT Desk is designed for general work use. Its adjustable legs allow for customization of the desk height to suit individual preferences and ergonomic needs.

- **Adjusting Height:** The desk features adjustable legs. To change the height, locate the adjustment mechanism on each leg (refer to the original assembly guide for exact location and method). Loosen the locking mechanism, adjust the leg to the desired height, and then securely tighten the locking mechanism. Ensure both legs are adjusted to the same height for stability.
- **Drawer Use:** The two integrated drawers provide convenient storage for office supplies, documents, or personal items. Ensure not to overload the drawers to maintain smooth operation.



Image: A clear front view of the IKEA BEKANT Desk, showcasing its minimalist design and white finish. This image represents the desk in its assembled state.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your BEKANT desk.

- **Cleaning:** Wipe the desk surface and legs with a damp cloth. Use a mild cleaner if necessary. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the melamine surface.
- **Weight Distribution:** Distribute weight evenly across the desktop. Avoid placing excessively heavy items in one concentrated area.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.



Image: A detailed close-up of the desk's corner, showing the smooth, rounded edge and the white melamine finish, which is easy to clean and maintain.

TROUBLESHOOTING

If you encounter issues with your BEKANT desk, consider the following common solutions:

- **Desk Wobbles:** Ensure all leg fasteners are securely tightened. Verify that the floor surface is even; use shims if necessary. Confirm both adjustable legs are set to the same height.
- **Drawers Stick:** Check for obstructions inside the drawer or along the runners. Ensure the drawer slides are properly aligned and lubricated if needed.
- **Surface Damage:** For minor scratches, touch-up pens or repair kits designed for melamine surfaces may be used. For significant damage, consider contacting IKEA customer service for advice.

SPECIFICATIONS

Attribute	Detail
Brand	IKEA
Model Number	IK.390.063.55
Color	White
Dimensions (L x W x H)	140 cm x 60 cm x 65 cm (approx. 59.99 x 140 x 65 cm as per product data)
Material	Wood (Base), Melamine (Top Surface)
Features	Adjustable Height, Integrated Cable Management, 2 Drawers
Recommended Use	Work, Home Office
Assembly Required	Yes

WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation provided with your original purchase or visit the official IKEA website. IKEA products typically come with a limited warranty covering defects in materials and workmanship.

If you require further assistance, have questions about assembly, or need to report a missing part, please contact IKEA customer support directly. You can usually find contact information on the IKEA website or on your purchase receipt.

Online Resources: For additional support, assembly videos, or spare parts, visit the official [IKEA website](#).

© 2023 IKEA. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question