

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [ist computers](#) /

> HP 15 Laptop User Manual - Intel Core i5, 16GB RAM, 512GB SSD

## ist computers HP 15 Laptop

# HP 15 Laptop User Manual

Model: HP 15 Laptop

## 1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HP 15 Laptop. This device is equipped with an Intel Core i5 processor, 16GB RAM, and a 512GB SSD, running on Windows 11 Home. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your laptop.

## 2. PACKAGE CONTENTS

Verify that all items are present in the box:

- HP 15 Laptop
- 45W AC Adapter with Power Cord
- User Manual (this document)
- 1 Year Warranty information



Image: Contents of the HP 15 Laptop box, including the laptop, power adapter, and documentation.

### 3. PRODUCT FEATURES

- **Reliable Performance:** Equipped with an Intel Core i5-1135G7 Processor, 16GB DDR4 RAM, and a 512GB PCIe NVMe M.2 SSD for efficient operation and fast storage.
- **Extended Battery Life:** Designed for up to 10 hours of battery life, allowing for prolonged use without frequent recharging.
- **Clear Display:** Features a 15.6" FHD (1920 x 1080) IPS micro-edge anti-glare BrightView Display with Intel Iris Xe graphics. Supports external monitors via HDMI at 4K (3840x2160) @60Hz.
- **Integrated Webcam:** HD webcam with advanced noise reduction software and dual array digital microphone for clear video calls. Includes a physical privacy shutter.
- **Versatile Connectivity:** Includes USB 3.2 Type-C 5Gbps ports, USB 3.1 Type-A 5Gbps ports, HDMI 1.4b, SD media card reader, and an Audio combo jack.
- **Wireless Capabilities:** Supports Wi-Fi 5 (802.11ac) and Bluetooth 5 for reliable wireless connections.
- **Operating System:** Pre-installed with Windows 11 Home 64-bit, featuring AI-powered Copilot for enhanced productivity.

## Go longer, faster




Long-lasting battery life lets you stay connected all day. A precision touchpad speeds up navigation and productivity.



Image: The HP 15 Laptop displaying a video conference, highlighting its webcam and display features.

# Be seen. Be heard. On your terms.



Get the point across with advanced noise reduction software and a high quality camera you can close when not in use.

**HP True Vision Camera** with temporal noise reduction and dual array digital microphone for face-to-face communication



Edge-to-edge  
Full HD display



Image: Close-up view of the HP 15 Laptop's side, illustrating the various input/output ports including USB-C, HDMI, and SD card reader.

## 4. SETUP GUIDE

### 4.1 Initial Power On

1. **Connect Power:** Plug the AC adapter into the laptop's power port and then into a wall outlet.
2. **Open Laptop:** Carefully open the laptop lid.
3. **Power On:** Press the power button, usually located on the top right of the keyboard.
4. **Initial Windows Setup:** Follow the on-screen instructions to complete the Windows 11 Home setup, including language, region, network connection, and user account creation.

### 4.2 Connecting Peripherals

Use the available ports to connect external devices:

- **USB Devices:** Connect mice, keyboards, external drives, or printers to the USB Type-A or USB Type-C ports.
- **External Display:** Use an HDMI cable to connect to an external monitor or TV.
- **Audio Devices:** Plug headphones or external speakers into the audio combo jack.

- **SD Cards:** Insert SD media cards into the multi-format SD media card reader.

# Reliable performance



The Intel Core i5 processor powers your ability to tackle the busiest days with supreme performance and battery life.




Image: Detailed view of the laptop's I/O ports, including Multi-format SD media card reader, Headphone/microphone combo, USB Type-C, HDMI 1.4b, AC Smart pin, and USB Type-A ports.

## 5. OPERATING INSTRUCTIONS

### 5.1 Basic Navigation

- **Touchpad:** Use the integrated touchpad for cursor control. Tap to click, use two fingers to scroll, and pinch to zoom.
- **Keyboard:** The laptop features a full-size keyboard with a numeric keypad. Function keys (F1-F12) provide quick access to system settings when pressed with the Fn key.
- **Windows 11:** Familiarize yourself with the Windows 11 interface, including the Start Menu, Taskbar, and Action Center.

### 5.2 Using the Webcam

The integrated HD webcam is suitable for video calls and online meetings. Ensure the privacy shutter (if present) is open before use. Access webcam settings through Windows settings or your video conferencing application.

# View more, carry less



See your photos, videos and projects on a 15.6" micro-edge bezel display in a portable laptop designed for travel.



Image: The HP 15 Laptop's screen showing a video call, with callouts for the HP True Vision Camera and Edge-to-edge Full HD display.

## 6. MAINTENANCE

### 6.1 Cleaning

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Keyboard and Chassis:** Use a soft cloth to wipe surfaces. For dust, use compressed air.
- **Ports:** Keep ports free of dust and debris to ensure proper connectivity.

### 6.2 Software Updates

Regularly check for and install Windows updates and driver updates to ensure optimal performance and security. Go to **Settings > Windows Update**.

### 6.3 Battery Care

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.

- For long-term storage, charge the battery to about 50-70%.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Laptop does not power on.	No power, discharged battery, hardware issue.	Ensure AC adapter is securely connected and outlet is working. Charge battery for at least 30 minutes. If issue persists, contact support.
Screen is blank.	Sleep mode, display settings, external monitor connected.	Press any key or move the mouse to wake from sleep. Press <b>Fn</b> + <b>F4</b> (or equivalent display toggle key) to cycle display outputs. Disconnect external monitors.
Wi-Fi not connecting.	Wi-Fi disabled, incorrect password, router issue.	Check Wi-Fi settings in Windows to ensure it's enabled. Verify Wi-Fi password. Restart your router and modem.
Laptop runs slowly.	Too many programs open, low disk space, malware.	Close unnecessary applications. Free up disk space. Run a virus scan. Check for and install system updates.

## 8. SPECIFICATIONS

Feature	Detail
Brand	ist computers
Model Name	HP 15 Laptop
Screen Size	15.6 Inches
Color	Silver
CPU Model	Intel Core i5-1135G7 (11th Gen)
Processor Speed	2.4 GHz (up to 4.2 GHz)
RAM Memory Installed Size	16 GB DDR4 (3200 MHz)
Hard Disk Size	512 GB SSD (PCIe NVMe M.2)
Operating System	Windows 11 Home 64-bit
Graphics Coprocessor	Intel Iris Xe Graphics (Integrated)
Display Resolution	1920x1080 Pixels (FHD)
Refresh Rate	60 Hz
Wireless Connectivity	Wi-Fi 5 (802.11ac), Bluetooth 5
USB Ports	1x USB 3.2 Type-C, 2x USB 3.1 Type-A
HDMI Ports	1x HDMI 1.4b
Other Ports	SD Media Card Reader, Audio Combo Jack

Feature	Detail
Webcam	HD Webcam (0.9 MP Front Photo Sensor Resolution)
Battery Life (Average)	10 Hours
Item Weight	3.8 Pounds
Dimensions (L x W x Thickness)	14.11"L x 9.53"W x 0.71"Th



Image: The HP 15 Laptop with its dimensions labeled: 15.6" (D), 0.78" (H), 14.11" (W), and weight 3.75 lb.

## 9. WARRANTY AND SUPPORT

Your HP 15 Laptop comes with a **1-year limited warranty** from the manufacturer on remaining components. Additionally, the upgraded Memory/SSD components are covered by a **three-year warranty from Issaquah Highlands Tech**. For technical support or warranty claims, please refer to the contact information provided with your purchase documentation or visit the manufacturer's official support website.

## 10. PRODUCT VIDEO OVERVIEW

---

Your browser does not support the video tag.

Video: An overview of the HP 15 Laptop, showcasing its design and features. This video is provided by Issaquah Highlands Tech.