

Hermitlux TH04-60CM

Hermitlux TH04-60CM A 60cm Telescopic Hood User Manual

Model: TH04-60CM A

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Hermitlux TH04-60CM A 60cm Telescopic Hood. Please read it thoroughly before installation and operation, and keep it for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the appliance is properly installed and grounded by a qualified technician.
- Do not operate the hood if the power cord is damaged.
- Regularly clean grease filters to prevent fire hazards.
- Do not flambé under the range hood.
- Keep children away from the appliance during operation.
- For any anomalies, contact customer service before attempting repairs.

3. PRODUCT OVERVIEW

The Hermitlux TH04-60CM A is a 60cm telescopic hood designed for efficient kitchen ventilation, offering both recirculation and evacuation modes. It features powerful extraction, low noise operation, and easy-to-clean components.

Key Features:

- **Super Suction:** Maximum airflow of 360 m³/h for quick oil smoke absorption.
- **Low Noise:** Sound level below 65 dB for quiet cooking.
- **Smart Memory:** Retracting the slide interrupts operation; pulling it out restores the last setting.
- **Washable Filter:** Removable design for easy cleaning.
- **Rocker Switches & Energy-Saving LED Lights:** Simple toggle switches for speed control and sufficient LED

illumination.

Components Included:

- Mounting Material
- User Guide
- Installation Drawings
- Carbon Filters



Image 3.1: Front view of the Hermitlux TH04-60CM A telescopic hood with filters visible.

4. SETUP

Before installation, please test the performance of the hood. In case of any anomalies, contact customer service.

Installation Steps:

1. Refer to the provided installation drawings for precise measurements and mounting points.
2. Ensure adequate space for the hood (dimensions: 31.5D x 59.5W x 19.4H cm).
3. Mount the hood securely using the supplied mounting material.
4. Connect the power supply (220 Volts AC).
5. If using evacuation mode, connect the exhaust pipe (not included). For recirculation, ensure carbon filters are correctly installed.




Image 4.1: Detailed dimensions of the Hermitlux TH04-60CM A telescopic hood for installation planning.

Your browser does not support the video tag.

Video 4.1: Installation guide for a similar CIARRA telescopic hood, demonstrating unpacking and mounting steps. Note: This video is for a similar product (CIARRA CBCS6906D) and serves as a general installation reference.

5. OPERATING INSTRUCTIONS

Power On/Off and Speed Control:

- Pull out the telescopic slide to activate the hood.
- Use the simple rocker switches to select one of the two fan speeds.
- Push the telescopic slide back in to turn off the hood.
- The smart memory function will recall the last used setting when the slide is pulled out again.

LED Lighting:

- The integrated LED lights provide illumination for your cooking area.
- Control the lights using the dedicated rocker switch.



Image 5.1: Illustration of the hood operating at two different speeds, showing smoke extraction.

FILTRES EN ALUMINIUM HAUTE PERFORMANCE

Élimine efficacement la graisse et les odeurs



Image 5.2: Close-up of the rocker switches and LED light, highlighting the control interface.

Your browser does not support the video tag.

Video 5.1: Demonstration of a CIARRA integrated hood in operation, showing LED lighting and push-button controls. Note: This video is for a similar product (CIARRA CBCB5913A) and serves as a general operation reference.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your telescopic hood.

Cleaning the Grease Filters:

- The aluminum grease filters are removable and washable.
- To remove, locate the release tabs on the filters and gently pull them down.
- Clean the filters with warm soapy water or in a dishwasher. Ensure they are completely dry before re-installing.
- Regular cleaning (e.g., monthly, depending on usage) is recommended to maintain suction power and prevent grease buildup.

Replacing Carbon Filters (for Recirculation Mode):

- If your hood is operating in recirculation mode, the carbon filters need periodic replacement.
- Refer to the installation drawings for specific instructions on accessing and replacing the carbon filters.
- Replacement frequency depends on usage, typically every 3-6 months.

Cleaning the Exterior:

- Wipe the stainless steel exterior with a soft cloth and a mild, non-abrasive cleaner.
- Avoid using harsh chemicals or abrasive pads that could damage the finish.



Image 6.1: View of the removable aluminum filters, illustrating their design for easy cleaning.

Your browser does not support the video tag.

Video 6.1: Preview video demonstrating the removal and cleaning of filters for a FIREGAS hood. Note: This video is a short preview for a similar product (FIREGAS Hood) and serves as a general maintenance reference.

7. TROUBLESHOOTING

If you encounter issues with your hood, refer to the following common problems and solutions. If the problem persists, contact customer service.

Problem	Possible Cause	Solution
Hood not turning on	No power supply, loose connection, faulty switch.	Check power outlet, ensure hood is plugged in, verify switch position.
Low suction power	Clogged grease filters, incorrect fan speed, blocked exhaust duct.	Clean or replace grease filters, select higher fan speed, check for obstructions in the ductwork.
Excessive noise	Loose components, improper installation, foreign objects in fan.	Ensure all parts are secure, check installation, inspect fan for debris.
Lights not working	Faulty LED bulb, loose wiring.	Check light switch, replace LED bulb if necessary (consult service manual or technician).

8. SPECIFICATIONS

Feature	Specification
Brand	Hermitlux
Model Number	HMX-ESH04S60-AC
Dimensions (L x W x H)	31.5 x 59.5 x 19.41 cm
Weight	7.2 Kilograms
Color	Silver
Material	Stainless Steel
Airflow Capacity	360 m³/h
Noise Level	65 Decibels (max)
Number of Speeds	2
Light Source Type	LED
Filter Type	Carbon Filters (Grease Filter also included)
Control Type	Button (Rocker Switch)
Voltage	220 Volts (AC)
Power	71.5 Watts
Annual Energy Consumption	22.3 kWh/year
Ventilation Type	Ductless/Recirculating
Special Features	Grease filter, Rust resistant, Stain resistant, LED lighting









Image 8.1: Official product data sheet detailing technical specifications and energy efficiency ratings.

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service requests, please contact Hermitlux customer service. Refer to your purchase documentation for specific warranty terms and contact details.

If you have any questions or require assistance, please visit the [Hermitlux Brand Store](#) or contact the seller directly.

Related Documents - TH04-60CM

	<p>Hermitlux Range Hood Installation and User's Manual</p> <p>This manual provides instructions for the installation, use, and maintenance of Hermitlux range hoods, including models HMX-USB13G70-AC, HMX-UBF25A75-AC, HMX-USD24Y75-AC, HMX-USD28G75-AC, HMX-USF40G75-AC, and HMX-USB19G71-AC. It covers safety precautions, installation methods for ducted and recirculation options, wall mounting, slim model installation, built-in model installation, filter installation, operation, maintenance, and troubleshooting.</p>
	<p>Hermitlux VH4160S-AC Dunstabzugshaube: Bedienungs- und Installationsanleitung</p> <p>Umfassende Bedienungs- und Installationsanleitung für die Hermitlux VH4160S-AC Dunstabzugshaube, einschließlich Betrieb, Reinigung, Wartung, Installation und Fehlerbehebung.</p>
	<p>Hermitlux Cooker Hood Installation Guide - VH1360E-CC, VH27C60S-AC, VH4160S-AC</p> <p>Detailed installation instructions for Hermitlux inclined cooker hoods (models VH1360E-CC, VH27C60S-AC, VH4160S-AC). Covers accessory lists, assembly overview, and step-by-step guidance for both recirculating and exhaust air modes.</p>
	<p>Hermitlux VH1360E-CC Dunstabzugshaube: Bedienungs- und Installationsanleitung</p> <p>Umfassende Bedienungs- und Installationsanleitung für die Hermitlux VH1360E-CC Dunstabzugshaube. Erfahren Sie mehr über Installation, Bedienung, Wartung und Fehlerbehebung.</p>
	<p>Hermitlux Range Hood Installation and User's Manual</p> <p>Comprehensive installation and user manual for Hermitlux range hoods, covering models HMX-USB13G70-AC, HMX-UBF25A75-AC, HMX-USD24Y75-AC, HMX-USD28G75-AC, HMX-USF40G75-AC, and HMX-USB19G71-AC. Includes safety precautions, installation guides for pyramid, slim, and built-in models, operation, maintenance, troubleshooting, and warranty information.</p>
	<p>Hermitlux DW03 Dishwasher Safety Instructions and Usage Guide</p> <p>Important safety instructions, warnings, and usage guidelines for the Hermitlux DW03 dishwasher. Learn how to operate your appliance safely and effectively.</p>