

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hasbro Gaming](#) /

› [Hasbro Gaming Twister Junior Instruction Manual \(Model HAS-F7478\)](#)

Hasbro Gaming HAS-F7478

Hasbro Gaming Twister Junior Instruction Manual

Model: HAS-F7478

PRODUCT OVERVIEW

The Twister Junior game offers an engaging animal adventure designed for young players. This versatile game features a double-sided mat and a reversible spinner, providing two distinct levels of play suitable for children aged 3 and up. It encourages turn-taking, color matching, animal recognition, movement, and balance, making it an ideal choice for family game nights or children's parties.

SETUP

What's Included

- Double-sided Twister mat
- Double-sided spinner board with arrow
- Game guide

Assembly

Adult assembly is required for the game components. Ensure all pieces are accounted for before beginning play.



Image: The Twister Junior game box, illustrating the double-sided mat and spinner, along with game components.

OPERATING INSTRUCTIONS

Game Modes

Level 1: Animal Safari

On the Animal Safari side of the mat, players spin to move along a safari trail. This mode focuses on introducing turn-taking, color matching, and animal recognition. Players take turns discovering colors and re-enacting animal sounds and movements. The first player to reach the end of the trail wins.



Image: The Animal Safari game mat, featuring a winding path with various animal characters on colored circles.

Level 2: Animal Party

Flip the mat over to the Animal Party side for a more active game. Players spin the spinner to determine which color and animal they must place their foot or hand on. This level encourages movement and balance. The last player remaining on the mat wins the game.



Image: The Animal Party game mat, displaying a grid of animal faces on colored circles for players to place their hands and feet.

Gameplay Directions

1. Choose a game side: Animal Safari or Animal Party.
2. Spin the pointer to determine the color and animal.
3. Place hands or feet on the corresponding color.
4. Continue taking turns until one player completes the game side or is the last one standing.




Image: Two children engaged in playing Twister Junior on the mat, with an adult observing and guiding the game.

Maintenance

To clean the game mat, wipe it with a damp cloth and mild soap. Allow it to air dry completely before storing. Keep the spinner and other components dry and free from dust.

Troubleshooting

If the spinner does not move freely, ensure it is properly attached to the board and that there are no obstructions. If any game pieces are lost, contact Hasbro Gaming customer support for assistance.

Specifications

Feature	Detail
Product Dimensions	1.61 x 13.11 x 10.51 inches
Item Weight	0.012 ounces
Item Model Number	HAS-F7478
Manufacturer Recommended Age	3 years and up
Players	2-4 players
Release Date	July 14, 2023
Language	English
Manufacturer	Hasbro

Warranty Information

For warranty details and information regarding product defects, please refer to the official Hasbro Gaming website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Customer Support

If you have any questions, require assistance, or need to report a missing part, please visit the Hasbro Gaming official website or contact their customer support line. Contact information can typically be found on the product packaging or the official brand website.