

[Manuals.plus](#) /

› [AECOJOY](#) /

› AECOJOY Aluminum Patio Furniture Loveseat (Model 16301GR-2) Instruction Manual

AECOJOY 16301GR-2


AECOJOY Aluminum Patio Furniture Loveseat (Model 16301GR-2) Instruction Manual

Model: **16301GR-2** | Brand: **AECOJOY**

1. INTRODUCTION

Thank you for choosing the AECOJOY Aluminum Patio Furniture Loveseat. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor furniture. Please read these instructions carefully before assembly and retain them for future reference.

PRODUCT DETAILS



Non-slip seat cushion

Each cushion is fitted with a non-slip cushion under it, which will allow you to use it without feeling any slippage

Durable Aluminum Structure

Rust-proof & Scratch Free, pure rustproof aluminum-made with coated surface help long-term use



Image 1.1: AECOJOY Aluminum Patio Furniture Loveseat, front view with light grey cushions.

2. SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the loveseat on a soft, clean surface to prevent scratching.
- Tighten all bolts and screws securely, but do not overtighten. Periodically check and retighten fasteners.
- Do not stand or jump on the loveseat.
- Keep children and pets away during assembly.
- Place the furniture on a level surface to prevent tipping.
- Avoid exposing cushions to prolonged heavy rain or extreme weather conditions to extend their lifespan.

3. PACKAGE CONTENTS

Verify that all components are included in your package before beginning assembly.

- Loveseat Frame Components (Aluminum sections)
- Seat Cushions (Light Grey)
- Back Cushions (Light Grey)
- Assembly Hardware (Bolts, Washers, Allen Wrench)

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow these steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, flat surface to prevent damage.
2. **Identify Parts:** Refer to the included diagram (if available in your physical manual) to identify each frame component (e.g., side frames, back frame, seat frame).
3. **Assemble Frame:** Connect the side frames to the seat frame and back frame using the provided bolts and washers. Hand-tighten all fasteners initially.
4. **Secure Connections:** Once all frame pieces are loosely connected, gradually tighten all bolts with the Allen wrench until secure. Do not overtighten.
5. **Place Cushions:** Position the seat and back cushions onto the assembled frame. The cushions feature non-slip backing to help keep them in place.

Product Dimensions




Image 4.1: Product dimensions showing the overall size of the loveseat (49.8" W x 23.6" D x 24.4" H) and cushion thickness (5").



Image 4.2: Detail showing the durable aluminum structure and the non-slip feature on the underside of the seat cushions.

5. OPERATING AND USAGE

The AECOJOY Loveseat is designed for outdoor use, providing comfortable seating for two individuals. Its modern design and durable materials make it suitable for various patio, garden, or backyard settings.

- **Placement:** Position the loveseat on a flat, stable surface.
- **Comfort:** The deep seats and high-rebound, thick foam cushions offer enhanced comfort.
- **Outdoor Use:** The aluminum frame is rust-proof and scratch-free, ideal for outdoor environments.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your AECOJOY Loveseat.

- **Frame Cleaning:** The aluminum frame can be easily wiped clean with a damp cloth. Avoid abrasive cleaners.
- **Cushion Care:** All cushion covers are removable and machine washable. Use cold water and a gentle cycle. Air dry or tumble dry on low heat.
- **Waterproof Fabric:** The cushion fabric is dirt-resistant and waterproof, but for best results, avoid prolonged exposure to heavy rain. Store cushions indoors during inclement weather or off-season.
- **Rust Prevention:** The frame is made of rust-proof aluminum. However, regular cleaning helps maintain its protective coating.
- **Fastener Check:** Periodically check all bolts and screws to ensure they remain tight. Retighten as necessary.



Image 6.1: Details highlighting the waterproof fabric, high-elastic cushions, and removable covers for easy cleaning.

7. TROUBLESHOOTING

If you encounter any issues with your loveseat, refer to the following common solutions:

- **Wobbly Loveseat:** Ensure all bolts are securely tightened. Check that the loveseat is placed on a flat, even surface.
- **Cushions Sliding:** The cushions are designed with non-slip backing. Ensure they are properly seated on the frame.
- **Difficulty Assembling:** Review the assembly instructions carefully. Ensure you are using the correct hardware for each step. Do not force parts together.

8. SPECIFICATIONS

Feature	Detail
Brand	AECOJOY
Model Number	16301GR-2
Type	Loveseat
Color	Light Grey
Style	Modern Patio Furniture Loveseat
Room Type	Backyard, Garden, Lawn, Outdoor, Patio

Item Dimensions (L x W x H)	49.8 x 23.6 x 24.4 inches
Seat Height	17.3 Inches
Item Weight	3.4 Pounds
Frame Material Type	Aluminum
Cushion Material	Cotton, Foam (Waterproof Fabric)
Assembly Required	Yes
Product Care Instructions	Easily Wipe with Damp Cloth, Removable Cushions for Wash

9. WARRANTY AND SUPPORT

For warranty information or product support, please contact AECOJOY customer service. Keep your purchase receipt and model number (16301GR-2) handy when contacting support.

Visit the AECOJOY Store for more products and information:[AECOJOY Store](#)

© 2023 AECOJOY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

