

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GEEZER](#) /

› [GEEZER Wireless Keyboard and Mouse Combo User Manual](#)

## GEEZER B0BWDQDPDJ

# GEEZER Wireless Keyboard and Mouse Combo

Model: B0BWDQDPDJ (A\_Coal Black)

## INTRODUCTION

Thank you for choosing the GEEZER Wireless Keyboard and Mouse Combo. This manual provides detailed instructions for setting up, operating, and maintaining your new wireless peripheral set. Designed for comfort and efficiency, this combo offers a seamless and quiet typing and navigation experience for various computing environments.

## PACKAGE CONTENTS

- GEEZER Wireless Keyboard
- GEEZER Wireless Mouse
- USB Nano Receiver (stored inside the mouse)
- Cleaning Brush
- User Manual (this document)

## SETUP

### 1. Inserting Batteries

The keyboard requires one AA battery and the mouse requires one AAA battery (batteries not included). Ensure correct polarity when inserting.

### 2. Connecting the Receiver (Plug & Play)

The USB Nano receiver is conveniently stored in the battery compartment of the mouse. Remove the receiver from the mouse.

# Plug and Play

One nano receiver connects both the wireless keyboard and mouse by 2.4G wireless connection



Image: The compact USB Nano receiver, ready to be plugged into a laptop for instant connectivity.

1. Locate the USB Nano receiver inside the mouse's battery compartment.
2. Plug the USB Nano receiver into an available USB port on your computer (PC, Laptop, Desktop, Smart TV, etc.).
3. The keyboard and mouse will automatically connect to your device. No additional drivers are required.

## OPERATING INSTRUCTIONS

### Basic Usage

The GEEZER keyboard features a full-sized 104-key layout with round, typewriter-style keycaps, providing a comfortable and quiet typing experience. The mouse offers precise optical tracking and a smooth scroll wheel.




Image: A user demonstrating the comfortable typing experience on the GEEZER wireless keyboard.

## Hotkey Functions

The keyboard includes 13 hotkey functions for quick access to multimedia and system controls. These are typically accessed by pressing the 'Fn' key in combination with the corresponding F-key (F1-F12) or other designated keys.

## Intelligent Auto-Sleep Function

To conserve battery life, both the keyboard and mouse are equipped with an intelligent auto-sleep function. If the devices are not used for more than a minute, they will enter sleep mode. To wake them up, simply click the mouse or press any key on the keyboard.



## Intelligent Auto-Sleep

Enter sleeping automatically while not using,  
save battery life and reduce battery replacement

Image: The keyboard and mouse in a low-light setting, indicating the intelligent auto-sleep feature for power saving.

### Ergonomic Design

The keyboard features an ergonomic design with adjustable foldable stands on the back, allowing you to set a comfortable typing angle to reduce wrist fatigue during prolonged use. The mouse is also designed for a comfortable hand-feeling.

# Ergonomic Design

Release wrist pressure and work effectively



Image: A close-up view of the keyboard's foldable stands and silicone non-slip pads, highlighting its ergonomic design.

## MAINTENANCE

### Cleaning

The keyboard features detachable keycaps, making cleaning easier. Use the provided cleaning brush to remove dust and debris from between the keys.



# Detachable Keycaps

Include a brush to deep clean for the keyboard

Image: Detachable keycaps shown alongside the included cleaning brush for easy maintenance.

## Battery Replacement

When the keyboard or mouse performance degrades (e.g., delayed response, connectivity issues), it may be time to replace the batteries. Refer to the 'Inserting Batteries' section for proper battery type and installation.

## TROUBLESHOOTING

Issue	Possible Solution
No connection/Lagging	Ensure the USB Nano receiver is securely plugged into a working USB port. Check battery levels and replace if necessary. Move the keyboard/mouse closer to the receiver (within 10m/33ft). Try plugging the receiver into a different USB port.
Keys not responding	Wake the keyboard from sleep mode by pressing any key. Check battery levels. Clean under the keycaps if debris is present.

Issue	Possible Solution
Mouse not tracking smoothly	<p>Ensure the mouse is on a clean, non-reflective surface.</p> <p>Check battery levels.</p> <p>Wake the mouse from sleep mode by clicking.</p>

## SPECIFICATIONS

Feature	Detail
Brand	GEEZER
Model	B0BWDQDPDJ (A_Coal Black)
Connectivity Technology	2.4G Wireless (USB Receiver)
Keyboard Layout	Full-Sized, 104 Keys, Round Keycap Typewriter Style
Compatible Devices	PC, Laptop, Desktop, Chrome-Book, Mac, Smart TV (with Windows XP/X/Win 7/8/10/2000/ME Vista iOS OS, etc.)
Operating Range	Up to 10m / 33ft
Special Features	Ergonomic Design, Intelligent Auto-Sleep, Detachable Keycaps, Wrist Rest
Keyboard Battery	1 x AA (not included)
Mouse Battery	1 x AAA (not included)
Item Weight	2.03 pounds
Package Dimensions	17.87 x 5.39 x 2.99 inches

## WARRANTY AND SUPPORT

If you encounter any problems during use, please contact us via Amazon email. We are committed to providing satisfactory solutions and will respond within 12 hours. For specific warranty details, please refer to the product listing on Amazon or contact the seller directly.

