

Shintenchi Kitchen Island

Shintenchi 42-inch Black Kitchen Island Cart Instruction Manual

Model: Kitchen Island | Brand: Shintenchi

1. INTRODUCTION

Thank you for purchasing the Shintenchi 42-inch Black Kitchen Island Cart. This manual provides essential information for the safe assembly, operation, and maintenance of your new kitchen island. Please read these instructions carefully before beginning assembly and retain them for future reference.

Important Safety Information

- Do not exceed the maximum weight capacity of **77 lbs (35 kg)** on the tabletop.
- Use caution when moving the cart on uneven surfaces to prevent tipping.
- Ensure all parts are properly secured before use. Regularly check and tighten fasteners as needed.
- Do not allow children to play on, with, or around the cart.
- Exercise care around sharp edges during assembly and use.

2. PARTS LIST AND HARDWARE

Before assembly, carefully unpack all components and verify that all parts and hardware are present. Refer to the included assembly diagram for a complete list of parts. Extra hardware is typically provided.



Image Description: An exploded diagram of the Shintenchi Kitchen Island Cart, illustrating all individual components, their labels, and overall dimensions (42"L x 18"W x 36.4"H). Key features like the drawer, cabinet, shelves, and towel rack are highlighted.

All necessary tools for assembly are included in the package. A Philips head screwdriver is required (not included).

3. ASSEMBLY INSTRUCTIONS

Assembly of the Shintenchi Kitchen Island Cart is designed to be straightforward. Follow the step-by-step instructions provided in the separate assembly manual included with your product. Here are some general tips:

- **Organize Parts:** Before starting, separate all screws and hardware to avoid confusion. Match part numbers to the plastic bags.
- **Follow Steps:** Assemble the cart step by step according to the manual's diagrams.
- **Avoid Overtightening:** The cart is constructed from wood material. When using a screwdriver, hand-tighten screws until you feel resistance, then stop. Overtightening can strip the material.
- **Door Hinge Adjustment:** The door hinges may require careful adjustment for proper alignment. There are typically adjustment screws on the hinges. Loosen them slightly to position the doors correctly, ensuring they close straight and do not rub against each other, then tighten the adjustment screws to secure the position.
- **Missing Pre-drilled Holes:** In rare cases, some pre-drilled holes might be missing. If this occurs, and you are confident the screw is essential, you may carefully create a small pilot hole with an awl or small drill bit before inserting the screw.



ADD COUNTER SPACE

Keep your kitchen clean and intuitive

Image Description: A detailed view of the assembled kitchen island cart, showcasing the storage drawer, double-door cabinet with an adjustable shelf, open shelves, and a wine rack. This image helps visualize the internal structure during assembly.

4. OPERATION AND FEATURES

Your Shintenchi Kitchen Island Cart is designed to enhance your kitchen's functionality and organization.

Ample Storage Space

- **Large Worktop:** The 42"L x 18"W tabletop provides a spacious surface for food preparation, dining, or holding small appliances.
- **Storage Drawer:** A convenient drawer is ideal for storing cutlery, napkins, or other small kitchen essentials.
- **Cabinet with Adjustable Shelf:** The double-door cabinet offers enclosed storage for larger items like pots, pans, or small appliances. The internal shelf is adjustable to accommodate various item heights.
- **Open Shelves & Wine Rack:** Utilize the open shelves for frequently accessed items, decorative pieces, or additional storage. The integrated wine rack securely holds bottles.

- **Towel Rack:** A side-mounted towel rack provides easy access to kitchen towels or paper towel rolls.




Image Description: A front view of the kitchen island cart, highlighting its various storage components: a top drawer, a double-door cabinet with an adjustable shelf, open shelves, and a wine rack. A towel rack is visible on the side.

Mobility and Stability

The kitchen island is equipped with four universal wheels for easy movement, two of which include brakes for stability.

- **Moving:** To move the cart, ensure the wheel brakes are disengaged. Push or pull the cart to your desired location.
- **Locking:** To secure the cart in place, engage the brakes on the two lockable wheels. This prevents unintended movement.



Image Description: A close-up view of one of the kitchen island's caster wheels, showing its 360-degree rotation capability and the locking mechanism. The image also illustrates the difference between unlocked and locked wheels.

5. CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your kitchen island cart.

- **Cleaning:** Wipe the surfaces with a dry cloth. For spills, use a slightly damp cloth and dry immediately. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.

- **Air Out:** Upon initial unpacking, if a slight chemical odor is present, wipe the interior surfaces and allow the cart to air out in a well-ventilated area for a few days.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary to maintain structural integrity.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your kitchen island cart.

Problem	Possible Cause	Solution
Doors do not align or close properly.	Hinges are not correctly installed or adjusted.	Loosen the adjustment screws on the hinges, align the doors to be straight and even, then retighten the screws. Ensure all hinge screws are fully secured.
Cart feels wobbly when rolling.	Loose connections or cam locks not fully engaged.	Ensure all cam locks and screws throughout the cart are fully tightened. Avoid moving the cart over very uneven surfaces.
Missing or stripped hardware.	Manufacturing variation or overtightening during assembly.	Check the hardware bag for extra pieces. If critical hardware is missing or damaged, contact customer support for replacements.
Strong odor upon unboxing.	New product off-gassing.	Wipe down all surfaces with a dry or slightly damp cloth and allow the cart to air out in a well-ventilated room for several days.

7. PRODUCT SPECIFICATIONS

- **Model:** Kitchen Island
- **Brand:** Shintenchi
- **Product Dimensions:** 18"D x 42"W x 36.4"H
- **Color:** Black
- **Frame Material:** Wood
- **Shelf Type:** Tiered Shelf
- **Number of Shelves:** 1 (adjustable within cabinet)
- **Item Weight:** 72 pounds
- **Maximum Weight Recommendation (Tabletop):** 77 Pounds
- **Assembly Required:** Yes
- **UPC:** 850050319047

8. WARRANTY AND CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Shintenchi Kitchen Island Cart, please contact Shintenchi customer support. While specific warranty details are not provided in this manual, Shintenchi typically offers support for product defects and missing parts.

You can visit the official Shintenchi store for more information or to contact support:

[Visit the Shintechi Store on Amazon](#)

© 2025 Shintechi. All rights reserved.