

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LELO](#) /

› [LELO TOR 3 Vibrating Ring Instruction Manual](#)

LELO TOR 3

LELO TOR 3 Vibrating Ring Instruction Manual

Model: TOR 3

INTRODUCTION

The LELO TOR 3 is an app-connected vibrating ring designed for enhanced sensation. Crafted from body-safe silicone, it features 8 pleasure settings and is fully waterproof. This manual provides essential information for the safe and effective use, maintenance, and care of your LELO TOR 3.

WHAT'S IN THE BOX

Upon unboxing your LELO TOR 3, please ensure all components are present:

- LELO TOR 3 Vibrating Ring
- USB Charging Cable
- Satin Storage Pouch
- Instruction Manual
- Warranty Registration Card
- Moisturizer Sachet (5 ml / 0.17 fl. oz.)

TOR™ 3
vibrating couples' ring



MANUAL
how to use guide



MOISTURIZER SACHET
water-based lubricant
5 ml / 0.17 fl. oz.



CHARGING CORD
USB cable



WARRANTY CARD
verifies product authenticity



SATIN POUCH
for storage

Figure 1: LELO TOR 3 Package Contents

The LELO TOR 3 is designed with a flexible diameter of 29 mm / 1.1 inches to accommodate various sizes.




Figure 2: LELO TOR 3 Device Overview

FEATURES

The LELO TOR 3 incorporates several features for an optimal experience:

- **8 Pleasure Settings:** Offers a range of intensities from gentle vibrations to satisfying pulses.
- **App-Controlled:** Connects via Bluetooth to the LELO app for additional control and settings.
- **Soft Silicone:** Made from extra-soft, body-safe silicone for comfort.
- **Flexible Design:** Adapts to various shapes and sizes.
- **Waterproof:** IPX7 certified, making it safe for use in the bath or shower and easy to clean.
- **USB Rechargeable:** Convenient and fast recharging.




Figure 3: Key Features of LELO TOR 3

SETUP

Initial Charging

Before first use, fully charge your LELO TOR 3 for 2 hours. Connect the USB charging cable to the device and a USB power source. The LED lights will blink to indicate the battery level during charging.

App Connection

To utilize the app-controlled features, ensure Bluetooth is activated on your smartphone. Download and open the official LELO app. Follow the in-app instructions to pair your LELO TOR 3 device.

OPERATING INSTRUCTIONS

Basic Controls

- **To Turn On:** Press the + button.
- **To Switch Settings:** Press the + or - button to cycle through the 8 pleasure settings.

- **To Turn Off:** Press and hold the - button.

Using the LELO App

Once connected via Bluetooth, the LELO app provides additional control over vibration patterns and intensities, allowing for a customized experience. Refer to the app's interface for detailed options.



Figure 4: LELO TOR 3 Usage Guide

MAINTENANCE

Cleaning

The LELO TOR 3 is fully waterproof (IPX7 certified) and easy to clean. After each use, wash the device with warm water and a mild, toy-safe soap. Rinse thoroughly and pat dry with a lint-free cloth or allow it to air dry completely before storage.

Storage

Store your LELO TOR 3 in its satin pouch in a clean, dry place, away from direct sunlight and extreme temperatures. Avoid storing it with other materials that could potentially damage the silicone.

TROUBLESHOOTING

- **Device Not Turning On:** Ensure the device is fully charged. Connect it to the USB charging cable and allow it to charge for the recommended 2 hours.
- **App Connectivity Issues:** Verify that Bluetooth is enabled on your smartphone and that the LELO app is updated to the latest version. Ensure the device is within close proximity to your phone. If issues persist, try restarting both the device and your phone.
- **Device Shuts Off Unexpectedly:** This can sometimes be related to low battery or intermittent app connectivity. Ensure the device is fully charged before use. If using the app, maintain a stable Bluetooth connection. If the problem continues, contact LELO customer support.
- **Vibrations Feel Weak:** Ensure the device is fully charged. If the issue persists, it may indicate a need for service.

For further assistance, please refer to the LELO official support channels.

SPECIFICATIONS

Attribute	Detail
Model Name	TOR 3
Item Model Number	85092
Brand	LELO
Material	Silicone
Color	Black
Product Dimensions	2.36 x 1.84 x 0.87 inches
Weight	1.23 ounces
Batteries	1 Lithium Ion battery (included)
Waterproof Rating	IPX7

WARRANTY AND SUPPORT

Your LELO TOR 3 comes with a warranty. Please refer to the included Warranty Registration Card for details on how to register your product and the terms of the warranty. Registering your product ensures you receive full warranty coverage and access to customer support.

For technical support, troubleshooting, or warranty claims, please visit the official LELO website or contact their customer service directly. Contact information can typically be found on the LELO website or on your warranty card.

