

[manuals.plus](#) /› [Lisciani](#) /› [Lisciani Carotina Baby Microphone 2-in-1 Instruction Manual](#)

Lisciani 100606

Lisciani Carotina Baby Microphone 2-in-1 Instruction Manual

MODEL: 100606

1. Introduction

The Lisciani Carotina Baby Microphone 2-in-1 is an interactive educational toy designed to stimulate sensory development and imagination in children from 12 months of age. This device combines a microphone with light and sound effects, encouraging creative play and musical exploration.

2. Safety Information

- This product complies with the latest safety regulations.
- Requires 3 x AAA batteries (included). Ensure batteries are inserted with correct polarity.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Adult supervision is recommended during play.
- The materials used are of high quality, non-toxic, and designed for durability and child safety.
- Recommended for children aged 12 months and up.

3. Package Contents

- 1 x Lisciani Carotina Baby Microphone 2-in-1
- 3 x AAA Batteries (pre-installed or included separately)

4. Setup

4.1 Battery Installation

1. Locate the battery compartment cover on the base of the microphone.
2. Using a small screwdriver, loosen the screw and remove the cover.
3. Insert 3 x AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the cover and tighten the screw securely.

Note: The product typically comes with batteries included. Replace them when sounds become faint or lights dim.

5. Operating Instructions

5.1 Power On/Off

Locate the power button, usually on the handle. Press it once to turn the microphone on. Press it again to turn it off.

5.2 Microphone Functions

The Carotina Baby Microphone offers various interactive features:

- **Real Microphone Mode:** Speak or sing into the top of the microphone. Your voice will be amplified, and the lights will activate.
- **Melodies and Sounds:** Press the designated buttons on the handle to activate different melodies, sound effects, and phrases. The lights will flash in sync with the sounds.
- **Light Effects:** The microphone features integrated lights that illuminate during play, enhancing the sensory experience.





A vibrant yellow and blue microphone with a friendly green face on the top, featuring red light-up sections and control buttons on the handle.



A detailed view of the microphone highlighting its light-up sections and the various control buttons for different sounds and melodies.



A young child happily holding and playing with the Lisciani Carotina Baby Microphone, demonstrating its use for singing and imaginative play.

6. Maintenance

- Cleaning:** Wipe the microphone with a soft, slightly damp cloth. Do not immerse the product in water or use harsh cleaning agents.
- Storage:** Store the microphone in a cool, dry place away from direct sunlight when not in use. Remove batteries if the toy will not be used for an extended period to prevent leakage.

7. Troubleshooting

Problem	Possible Cause	Solution
No sound or lights	Batteries are dead or incorrectly installed.	Check battery polarity or replace with new AAA batteries.
Sound is distorted or faint	Batteries are low.	Replace all batteries with new AAA batteries.
Microphone not responding to buttons	Temporary electronic glitch.	Turn the microphone off and then on again. If the issue persists, replace batteries.

8. Specifications

- Model Number:** 100606
- Brand:** Lisciani
- Recommended Age:** 12 months and up
- Power Source:** 3 x AAA batteries
- Materials:** High-quality, non-toxic plastic
- Features:** 2-in-1 microphone, light effects, sound effects, melodies

9. Warranty and Support

Lisciani products are manufactured to high-quality standards. For information regarding warranty, returns, or technical support, please refer to the contact details provided on the product packaging or visit the official Lisciani website. Please retain your proof of purchase for any warranty claims.