

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [EUHOMY](#) /

› EUHOMY Countertop Ice Maker Machine User Manual

EUHOMY IM-06D-HM

EUHOMY Countertop Ice Maker Machine User Manual

Model: IM-06D-HM | Brand: EUHOMY

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the EUHOMY Countertop Ice Maker Machine. This portable ice maker is designed to provide fresh bullet ice quickly and efficiently, perfect for various settings including your home, kitchen, camping trips, RVs, and parties.

Key features of your EUHOMY Ice Maker include:

- **Rapid Ice Production:** Produces 9 ice cubes in as little as 6 minutes, with a daily capacity of up to 26 lbs.
- **Portable Design:** Features a sturdy handle and compact dimensions (11.57"D x 11.42"W x 8.74"H) for easy transport.
- **Auto-Cleaning Function:** Simplifies maintenance with a one-touch self-cleaning mode.
- **Smart Operation:** Equipped with infrared sensors to indicate "ICE FULL" and "ADD WATER" status.
- **Quiet Operation:** Operates at less than 45dB, ensuring a comfortable environment.

2. IMPORTANT SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage to the appliance or injury to yourself and others, please read all instructions thoroughly before using the EUHOMY Ice Maker. Keep this manual for future reference.

- Always connect the appliance to a grounded power outlet with the correct voltage (115 Volts).
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Unplug the ice maker from the power outlet before cleaning, servicing, or when not in use.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Ensure the ice maker is placed on a stable, level surface, away from direct sunlight or heat sources.
- Allow at least 4 inches of clearance around the appliance for proper ventilation.
- Do not use the appliance for anything other than its intended use (ice making).
- Supervise children closely when the appliance is in use.
- Use only potable water in the water reservoir.

- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

3. PRODUCT COMPONENTS

Your EUHOMY Ice Maker comes with the following components:

- Ice Maker Unit (with integrated handle)
- Ice Basket
- Ice Scoop
- User Manual (this document)



Figure 3.1: EUHOMY Countertop Ice Maker with included accessories.



THAT FITS EVERY SPACE!

COMPACT SIZE, BIG SURPRISE

No More 'Where Do I Put This?' Just Pure Ice Magic on Day One



Figure 3.2: Compact dimensions and components of the EUHOMY Ice Maker.

4. SETUP GUIDE

4.1 Unpacking and Placement

1. Carefully remove the ice maker from its packaging.
2. Place the unit on a flat, stable, and heat-resistant surface. Ensure there is adequate ventilation (at least 4

inches of space) around the unit.

3. Avoid placing the ice maker near heat sources or in direct sunlight.
4. Before first use, it is recommended to let the unit stand upright for at least 2 hours if it was not transported in an upright position. This allows the refrigerant to settle.

4.2 Initial Cleaning

Before making ice for consumption, clean the interior of the ice maker:

1. Remove the ice basket and ice scoop.
2. Clean the interior liner, ice basket, and ice scoop with diluted detergent, warm water, and a soft cloth.
3. Rinse the interior thoroughly with clean water.
4. Drain any remaining water from the unit. Refer to the "Maintenance and Cleaning" section for draining instructions.
5. Wipe all surfaces dry.

5. OPERATING INSTRUCTIONS

Operating your EUHOMY Ice Maker is simple and straightforward.

5.1 Making Ice

1. **Add Water:** Open the top cover and pour potable water into the water reservoir up to the "MAX" water level mark. Do not overfill.
2. **Power On:** Plug the ice maker into a grounded electrical outlet. Press the **ON/OFF** button on the control panel to start the ice-making cycle. The "POWER" indicator light will illuminate.
3. **Ice Production:** The ice maker will begin producing ice cubes. The first batch of ice may take slightly longer (around 6-10 minutes) and may be smaller or irregularly shaped. Subsequent cycles will be faster and produce more consistent ice.
4. **Ice Full Indicator:** When the ice basket is full, the "ICE FULL" indicator light will flash, and the ice maker will automatically stop production. Remove ice from the basket to resume operation.
5. **Add Water Indicator:** If the water level in the reservoir is too low, the "ADD WATER" indicator light will flash, and the unit will stop. Add more water to the reservoir to resume ice production.
6. **Harvesting Ice:** Use the provided ice scoop to remove ice from the basket.




Figure 5.1: Simplified steps for operating the ice maker.

5.2 Official Product Video: How to Use

Your browser does not support the video tag.

Video 5.1: An official video from EUHOMY demonstrating the use of the Countertop Ice Maker Machine. This video provides a visual guide to the setup and operation of the appliance, including adding water and starting the ice production process.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your ice maker.

6.1 Auto-Cleaning Function

The EUHOMY Ice Maker features a convenient one-touch auto-cleaning function:

1. Ensure the ice maker is empty of ice and water.
2. Add clean water to the reservoir up to the "MAX" line.
3. Press and hold the **"ON/OFF"** button for 5 seconds. The unit will enter auto-cleaning mode, which lasts for approximately 30 minutes.
4. Once the cleaning cycle is complete, drain the water from the unit.

SELF-CLEANING IN **5 SECONDS**, DONE IN 30 MINUTES

RELAX, IT'S HANDS-FREE!

No Scrubbing Needed – Enjoy Purer Ice
with Zero Effort.*



*It's recommended to pair with EUHOMY cleaner. Automatic cleaning removes 99% of bacteria. Descale once a month.

Figure 6.1: The self-cleaning process in action, ensuring purity with minimal effort.

6.2 Manual Cleaning and Draining

For thorough cleaning or before long-term storage:

1. Unplug the ice maker from the power outlet.
2. Remove the ice basket.
3. To drain the water, locate the drain plug at the bottom of the unit. Place a basin or towel underneath and remove the plug to allow water to flow out.
4. Clean the interior with a soft cloth and a mild, non-abrasive detergent. Rinse thoroughly.

5. Clean the exterior with a damp cloth.
6. Ensure all parts are completely dry before reassembling or storing the unit.

Note: It is recommended to descale the ice maker once a month to prevent mineral buildup, especially in areas with hard water.

7. TROUBLESHOOTING GUIDE

If you encounter issues with your EUHOMY Ice Maker, please refer to the following common problems and their solutions:

| Problem | Possible Cause | Solution |
|-----------------------------------|---|---|
| "ADD WATER" indicator flashes. | Water level is too low. | Add potable water to the reservoir up to the MAX line. |
| "ICE FULL" indicator flashes. | Ice basket is full. | Remove ice from the basket. |
| Ice maker is not producing ice. | No power, insufficient water, or ambient temperature too high. | Check power connection. Add water. Ensure room temperature is within operating range (typically 50°F-90°F). |
| Ice cubes are small or irregular. | First cycle, water temperature too high, or air bubbles. | This is normal for the first few cycles. Use colder water. Ensure proper ventilation. |
| Unusual noise during operation. | Normal operation sounds (compressor, water pump) or unit not level. | Ensure the unit is on a level surface. If noise is excessive or unusual, contact customer support. |

If the problem persists after attempting these solutions, please contact EUHOMY Customer Support for assistance.

8. PRODUCT SPECIFICATIONS

| Specification | Detail |
|--------------------------------|-------------------------|
| Brand | EUHOMY |
| Model Name | ice maker |
| Model Number | IM-06D-HM |
| Product Dimensions (D x W x H) | 11.42" x 8.74" x 11.57" |
| Ice Production Capacity | 26 Pounds per 24 Hours |

| Specification | Detail |
|----------------------|---------------------------------|
| Ice Storage Capacity | 1.3 Pounds (approx.) |
| Water Tank Capacity | 1.2 Liters |
| Wattage | 170 watts |
| Voltage | 115 Volts |
| Refrigerant | R600a |
| Material | Acrylonitrile Butadiene Styrene |
| Item Weight | 12.87 pounds |
| UPC | 197644191543 |

9. WARRANTY AND CUSTOMER SUPPORT

EUHOMY is committed to providing high-quality products and excellent customer service.

- **Warranty:** Your EUHOMY Ice Maker is covered by a 12-month warranty from the original purchase date.
- **Technical Support:** We offer lifetime technical service support for your product.

Should you have any questions, concerns, or require assistance with your ice maker, please do not hesitate to contact our customer support team. Our 7*24-hour customer support is always ready to help you.

For more information or to contact support, please visit the official EUHOMY website or refer to the contact details provided with your purchase documentation.