

Serounder Serounderat4m1xo9v2

Serounder Replacement Air Conditioner Remote Control User Manual

Model: Serounderat4m1xo9v2

INTRODUCTION

This manual provides instructions for the operation and maintenance of your Serounder Replacement Air Conditioner Remote Control. This remote is designed to be a direct replacement for original remote controls, specifically compatible with models such as RG67N BGEF and RG67V BGEF. It offers sensitive button response and full access to all necessary functions without the need for complex pairing.

SETUP

Battery Installation

The remote control requires **two AAA batteries** (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

Once batteries are installed, the remote is ready for use without any pairing process.

OPERATING INSTRUCTIONS

This remote control provides intuitive access to various air conditioner functions. Point the remote control directly at the air conditioner's receiver when operating.

Button Functions Overview



Figure 1: Front view of the remote control, highlighting the display and button layout.



Figure 2: Proper usage of the remote control, demonstrating it being pointed at an air conditioner unit.

Remote Control Button Functions

Button	Function
Power Button (Blue circle with line)	Turns the air conditioner On or Off.
Mode	Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
Temp Up/Down (Arrows)	Adjusts the desired temperature setting.
Fan	Adjusts fan speed settings.
Swing	Controls the vertical swing of the air conditioner's louvers.
My Mode	Activates a personalized or favorite setting (if supported by AC unit).
Timer On/Off	Sets a timer for the air conditioner to turn On or Off automatically.
ECO Sleep	Activates an energy-saving sleep mode.
Follow Me	Enables the air conditioner to sense the temperature at the remote's location (if supported by AC unit).
High Power	Activates a powerful cooling/heating mode for rapid temperature change.
LED	Turns the display light on the air conditioner unit On or Off.

Button	Function
Fix	Specific function, potentially for fixed louver position or diagnostic (refer to AC unit manual for details).

MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the display fades. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries. Obstruction between remote and AC unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit.
AC unit not responding to specific buttons.	Button malfunction. Feature not supported by AC unit.	Ensure the button is pressed firmly. Consult your AC unit's manual to confirm feature compatibility.
Display on remote is dim or blank.	Low battery power.	Replace batteries.

SPECIFICATIONS

- Brand:** Serounder
- Model Number:** Serounderat4m1xo9v2
- Compatible Models:** RG67N BGEF, RG67V BGEF, and similar
- Power Supply:** 2 x AAA Batteries (not included)
- Material:** ABS
- Connectivity Technology:** Infrared
- Package Dimensions:** 6.69 x 2.72 x 0.79 inches
- Item Weight:** 2.39 ounces
- Manufacturer:** Serounder
- Country of Origin:** China

WARRANTY AND SUPPORT

This product is designed for reliable performance. For any issues not covered in this manual, please refer to the original product listing or contact the seller for support.

Please note that warranty terms and conditions may vary. Keep your purchase receipt for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BWJ4S1LC>

More documents and user manuals: <https://manuals.plus/>