ZEBRONICS ZEB-VITA PRO

Zebronics ZEB-VITA PRO Wireless Speaker User Manual

Model: ZEB-VITA PRO | Brand: ZEBRONICS

Introduction

The Zebronics ZEB-VITA PRO is a versatile wireless Bluetooth speaker designed to deliver powerful audio with multiple connectivity options. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your speaker to ensure optimal performance.

What's in the Box

Carefully unpack your ZEB-VITA PRO speaker and ensure all items are present:

- Speaker Unit (1)
- Charging Cable (1)
- QR Code Guide (1)

Product Overview

The ZEB-VITA PRO speaker combines a sleek design with functional features for an enhanced audio experience.



This image highlights the key features of the ZEB-VITA PRO speaker, including its LED display, built-in rechargeable battery, media and volume controls, wall-mountable design, and connectivity options like USB and AUX.



The compact dimensions of the speaker are 474mm in length, 65mm in height, and 65mm in depth, making it suitable for various setups.

Controls and Ports

- **Power Button:** Press and hold to turn on/off.
- **Mode Button:** Toggle between Bluetooth, AUX, USB, mSD, and FM radio modes.
- **Volume Up/Next Track:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track:** Short press for volume down, long press for previous track.
- **Play/Pause/Call:** Play/pause music, answer/end calls.
- **USB Port:** For USB drive playback.
- **mSD Card Slot:** For microSD card playback.
- **AUX Input:** For wired audio connection.
- **Charging Port:** Connect the charging cable here.
- **LED Display:** Shows current mode, volume level, and battery status.

Setup

Initial Charging

1. Before first use, fully charge the speaker.
2. Connect the provided charging cable to the speaker's charging port and a compatible USB power adapter (DC 5V, 2A).
3. The LED display will indicate charging status. Once fully charged, disconnect the cable.

Powering On/Off

- To power on, press and hold the Power button until the LED display lights up.
- To power off, press and hold the Power button again until the LED display turns off.

Operating Instructions

Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth mode (indicated on the LED display).
2. Enable Bluetooth on your smartphone, tablet, or laptop.
3. Search for available devices and select "ZEB-VITA PRO" from the list.
4. Once paired, the speaker will confirm the connection.

AUX Mode

1. Connect one end of a 3.5mm audio cable (not included) to the AUX input port on the speaker.
2. Connect the other end to the audio output of your device.
3. Press the Mode button on the speaker until "AUX" is displayed.
4. Play audio from your connected device.

USB / mSD Card Playback

1. Insert a USB drive or a microSD card (up to 32GB) containing MP3 audio files into the respective port/slot.
2. The speaker will automatically switch to USB or mSD mode and begin playback. If not, press the Mode button to select the correct mode.

FM Radio

1. Press the Mode button until "FM" is displayed.
2. Long press the Play/Pause button to auto-scan and save available FM channels.
3. Use the Volume Up/Down buttons (long press) to navigate between saved channels.

TWS (True Wireless Stereo) Function

To experience true wireless stereo sound, you can pair two ZEB-VITA PRO speakers together:

1. Ensure both ZEB-VITA PRO speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one of the speakers (this will be the primary speaker), long press the Play/Pause button. You will hear an indication sound.
3. The two speakers will automatically connect to each other.
4. Once connected, pair your device to the primary speaker via Bluetooth as described above. Audio will now play in stereo through both speakers.

Call Function



The speaker supports a call function, allowing you to answer incoming calls directly through its built-in microphone when connected via Bluetooth to your smartphone.

- When connected to your smartphone via Bluetooth, the speaker's built-in microphone allows for hands-free calling.
- To answer an incoming call, short press the Play/Pause button.
- To end a call, short press the Play/Pause button again.
- To reject an incoming call, long press the Play/Pause button.

Charging

The ZEB-VITA PRO features a built-in rechargeable battery. To charge the speaker:

1. Connect the micro USB end of the charging cable to the speaker's charging port.
2. Connect the standard USB end to a USB power source (e.g., computer USB port, USB wall adapter).

3. The LED display will show the charging status. A full charge typically takes a few hours.
4. Once fully charged, the LED indicator will change or turn off. Disconnect the charging cable.



Enjoy extended listening sessions with up to 10 hours of playback time on a single charge (at 50% volume).

Maintenance

- Keep the speaker away from water, moisture, and direct sunlight.
- Do not expose the speaker to extreme temperatures.
- Clean the speaker with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Avoid dropping or subjecting the speaker to strong impacts.
- Store the speaker in a cool, dry place when not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on	Low battery; Power button not pressed correctly	Charge the speaker; Press and hold the Power button for a few seconds.
No sound	Volume too low; Incorrect mode selected; Device not connected	Increase volume; Press Mode button to select correct input; Re-pair Bluetooth or re-connect AUX/USB/mSD.
Bluetooth pairing fails	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker	Ensure speaker is in Bluetooth mode; Turn on device Bluetooth; Move device closer to speaker (within 10m).
TWS pairing fails	Speakers already connected to a device; Incorrect pairing procedure	Disconnect both speakers from any devices; Follow TWS pairing instructions carefully.
FM radio reception is poor	Weak signal; Interference	Move the speaker to a different location; Re-scan channels.

Specifications



The ZEB-VITA PRO speaker features dual 52mm drivers, delivering a powerful 24 Watts of audio output for clear and robust sound.

Feature	Detail
Speaker Output Power	24 Watts RMS
Connectivity Technology	Bluetooth v5.0, AUX, mSD Card, USB, FM Radio
Audio Output Mode	Stereo
Mounting Type	Wall Mount, Table Top
Control Method	Button, Touch
Speaker Driver Size	Dual 52 mm
Battery Average Life	10 Hours (at 50% volume)
Impedance	4 Ohms

Feature	Detail
Item Weight	913 Grams
Item Dimensions (D x W x H)	9D x 51W x 9H Centimeters
Compatible Devices	Smartphones, Tablets, Laptops, Televisions
Power Source	Battery Powered

Warranty and Support

Your Zebronics ZEB-VITA PRO speaker comes with a**1-year carry-in warranty** to the service center. For any technical assistance, service, or warranty claims, please contact Zebronics customer support.
Please retain your purchase receipt for warranty validation.

Product Overview Video

This video provides a visual overview of the Zebronics ZEB-VITA PRO wireless soundbar speaker, highlighting its design, audio performance, and connectivity features.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question