

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Coeshome](#) /

› [Coeshome 40 Inch Computer Desk Instruction Manual](#)

Coeshome B01011599USAN0222A4BAB4W

Coeshome 40 Inch Computer Desk Instruction Manual

INTRODUCTION

Welcome to your new Coeshome 40 Inch Computer Desk. This manual provides essential information for assembly, proper use, maintenance, and troubleshooting to ensure a long-lasting and satisfactory experience with your product. Please read these instructions carefully before beginning assembly or use.

PRODUCT OVERVIEW

The Coeshome 40 Inch Computer Desk is designed for versatility and durability, suitable for various environments such as home offices, study areas, and classrooms.



Image: The Coleshome 40 Inch Computer Desk, showcasing its vintage brown top and black metal frame, set up with a monitor, keyboard, and mouse.

Key Features

- **Diversified Use:** Suitable for various settings including home offices, study areas, and classrooms.
- **Compact Dimensions:** Measuring 40" (L) x 19" (W) x 29" (H), this desk is designed to fit smaller spaces while providing ample working room.
- **Sturdy Construction:** Features thick metal frames made of heavy-duty powder-coated steel for enhanced stability and safety.
- **Durable Desktop:** The desktop is waterproof, scratch-resistant, and heat-resistant.
- **Easy Assembly:** Designed for quick and straightforward assembly, typically within 30 minutes.
- **Low Maintenance:** Melamine veneer tabletop is waterproof, heat-resistant, and dust-free, requiring only a damp cloth for cleaning.

Components

- Desktop Panel (Vintage Brown)
- Desk Legs (Black Metal Frames)

- Crossbars/Support Beams
- Adjustable Feet Pads
- Assembly Hardware (Screws, Allen Wrench)
- Headphone Hook

SETUP AND ASSEMBLY

Follow these steps carefully to assemble your Coleshome Computer Desk.

Before You Begin

- Unpack all components and verify against the parts list provided in your packaging.
- Ensure you have a clear, spacious area for assembly.
- The necessary Allen wrench is included in the package.

Product Dimensions

| Ergonomic height and width



Image: Product dimensions diagram, indicating the desk is 40 inches long, 19 inches wide, and 29 inches high.

Assembly Steps

1. **Attach Feet Pads:** Screw the adjustable feet pads into the pre-drilled holes at the bottom of each desk leg.
2. **Assemble Leg Frames:** Connect the two desk leg frames using the provided crossbars. Secure them firmly with the screws and Allen wrench.
3. **Prepare Desktop:** Place the desktop panel upside down on a soft, clean surface to prevent scratches.
4. **Attach Frame to Desktop:** Align the assembled leg frame with the pre-drilled holes on the underside of the desktop. Secure the frame to the desktop using the appropriate screws.
5. **Install Headphone Hook:** Attach the headphone hook to the desired location on the desk frame using the provided screw.
6. **Final Positioning:** Carefully flip the desk upright and move it to its intended location. Adjust the feet pads to ensure the desk is level and stable.



Image: Detail of the desk's metal frame, illustrating its robust construction for high stability.



Image: A close-up view of the adjustable feet pads, designed to stabilize the desk on uneven surfaces.

OPERATING INSTRUCTIONS

To ensure optimal performance and longevity of your desk, please observe the following guidelines:

Proper Placement

- Always place the desk on a level surface to ensure maximum stability.

- Use the adjustable feet pads to fine-tune the desk's balance and prevent wobbling, especially on uneven floors.

Weight Capacity

- The maximum weight recommendation for this desk is **100 pounds (approximately 45 kg)**. Do not exceed this limit to prevent damage to the desk or potential injury.

Usage Tips

- Utilize the integrated headphone hook for convenient storage of headphones or other small, lightweight items.
- The desk is primarily designed for writing, computer work, and general home office activities.

MAINTENANCE

Regular care will help maintain the appearance and functionality of your Coleshome Computer Desk.

Cleaning

- Wipe the desktop and metal frame with a soft, damp cloth.
- Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- The melamine veneer tabletop is designed to be waterproof and dust-free for easy cleaning.



Image: A detailed view of the vintage brown desktop surface, highlighting its texture and easy-to-clean finish.

Regular Checks

- Periodically inspect all screws and connections to ensure they remain tight. Retighten any loose fasteners to maintain the desk's stability and structural integrity.

TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common solutions:

Desk is Unstable or Wobbly

- **Check Surface:** Ensure the desk is placed on a flat, level surface.
- **Adjust Feet Pads:** Rotate the individual adjustable feet pads at the bottom of the legs until the desk is stable and does not wobble.
- **Tighten Screws:** Re-check all assembly screws and tighten any that may have loosened over time.

Missing Parts or Damaged Components

- If any parts are missing or damaged upon arrival, please contact Coleshome customer support immediately for assistance.

SPECIFICATIONS

| | |
|--------------------------------|---|
| Brand | Coleshome |
| Model Number | B01011599USAN0222A4BAB4W |
| Product Dimensions (L x W x H) | 40"D x 19"W x 29"H (101.6 cm x 48.26 cm x 73.66 cm) |
| Color | Vintage Brown (Top), Black (Frame) |
| Style | Modern |
| Top Material Type | Engineered Wood (Melamine Veneer) |
| Base Material | Powder-Coated Steel |
| Item Weight | 17 Pounds (7.7 kg) |
| Maximum Weight Recommendation | 100 Pounds (45 kg) |
| Required Assembly | Yes |
| Included Components | Headphone Hook, Assembly Tools |

SAFETY INFORMATION

Please adhere to the following safety guidelines to prevent injury or damage to the product:

- **Weight Limit:** Do not exceed the maximum weight recommendation of 100 pounds (45 kg). Overloading the desk can cause structural failure and potential injury.
- **Proper Assembly:** Ensure all assembly steps are followed correctly and all fasteners are securely tightened. Incorrect assembly can compromise the desk's stability and safety.
- **Avoid Standing/Sitting:** This desk is not designed for standing or sitting on. Do not use it as a step stool or seat.
- **Children and Small Parts:** Keep small assembly parts away from children to prevent choking hazards.
- **Sharp Edges:** While the desk features anti-collision corners, exercise caution around all edges during handling and use.



Image: A close-up showing the anti-collision corner design of the desktop, enhancing user safety.

CUSTOMER SUPPORT

Coleshome is committed to ensuring your satisfaction with our products. If you have any questions, concerns, or require assistance with your 40 Inch Computer Desk, please do not hesitate to contact our customer support team.

Please refer to your purchase documentation or the Coleshome official website for specific contact details and warranty information.