

[Manuals.plus](#) /

› [Coleshome](#) /

› Coleshome 48 Inch Computer Desk Instruction Manual

Coleshome B01011611USAN0222A4GL8P9

Coleshome Computer Desk Instruction Manual

Model: B01011611USAN0222A4GL8P9 | Brand: Coleshome

INTRODUCTION

Thank you for choosing the Coleshome 48 Inch Computer Desk. This modern and simple style desk is designed to provide a functional and comfortable workspace for your home office, study, or student writing needs. Its vintage finish adds a touch of elegance to any room. This manual provides detailed instructions for assembly, usage, and maintenance to ensure you get the most out of your new desk.



Image: The Coleshome 48 Inch Computer Desk, featuring a vintage wood-grain top and black metal legs, set up with two computer monitors, a keyboard, and a mouse, demonstrating its spacious and functional design for a modern workspace.

COMPONENTS LIST

Before beginning assembly, please ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
Desktop Panel	48"L x 20"W x 0.5"H engineered wood with vintage vinyl finish.	1
Leg Frames	Black powder-coated alloy steel frames (U-shaped).	2
Cross Braces	Metal bars for stability.	2
Adjustable Feet Pads	For leveling the desk on uneven surfaces.	4

Part	Description	Quantity
Headphone Hook	Optional accessory for hanging headphones or bags.	1
Assembly Hardware	Screws, bolts, and Allen wrench.	1 Set

Product Dimensions

I Ergonomic height and width



Image: Detailed product dimensions of the Coleshome desk, indicating its ergonomic height and width for comfortable use.

SETUP INSTRUCTIONS

Assembly of the Coleshome Computer Desk is designed to be quick and straightforward, typically taking less than 30 minutes. All necessary tools are included in the package.

- Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface to ensure nothing is missing.
- Attach Leg Frames:** Secure the two metal leg frames to the underside of the desktop panel using the provided screws and Allen wrench. Ensure they are aligned correctly with the pre-drilled holes.
- Install Cross Braces:** Attach the cross braces between the leg frames. These provide additional stability to the desk. Tighten all screws firmly but do not overtighten.

4. **Attach Adjustable Feet Pads:** Screw the adjustable feet pads into the bottom of each leg. These can be adjusted later to level the desk on uneven flooring.
5. **Install Headphone Hook (Optional):** If desired, attach the headphone hook to either the inside or outside of a leg frame using the designated attachment point. This hook can also be used for bags or other accessories.
6. **Final Check:** Once assembled, gently lift and place the desk in its desired location. Adjust the feet pads as needed to eliminate any wobbling.



Image: A close-up view of the desk's sturdy metal frame, designed for high stability and durability.



Image: Detail of the adjustable feet pads, allowing for easy leveling on various floor types.

OPERATING GUIDELINES

The Coleshome Computer Desk is versatile and suitable for various uses:

- **Home Office:** Provides ample space for a monitor, laptop, keyboard, mouse, and other office essentials.
- **Study Desk:** Ideal for students, offering a dedicated area for textbooks, notebooks, and a computer.
- **Writing Desk:** A comfortable surface for writing, drawing, or other creative tasks.
- **Multi-purpose:** Can also serve as a gaming desk, craft table, or a compact workstation in smaller spaces.

The desk's design ensures plenty of legroom for comfortable seating. The headphone hook can help keep your workspace tidy by holding headphones, bags, or other items off the floor.



Image: The Coleshome desk positioned by a window, showcasing its suitability for various room settings and providing a comfortable work environment.



Image: The desk integrated into a bedroom, highlighting its compact size and versatility for different living spaces.

MAINTENANCE

To keep your Coleshome Computer Desk in optimal condition, follow these simple maintenance tips:

- **Cleaning:** The melamine veneer tabletop is waterproof, heat-resistant, and dust-free. Simply wipe the surface with a damp cloth to clean. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Wipe up spills immediately to prevent any potential damage to the surface.
- **Heat Protection:** While heat-resistant, it is recommended to use coasters or heat pads for hot items to prolong the life of the finish.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.




Image: A close-up of the desk's surface, illustrating its elegant texture and ease of cleaning with a simple wipe.

TROUBLESHOOTING

If you encounter any issues with your Coleshome Computer Desk, refer to the following common solutions:

- **Desk Wobbles:**

- Ensure all screws connecting the desktop to the leg frames and the cross braces are securely tightened.
- Adjust the individual feet pads at the bottom of each leg. Turn them clockwise or counter-clockwise until the desk is stable on your flooring.

- **Parts Missing/Damaged:**

- Double-check the packaging and all contents.
- Contact Coleshome customer support with your product model and details of the missing/damaged part for assistance.

- **Difficulty Assembling:**

- Review the setup instructions carefully, paying attention to the orientation of parts.


- Ensure you are using the correct screws for each connection.
- If possible, have a second person assist with assembly.

SPECIFICATIONS

Feature	Detail
Brand	Coleshome
Model Number	B01011611USAN0222A4GL8P9
Product Dimensions (L x W x H)	48"D x 20"W x 29"H
Item Weight	22 Pounds
Maximum Weight Recommendation	100 Pounds
Top Material Type	Engineered Wood with Melamine Veneer
Base Material	Alloy Steel (Legs)
Color	Vintage (as per current product)
Style	Modern, Simple
Assembly Required	Yes (All tools included)
Recommended Number of People for Assembly	1
Product Care Instructions	Wipe with Damp Cloth



Image: The desk's solid desktop, showcasing its elegant texture and durable finish.



Solid Desktop
with
elegant texture

Image: Detail of the anti-collision corner, designed for safety and durability.

WARRANTY AND SUPPORT

Coleshome is committed to customer satisfaction. While specific warranty details are typically provided with your purchase, please retain your proof of purchase for any warranty claims.

For any questions, concerns, or support needs regarding your Coleshome Computer Desk, please contact Coleshome customer service directly. You can often find contact information on the product packaging or through the retailer where you purchased the item.

Your satisfaction is our goal. We are here to support you if you encounter any problems before or after purchase.

© 2024 Coleshome. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question