Coleshome B01011592USAN0222A47Y1A6

Coleshome 40-Inch Modern Computer Desk

INSTRUCTION MANUAL

Brand: Coleshome | **Model:** B01011592USAN0222A47Y1A6

1. Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your new Coleshome 40-Inch Modern Computer Desk. This desk is designed for versatile use in home offices, study areas, or as a writing surface, offering a blend of functionality and contemporary style. Please read all instructions carefully before assembly and use to ensure proper setup and longevity of your product.

Key Features:

- **Durable Construction:** Thick metal frames made of heavy-duty powder-coated steel for enhanced stability and safety.
- **Easy Maintenance:** Melamine veneer tabletop is waterproof, heat-resistant, and dust-free.
- **Space-Saving Design:** Compact dimensions suitable for smaller spaces while providing ample working room.
- **Integrated Accessories:** Includes a headphone hook for convenient storage.

2. Safety Information

WARNING: Do not place items heavier than 100 pounds (45 kg) on the desk to prevent structural damage or injury.

- Ensure all screws and fasteners are securely tightened before use.
- Place the desk on a level and stable surface to prevent wobbling or tipping.
- Keep small parts and assembly tools out of reach of children.
- Avoid exposing the desk to extreme temperatures or direct sunlight for prolonged periods.

3. Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact Coleshome customer service.

Item	Quantity
Desktop Panel	1
Metal Leg Frames	2
Support Bars (Crossbars)	2
Adjustable Feet Pads	4
Headphone Hook	1
Assembly Hardware (Screws, Allen Wrench)	1 Set
Instruction Manual	1

4. Setup and Assembly

Assembly is designed to be straightforward and can typically be completed within 30 minutes. All necessary tools are included.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Attach Leg Frames:** Align the metal leg frames with the pre-drilled holes on the underside of the desktop panel. Secure them using the provided screws and Allen wrench. Ensure the frames are oriented correctly as shown in the diagrams.
3. **Install Support Bars:** Attach the two support bars (crossbars) between the leg frames. These provide additional stability. Tighten all screws firmly.
4. **Attach Adjustable Feet Pads:** Screw the adjustable feet pads into the bottom of each leg. These help level the desk on uneven surfaces and protect your floor.
5. **Install Headphone Hook:** Attach the headphone hook to your preferred side of the desk using the designated screw hole.
6. **Final Check:** Once assembled, gently lift and place the desk in its desired location. Press down on the desktop to ensure all connections are secure and the desk is stable. Adjust the feet pads if necessary to eliminate any wobbling.



Image: Detail of the sturdy metal frame, highlighting its robust construction for stability.



Image: Adjustable feet pads ensure stability on uneven floors and protect surfaces.

5. Operating Instructions

The Coleshome Computer Desk is designed for straightforward use. Once assembled and placed, it is ready for your daily activities.

- **Placement:** Position the desk in your desired location, ensuring adequate space for movement and access to power outlets if using electronic devices.
- **Leveling:** Use the adjustable feet pads to fine-tune the desk's height and ensure it sits level, preventing any rocking or instability.
- **Headphone Storage:** Utilize the integrated headphone hook to keep your headphones conveniently stored and off the desktop surface.
- **Weight Distribution:** Distribute weight evenly across the desktop. Avoid concentrating heavy items in one area to maintain stability and prevent damage.



Image: The Coleshome 40-Inch Computer Desk set up for a home office, showcasing its functional design.




Image: Product dimensions (40"L x 19"W x 29"H) for optimal space planning.

6. Maintenance

Proper care will extend the life and appearance of your Coleshome desk.

- **Cleaning the Desktop:** The melamine veneer tabletop is waterproof and dust-free. Wipe regularly with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cleaning the Frame:** The powder-coated steel frame can be wiped clean with a damp cloth. Dry immediately to prevent rust.
- **Periodic Checks:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Scratches:** While the tabletop is scratch-resistant, using coasters for drinks and protective pads under heavy or sharp objects is recommended to preserve the surface.



Image: The solid desktop features an elegant texture and is easy to clean.



Image: The anti-collision corner design helps protect the desk from everyday bumps.

7. Troubleshooting

If you encounter any issues with your desk, please refer to the following common solutions:

- **Wobbling Desk:** Ensure the desk is placed on a flat surface. Adjust the individual feet pads by twisting them until the desk is stable and level. Check that all assembly screws are securely tightened.
- **Loose Parts:** If any part feels loose, re-tighten the corresponding screws using the provided Allen wrench. Avoid over-tightening.
- **Scratches/Damage:** For minor scratches on the tabletop, furniture repair markers or touch-up pens matching the Deep Brown color may be used. For significant damage, contact customer service.
- **Difficulty Assembling:** Review the assembly instructions carefully. Ensure all parts are correctly oriented before tightening screws. Do not force parts together.

8. Specifications

Feature	Detail
Brand	Coleshome
Model Number	B01011592USAN0222A47Y1A6

Feature	Detail
Product Dimensions (D x W x H)	40"D x 19"W x 29"H
Item Weight	17 Pounds (7.7 kg)
Color	Deep Brown
Style	Modern
Top Material Type	Engineered Wood (Melamine Veneer)
Base Material	Heavy-duty Powder Coated Steel
Maximum Weight Recommendation	100 Pounds (45 kg)
Included Components	Headphone Hook
Assembly Required	Yes

9. Warranty and Support

Coleshome is committed to providing high-quality products. For any questions, concerns, or warranty inquiries regarding your desk, please contact Coleshome customer service through the retailer where the product was purchased or visit the official Coleshome website for support information.
Please retain your purchase receipt as proof of purchase for any warranty claims.

© 2023 Coleshome. All rights reserved.