

**Karlsso** PTG-KA5915BK

# Karlsso Belle Numbers Alarm Clock User Manual

Model: PTG-KA5915BK

## 1. INTRODUCTION

---

Thank you for choosing the Karlsso Belle Numbers Alarm Clock. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read this manual thoroughly before use to ensure proper function and longevity of your device.

The Karlsso Belle Numbers Alarm Clock is a stylish and functional timepiece designed for indoor use, particularly suitable for bedrooms. It features an analog display and a reliable alarm function.



Figure 1.1: The Karlsson Belle Numbers Alarm Clock in a typical setting.

## 2. SETUP

---

### 2.1 Battery Installation

1. Locate the battery compartment cover on the back of the alarm clock.
2. Gently slide or remove the cover.
3. Insert one (1) AA battery, ensuring the positive (+) and negative (-) terminals align with the indicators inside the compartment.
4. Replace the battery compartment cover securely.



Figure 2.1: Rear view of the alarm clock, highlighting the battery compartment and setting knobs.

## 2.2 Setting the Current Time

After installing the battery, the clock will begin to run. To set the correct time:

1. Locate the time setting knob on the back of the clock (usually the larger knob).
2. Rotate the knob clockwise or counter-clockwise until the hour and minute hands display the accurate current time.

## 3. OPERATING INSTRUCTIONS

---

### 3.1 Setting the Alarm

The alarm function allows you to set a specific time for the alarm to sound.

1. Locate the alarm setting knob on the back of the clock (usually smaller than the time setting knob).
2. Rotate this knob to move the alarm hand (often a distinct color or shape) to your desired alarm time.
3. Locate the alarm ON/OFF switch, typically a small switch on the back or side of the clock.
4. Slide the switch to the "ON" position to activate the alarm. Slide it to "OFF" to deactivate.



Figure 3.1: Detailed view of the clock face, showing the hour, minute, and alarm hands.

### **3.2 Snooze Function (If applicable)**

This model does not feature a dedicated snooze function. To stop the alarm, slide the alarm ON/OFF switch to the "OFF" position.

## **4. MAINTENANCE**

---

### **4.1 Cleaning**

To clean the alarm clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or internal components.

### **4.2 Battery Replacement**

When the clock begins to lose time or the alarm function weakens, it is an indication that the battery needs to be replaced. Follow the steps in Section 2.1 for battery installation. Always use a fresh AA battery for optimal performance.

## **5. TROUBLESHOOTING**

---

- **Clock not running or running slowly:**

Check if the battery is inserted correctly with the correct polarity. Replace the battery with a new AA battery if necessary.
- **Alarm not sounding:**

Ensure the alarm ON/OFF switch is in the "ON" position. Verify that the alarm hand is set to the desired time. Check the battery as a weak battery can affect alarm volume.
- **Alarm sounds at the wrong time:**

Re-adjust the alarm setting knob to align the alarm hand precisely with your desired alarm time.

## 6. SPECIFICATIONS





Brand	Karlsson
Model Number	PTG-KA5915BK
Color	Black
Material	Iron
Dimensions (L x W x H)	6 x 3.81 x 12 cm
Weight	200 grams
Power Source	1 AA Battery (not included)
Special Feature	Alarm
Display Type	Analog
Intended Use	Indoor (Bedroom)

## 7. WARRANTY AND SUPPORT

Warranty information for your Karlsson Belle Numbers Alarm Clock is typically provided at the point of purchase or within the product packaging. Please retain your proof of purchase for any warranty claims.

For technical support, troubleshooting assistance beyond this manual, or warranty inquiries, please contact the retailer from whom you purchased the product or refer to the official Karlsson website for customer service contact details.

*Note: Availability of spare parts information is not provided.*

	<p><a href="#">Karlsson KA6039 Alarm Clock: User Manual and Features</a></p> <p>Comprehensive guide to the Karlsson KA6039 alarm clock, covering product specifications, features like display modes, alarms, brightness settings, sound control, and usage instructions. Includes setup, maintenance, and troubleshooting tips.</p>
	<p><a href="#">Karlsson KA6061 LED Cuckoo Alarm Clock Instruction Manual</a></p> <p>Comprehensive guide for the Karlsson KA6061 LED Cuckoo Alarm Clock, covering setup, functions, alarm settings, and troubleshooting.</p>
	<p><a href="#">Karlsson Alarm Clock User Manual and Instructions</a></p> <p>User guide for Karlsson alarm clocks, providing step-by-step instructions for setting the time and alarm functions, including details on the ON/OFF switch and alarm behavior.</p>
	<p><a href="#">Karlsson KA6061 LED Cuckoo Alarm Clock Instruction Manual</a></p> <p>Comprehensive instructions for setting up and operating the Karlsson KA6061 LED Cuckoo Alarm Clock, including functions, time and calendar settings, alarm, snooze, temperature display, and warnings.</p>