Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Philips /
- > Philips Shaver Series 7000 Wet & Dry Electric Shaver S7886/55 Instruction Manual

Philips S7886/55

Philips Shaver Series 7000 Wet & Dry Electric Shaver Instruction Manual

Model S7886/55

1. Introduction

This manual provides essential instructions for the safe and effective use of your Philips Shaver Series 7000 Wet & Dry Electric Shaver, Model S7886/55. This shaver is designed for both wet and dry shaving, offering advanced skin protection and a close shave.

Key features include:

- Nano SkinGlide Coating: A protective layer between the shaving heads and skin to reduce friction.
- SteelPrecision Blades: Self-sharpening blades designed for efficient cutting.
- Motion Control Sensor: Provides guidance for an optimized shaving technique.
- Power Adapt Sensor: Automatically adjusts cutting power based on hair density.
- Wet & Dry Functionality: Suitable for comfortable dry shaves or refreshing wet shaves with gel or foam.
- Pop-up Precision Trimmer: Integrated for detailing moustaches and sideburns.



Image 1.1: Philips Shaver Series 7000 electric shaver. This image shows the main shaver unit with its three rotary heads and control panel.

2. Safety Information

Read all instructions carefully before using the appliance and save them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This appliance is waterproof and suitable for use in the bath or shower. For safety reasons, the appliance can only be used cordlessly.
- Do not use the appliance if it is damaged.
- Keep the appliance and its accessories away from children.
- Only use the original charging stand and Quick Clean Pod supplied with the appliance.
- Do not immerse the charging stand or Quick Clean Pod in water.
- Ensure your hands are dry when handling the charging stand.
- Do not use abrasive cleaning agents or scourers on the appliance.

3. What's in the Box

Carefully unpack the box and check that all items are present and in good condition. The package includes:

- Philips Shaver Series 7000 (S7886/55) Electric Shaver
- · Charging stand
- Quick Clean Pod (with 1 cartridge included)
- · Travel case



Image 3.1: Contents of the Philips Shaver Series 7000 package. This image displays the shaver, charging stand, Quick Clean Pod, and travel case alongside the product packaging.

4. Setup

4.1 Initial Charging

- 1. Connect the charging stand to a power outlet using a compatible USB adapter (not included).
- 2. Place the shaver into the charging stand. The battery indicator on the shaver will illuminate to show charging

status.

3. Charge the shaver for approximately 1 hour for a full charge, providing up to 60 minutes of shaving time. A 5-minute quick charge provides enough power for one shave.




Image 4.1: Philips Shaver Series 7000 connected to a USB charging cable. This image illustrates the shaver being charged, highlighting the USB connection point.

4.2 Quick Clean Pod Setup

- 1. Open the Quick Clean Pod by lifting the top cover.
- 2. Remove the protective foil from the Quick Clean cartridge and insert it into the pod.
- 3. Close the top cover securely.
- 4. After shaving, place the shaver head-down into the Quick Clean Pod for automatic cleaning and lubrication.

5. Operating Instructions

5.1 Powering On/Off

Press the power button once to turn the shaver on. Press it again to turn the shaver off.

5.2 Shaving Techniques

For optimal results, ensure your skin is clean before shaving.

- Dry Shave: Move the shaver in small, circular motions over your skin.
- Wet Shave: Apply shaving gel or foam to your skin. Move the shaver in small, circular motions. Rinse the shaver heads under warm water during shaving to prevent clogging.

The shaver's flexible heads adapt to your facial contours, and the Nano SkinGlide coating helps reduce friction for a comfortable shave.




Image 5.1: A man using the Philips Shaver Series 7000 for shaving. This image demonstrates the shaver in use on a person's face.



Image 5.2: Close-up of the Philips Shaver Series 7000 with an arrow indicating the motion control sensor. This image highlights the shaver's sensor technology designed to guide shaving technique.

5.3 Using the Pop-up Precision Trimmer

To activate the precision trimmer, slide the trimmer release button upwards. Use the trimmer for shaping sideburns or moustaches. After use, slide the button downwards to retract the trimmer.

5.4 Philips GroomTribe App Integration

For personalized shaving guidance and skin progress tracking, download the Philips GroomTribe app. Pair your shaver with the app via Bluetooth to access features like motion sensing technology feedback and personalized shave routines.

6. Maintenance

6.1 Daily Cleaning

- 1. After each shave, turn off the shaver.
- 2. Press the release button to open the shaving head unit.

- 3. Rinse the shaving heads thoroughly under warm running water.
- 4. Shake off excess water and allow the shaver to air dry.

6.2 Quick Clean Pod Cleaning

For a more thorough cleaning and lubrication, place the shaver in the Quick Clean Pod after rinsing. The pod will automatically clean and lubricate the shaver heads. Replace the Quick Clean cartridge when indicated by the pod or approximately every three months, depending on usage.

6.3 Replacing Shaving Heads

For optimal performance, replace the shaving heads every two years. Replacement heads are available from authorized Philips retailers. Refer to the shaver's model number (\$7886/55) when purchasing replacement parts.



Image 6.1: Detailed view of the Philips Shaver's SteelPrecision blades. This image shows the intricate design of the cutting elements within the shaver head.



Image 6.2: Close-up illustrating the Nano SkinGlide coating on the Philips Shaver. This image highlights the smooth surface designed to reduce friction during shaving.

7. Troubleshooting

If you encounter issues with your Philips Shaver Series 7000, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver using the charging stand.
Poor shaving performance.	Shaving heads are dirty or worn.	Clean the shaving heads thoroughly or replace them if they are older than two years.
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure you are using small, circular motions. Consider using the GroomTribe app for technique guidance. Try wet shaving with gel or foam.

Problem	Possible Cause	Solution
Quick Clean Pod not functioning.	Cartridge empty or incorrectly inserted.	Replace the Quick Clean cartridge or ensure it is correctly seated.

If the problem persists, please contact Philips customer support.

8. Specifications

• Model: S7886/55

• Power Source: Battery Powered

• Battery Type: Lithium-ion

• Battery Life: Up to 60 minutes shaving time (approx. 3 days of use based on typical shaving duration)

• Charging Time: 1 hour for full charge, 5-minute quick charge for one shave

• Blade Material: Stainless Steel

• Special Features: Wet & Dry use, SkinIQ Technology, Pop-up Trimmer, Quick Clean Pod compatible

• Weight: 990 g (product package weight)

• Manufacturer: Philips Consumer Lifestyle B.V.

9. Warranty and Support

Philips products are designed and manufactured to the highest quality standards. This product is covered by a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Philips website.

For further assistance, product registration, or to purchase accessories and replacement parts, please visit the Philips support website or contact your local Philips customer service center. Always provide your model number (\$7886/55) when seeking support.

You can find more information and support at the Philips Store on Amazon.

© 2024 Philips. All rights reserved.

Related Documents - S7886/55



Philips Shaver Series 7000 S7887/63: Advanced Skin Protection with SkinIQ Technology

Discover the Philips Shaver Series 7000 (S7887/63) for a close, comfortable shave. Featuring SkinIQ technology, Steel Precision blades, and 360-D flexible heads for advanced skin protection and personalized grooming.



Philips i9000 Prestige Ultra Shaver with SkinIQ Pro Technology

Detailed overview of the Philips i9000 Prestige Ultra electric shaver, highlighting its SkinIQ Pro technology, Triple Lift & Cut blades, 360° contouring head, and personalized shaving modes for ultimate comfort and performance.



Philips Shaver 3000 Series S3244/12: Comfortable Close Shaving

Explore the Philips Shaver 3000 Series S3244/12, designed for a close and comfortable shave, even on sensitive skin. Featuring SkinProtect technology, 5D Pivot & Flex heads, PowerCut blades, wet/dry functionality, and a 60-minute runtime.



Philips Shaver Series 5000 S5887/50: Advanced Wet & Dry Shaving with SkinIQ Technology

Discover the Philips Shaver Series 5000 S5887/50, featuring SkinIQ technology for an efficient and skin-friendly shave. Enjoy wet & dry use, 60-minute battery life, and convenient USB-A charging.



Philips Shaver Series 5000 S5887/10: Powerful Shaving with SkinIQ Technology

Discover the Philips Shaver Series 5000 (S5887/10) for a powerful, skin-gentle shave. Featuring Steel Precision blades, SkinIQ technology, 360-D flexing heads, and 60 minutes of cordless use for a superior grooming experience.



Philips Shaver Series 9000 Prestige SP9883/35: Advanced Wet & Dry Electric Shaver with SkinIQ Technology

Discover the Philips Shaver Series 9000 Prestige SP9883/35, an advanced wet and dry electric shaver featuring SkinIQ technology for a personalized, close, and gentle shave. Explore its features, specifications, and benefits for ultimate grooming.