

## GUESS GW0494G5

# GUESS Gents Blue Silicone Strap Watch (Model: GW0494G5) User Manual

Comprehensive instructions for your GUESS timepiece.

## INTRODUCTION

This manual provides detailed instructions for the proper use, care, and maintenance of your GUESS Gents Blue Silicone Strap Watch, Model GW0494G5. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.





Image: Front view of the GUESS Gents Blue Silicone Strap Watch GW0494G5, featuring a blue dial, rose gold-tone case, and blue silicone strap.

## SETUP

---

### 1. Setting the Time

- 1. Pull out the crown:** Gently pull the crown (the small knob on the side of the watch case) out to the first position.
- 2. Adjust the time:** Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
- 3. Push in the crown:** Once the time is set, push the crown back into its normal operating position. This will start the watch movement.



Image: Side view of the watch, highlighting the crown used for setting the time.

## 2. Adjusting the Silicone Strap

The silicone strap is designed for comfort and adjustability. To adjust the fit:

1. Locate the buckle and the series of holes on the strap.
2. Thread the end of the strap through the buckle.

3. Select the hole that provides a comfortable yet secure fit on your wrist.

4. Secure the pin of the buckle into the chosen hole.





Image: Detail of the blue silicone strap and rose gold-tone buckle, illustrating the adjustment mechanism.

## OPERATING YOUR WATCH

---

### Reading the Time

Your GUESS watch features a classic analog display with hour, minute, and second hands. The dial includes bold Arabic numerals and minute markers for clear readability. The outer ring features a tachymeter design for aesthetic appeal.



Image: Angled view of the watch face, highlighting the blue dial, Arabic numerals, and hands.

## Water Resistance

This watch is water resistant to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. Avoid operating the crown while the watch is wet or submerged to prevent water ingress.

- **50 Meters (5 ATM):** Suitable for showering, bathing, and shallow swimming.
- **Avoid:** Hot water, steam, high-pressure water jets, diving, or prolonged submersion.

## MAINTENANCE AND CARE

---

### Cleaning Your Watch

To maintain the appearance of your watch:

- Wipe the case and silicone strap with a soft, damp cloth.
- For stubborn dirt on the silicone strap, a mild soap solution can be used, followed by rinsing with clean water and thorough drying.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and strap material.

### Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. The original watch box is ideal for storage.

### Battery Replacement

Your watch is powered by a quartz movement and requires a product-specific battery. When the battery needs replacement, it is highly recommended to take your watch to an authorized GUESS service center or a reputable watchmaker. Attempting to replace the battery yourself may void the warranty and compromise the watch's water resistance.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Watch not running	Battery depleted or crown not pushed in.	Ensure crown is fully pushed in. If not, battery may need replacement by a professional.
Time is inaccurate	Watch exposed to strong magnetic fields or low battery.	Keep watch away from magnets. If problem persists, battery may be low or watch requires servicing.
Condensation under crystal	Temperature change or water ingress.	If condensation persists, water resistance may be compromised. Seek professional inspection immediately.

## SPECIFICATIONS

---

- **Model Number:** GW0494G5
- **Case Diameter:** 42mm
- **Case Material:** Rose Gold Tone Stainless Steel

- **Dial:** Sunray Blue Dial with Arabic Numerals
- **Strap Material:** Blue Smooth Silicone
- **Movement:** Quartz Analog 3 hands
- **Water Resistance:** 50 meters (5 ATM)
- **Battery:** 1 Product Specific battery (included)
- **Product Dimensions:** 12 x 4.2 x 0.92 cm
- **Weight:** 140 g

## WARRANTY AND SUPPORT

---

Your GUESS watch is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For warranty claims, service, or technical support, please contact an authorized GUESS service center or visit the official GUESS Watches website for contact information. Always retain your proof of purchase for warranty validation.

**GUESS Watches Official Website:** [www.guesswatches.com](http://www.guesswatches.com)

© 2023 GUESS Watches. All rights reserved. Model: GW0494G5.