

[Manuals.plus](#) /

› [PlayBetter](#) /

› Bushnell iON Elite Golf GPS Watch User Manual

PlayBetter 362151 (Watch), Z05 (Charger)

Bushnell iON Elite Golf GPS Watch User Manual

Model: 362151 (Watch)

INTRODUCTION

Welcome to the user manual for your Bushnell iON Elite Golf GPS Watch. This guide provides comprehensive instructions to help you set up, operate, and maintain your device, ensuring you get the most out of its advanced golf features. The iON Elite is designed to enhance your game with precise distances, course layouts, and performance tracking capabilities.

WHAT'S IN THE BOX

Your Bushnell iON Elite Golf GPS Watch package includes the following items:

- Bushnell iON Elite Slope GPS Watch
- PlayBetter HD Tempered Glass Screen Protectors
- Portable 5000mAh Charger
- USB Charging/Sync Cable



Image: Bushnell iON Elite Golf GPS Watch shown with its screen protectors, portable charger, and USB cable.

SETUP

Charging the Device

Before initial use, fully charge your iON Elite watch. Connect the USB Charging/Sync Cable to the watch's charging port and a compatible USB power source (e.g., computer USB port, wall adapter, or the included portable charger). The battery indicator on the watch display will show charging progress.



Image: The included PlayBetter portable 5000mAh charger, used for convenient charging on the go.

Powering On/Off

To power on the watch, press and hold the power button located on the side of the device until the Bushnell Golf logo appears. To power off, press and hold the power button until the power off option appears on the screen, then confirm.

Initial Sync and Course Updates

For optimal performance, it is recommended to sync your iON Elite with the Bushnell Golf Mobile App. This ensures your watch has the latest course data and firmware updates. Download the Bushnell Golf app from your device's app store (App Store for iOS, Google Play for Android).

DYNAMIC GREEN MAPPING

The front and back distances are shown based on the golfer's line of play.



Image: Screenshots of the Bushnell Golf Mobile App interface on a smartphone, showing various features and data.

OPERATING INSTRUCTIONS

Basic Navigation

The iON Elite features a color touchscreen for intuitive navigation. Swipe left or right to access different menus and features. Tap on icons or options to select them. Use the physical buttons on the side for quick access to specific functions or to return to the previous screen.



Image: Close-up of the Bushnell iON Elite watch face displaying the current time and battery status.

Golf Mode

From the main menu, select 'Golf' to begin a round. The watch will automatically recognize the course you are on from its database of over 38,000 preloaded courses. Auto Hole Advance ensures the watch automatically transitions to the next hole as you move across the course, maintaining the pace of your game.



Image: The watch display showing the 'Golf' option selected, ready to start a round.

Distance Features

The iON Elite provides accurate front, center, and back distances to the green based on your line of play. It also features Bushnell's patented Slope Compensated Distances, which adjusts yardages based on elevation changes for more precise shot planning.



Image: The watch display showing large, easy-to-read front, center, and back distances to the green.

GreenView & Pin Placement

Utilize the GreenView feature to see the shape of the green. You can also adjust the pin position on the screen for heightened accuracy, tailoring your strategies based on the day's exact pin locations.



Image: The watch display showing the GreenView feature, allowing users to adjust the pin location on the green.

Hole Maps & Shot Planning

The HoleView screen allows you to view the layout of the entire hole. With Shot Planning, you can get precise distances to any point on the hole, helping you optimize approach shots and ensuring you get closer to the pin each time.



Image: The watch display showing a detailed hole map for strategic shot planning.

Shot Tracking & Scorekeeping

The iON Elite features a shot distance calculator to measure your shots. It also includes built-in scorekeeping and a round odometer, allowing you to track your rounds, analyze your performance, and spot patterns to refine your strategies. This transforms your raw data into actionable decisions, game after game.



Image: The watch display showing the scorekeeping interface, allowing users to input strokes and putts.

BUSHNELL GOLF MOBILE APP INTEGRATION

The Bushnell Golf app provides additional product benefits, information, and data to further improve your game. It also allows you to easily update your GPS device. The app is available for download on both the App Store and Google Play.

DYNAMIC GREEN MAPPING

The front and back distances are shown based on the golfer's line of play.



Image: Screenshots of the Bushnell Golf Mobile App interface on a smartphone, highlighting its features.

SPECIFICATIONS

Feature	Detail
Item Weight	15.8 ounces
Product Dimensions	0.59 x 1.81 x 2.09 inches
Item Model Number	362151 (Watch), Z05 (Charger)
Batteries	1 Lithium Ion batteries required (included)
Display Size	1.28 Inches
Battery Life	12 Hours
Special Feature	Touchscreen
Connectivity Technology	Bluetooth
Map Type	Worldwide (38,000+ preloaded courses)
Mounting Type	Wrist Mount

MAINTENANCE

Charging

Ensure the watch is fully charged before each round to utilize its full 12-hour battery life. Use the provided USB Charging/Sync Cable for optimal charging performance.

Cleaning

Wipe the watch and screen with a soft, damp cloth after each use to remove dirt, sweat, and debris. Avoid using harsh chemicals or abrasive materials that could damage the screen or casing.

Storage

Store the watch in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the battery is partially charged (around 50%) to maintain battery health.

TROUBLESHOOTING

No GPS Signal

If your watch is not acquiring a GPS signal, ensure you are in an open area with a clear view of the sky. Allow a few minutes for the watch to locate satellites. If the issue persists, try restarting the device or performing a course update via the Bushnell Golf Mobile App.

Battery Draining Quickly

Check the brightness settings of your display; higher brightness consumes more battery. Ensure Bluetooth is turned off when not in use. If the battery life is significantly shorter than expected, ensure the watch is fully charged before use and consider contacting support if the problem continues.

Display Issues

If the touchscreen is unresponsive or the display is not functioning correctly, try restarting the watch. Ensure the screen is clean and free of moisture. If the problem persists, a factory reset might be necessary (refer to the Bushnell Golf App or online resources for instructions), or contact customer support.

Video: A quick demonstration of the Bushnell iON Elite (White) Golf GPS Watch's color screen and its responsiveness.

WARRANTY AND SUPPORT

For warranty information, product registration, and technical support, please visit the official Bushnell Golf website or refer to the documentation included with your purchase. You can also find helpful resources and FAQs within the Bushnell Golf Mobile App.

Manufacturer: Bushnell Golf (Watch), PlayBetter (Charger)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I change the time display on my Bushnell iON Elite Golf GPS Watch from a digital display back to a clock face?

To change the watch face on your Bushnell iON Elite Golf GPS Watch, follow these steps: Access Settings: From the main time display, swipe the touchscreen to navigate to the Settings menu. Select Watch Face: Look...

[Read full answer](#)