

Timex TW2V59800UK

Timex Men's Command Encounter 45mm Watch

Model: TW2V59800UK

INTRODUCTION

Thank you for choosing the Timex Men's Command Encounter 45mm Watch. This robust timepiece is designed for durability and functionality, featuring a digital negative display, a 45mm case, and water resistance up to 100 meters. This manual provides essential information to help you set up, operate, and maintain your watch, ensuring years of reliable performance.



Front view of the Timex Command Encounter watch, displaying the time, date, and various mode indicators.

Battery Installation

Your Timex Command Encounter watch comes with a pre-installed lithium metal battery (CR2025). The battery is typically activated at the factory. If the display is blank or dim upon arrival, the battery may need to be replaced. It is recommended to have battery replacement performed by a qualified watch technician to ensure water resistance is maintained.

Initial Time and Date Setting

To set the time and date:

1. Press and hold the **MODE** button until the time display begins to flash.
2. Use the **START/STOP** button to adjust the flashing digit (hours, minutes, seconds).
3. Press the **RESET** button to move to the next setting (e.g., from hours to minutes).
4. Continue adjusting and moving through the settings for year, month, and day.
5. Once all settings are correct, press the **MODE** button again to exit the setting mode.



Side view of the watch, highlighting the accessible control buttons.

OPERATING INSTRUCTIONS

Navigating Modes

Press the **MODE** button to cycle through the watch's functions:

- **Time Mode:** Displays current time, date, and day of the week.
- **Chronograph Mode:** For timing events. Press **START/STOP** to begin/pause, **RESET** to clear.
- **Timer Mode:** For countdowns. Set the desired time, then press **START/STOP**.
- **Alarm Mode:** Set daily alarms. Press **START/STOP** to toggle alarm on/off.

Using INDIGLO® Night-Light

Press the **INDIGLO** button (top left) to activate the night-light for easy viewing in low-light conditions. The INDIGLO® night-light illuminates the entire watch face.

MAINTENANCE

Cleaning Your Watch

To clean your watch, wipe it with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water. Ensure the watch is completely dry before storing.

Water Resistance

This watch is water resistant up to 100 meters (330 feet). This rating means it is suitable for showering, swimming, and snorkeling. It is **not** suitable for scuba diving. Do not operate buttons underwater, as this can compromise the water resistance seal.



Detailed view of the watch's stainless steel case back, indicating its shock and water resistance.

TRTROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--------------------------|----------------------|--|
| Display is blank or dim. | Low or dead battery. | Replace battery (CR2025). Seek professional assistance to maintain water resistance. |

| Problem | Possible Cause | Solution |
|---------------------------|---|--|
| Buttons are unresponsive. | Watch may be in a locked mode or internal issue. | Try pressing all buttons firmly. If issue persists, contact customer support. |
| Water inside the watch. | Seal compromised, possibly by operating buttons underwater or damage. | Immediately take the watch to a qualified service center. Do not attempt to dry it yourself. |

SPECIFICATIONS

- **Model Number:** TW2V59800UK
- **Case Diameter:** 45mm
- **Strap Length:** 8 inches (black)
- **Display Type:** Digital Negative Display
- **Lens Material:** Mineral Glass
- **Water Resistance:** 100 meters (330 feet)
- **Battery Type:** 1 Lithium Metal battery (CR2025)
- **Manufacturer:** Timex
- **Approximate Weight:** 8.11 ounces


SCRATCH-RESISTANT
MINERAL GLASS


LEGENDARY
TIMEXDURABILITY



TIMEX

WATCHMAKERS EST. 1854

Timex's commitment to quality and durability, featuring scratch-resistant mineral glass and legendary Timex durability.

WARRANTY AND SUPPORT

Timex watches are manufactured to high standards and are backed by a limited warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Timex website. For technical support, service, or parts, please contact Timex customer service directly. Keep your proof of purchase for warranty claims. You can find more information and support on the official Timex website: www.timex.com

