

VEVOR Hose Reel 130 ft x 1/2 inch

VEVOR Retractable Hose Reel 130 ft x 1/2 inch User Manual

Model: Hose Reel 130 ft x 1/2 inch

1. SAFETY INFORMATION

Please read and understand all safety instructions before operating this product. Failure to follow these instructions may result in product damage or personal injury.

- Always ensure the hose reel is securely mounted before use.
- Do not allow children to operate the hose reel unsupervised.
- When retracting the hose, always guide it manually to prevent whipping or tangling, which can cause injury or damage.
- Do not release the hose suddenly during retraction. Maintain a firm grip and guide it back slowly.
- Drain all water from the hose reel and store it in a freeze-proof location during winter months to prevent damage.
- Do not exceed the maximum working pressure of 200 PSI.

2. PRODUCT OVERVIEW

The VEVOR Retractable Hose Reel is designed for convenient and efficient garden watering. It features an automatic rewind system, a durable hose, and a versatile spray nozzle.

Key Features:

- **Automatic Rewind:** Ensures secure and slow retraction of the hose with a gentle pull, preventing tangles and damage.
- **180° Swivel Bracket:** Allows multi-directional watering and reduces hose wear.
- **Lock at Any Length:** The hose can be locked at any desired length for customized use.
- **Durable Construction:** Features an all-weather PP housing, 3-layer PVC hose, and brass fittings for long-term outdoor use.
- **9-Pattern Nozzle:** Includes jet, soaker, angle, flat, cone, shower, center, rinse, and mist patterns for various watering needs.

- **Built-in Carry Handle:** For easy removal and storage.

Make Yard Watering Easier

Retractable Design



Standard Hose



Image: The retractable design offers neat storage and lockable length compared to standard hoses.

Designed for Safer Family Use

8-12 s / 129.6 ft Slow Retraction



Image: The slow retraction system ensures safe and controlled hose rewind.

Easy Reach Where You Need

130 ft
Hose Length

1/2"
Hose Diameter

13185 sq ft
Coverage Area




Image: The 180° swivel bracket allows extensive coverage and flexible watering.

9 Pattern Spray Nozzle

Meets Various Watering Needs



Easy On/Off Control



Extra Standard Nozzle



Rinse



Cone



Soaker



Flat



Mist



Center



Angle



Vertical



Shower

Image: The included 9-pattern spray nozzle offers versatility for different watering needs.

3. PACKAGE CONTENTS

Verify that all components are present before installation.

- 1 x Hose Reel (with 130 ft x 1/2 inch hose pre-installed)
- 1 x 9-Pattern Spray Nozzle
- 1 x General Nozzle
- 2 x Leak-proof Washers

- 4 x Screws (for mounting)
- 4 x Expansion Anchors (for mounting)



Image: Overview of product dimensions and included accessories.

4. SPECIFICATIONS

Brand	VEVOR
Model Number	Hose Reel 130 ft x 1/2 inch
Hose Length	130 ft (39.5 m)
Hose Diameter	1/2 inch (11 mm)
Lead-in Hose Length	6.6 ft (2 m)
Lead-in Connector Diameter	3/4 inch (19 mm)
Hose Working Pressure	200 PSI
Hose Burst Pressure	600 PSI
Adjustable Bracket Angle	180°
Product Dimensions (L x W x H)	19.9 x 10 x 17.7 inches (50.5 x 25.5 x 45 cm)
Product Weight	29.76 lbs (13.5 kg)
Main Materials	3-Layer PVC Hose, PP Housing, PP & ABS Nozzle



Item Model Number: **XW40-1/2**

Hose Length: **130 ft / 39.5 m**

Hose Diameter: **1/2 in / 11 mm**

Lead-in Hose Length: **6.6 ft / 2 m**

Spray Coverage Area: **13185.8 sq ft / 1225 m²**

Adjustable Bracket Angle: **180°**

Lead-in Connector Diameter: **3/4 in / 19 mm**

Product Weight: **29.76 lbs / 13.5 kg**

Main Materials:

3-Layer PVC Hose + PP Housing + PP & ABS Nozzle

Product Dimensions:

19.88 × 10.04 × 17.72 in / 50.5 × 25.5 × 45 cm

Image: Detailed measurements of the hose reel unit.

5. SETUP AND INSTALLATION

Follow these steps to properly install your VEVOR Retractable Hose Reel.

1. **Choose Mounting Location:** Select a sturdy wall (brick, concrete, wood post) near your water source. Ensure the location allows for the 180° swivel and easy access.
2. **Mark Mounting Position:** Hold the mounting bracket against the wall at the desired height and mark the four drilling points.

3. **Drill Holes:** Use an appropriate drill bit for your wall material to drill holes at the marked positions.
4. **Insert Wall Anchors:** For brick or concrete walls, insert the provided expansion anchors into the drilled holes.
5. **Secure Bracket:** Attach the mounting bracket to the wall using the provided screws, ensuring it is firmly secured.
6. **Attach Hose Reel:** Slide the hose reel onto the mounting pin of the secured bracket. Ensure it locks into place.
7. **Connect Lead-in Hose:** Connect the short lead-in hose from the reel to your outdoor faucet. Ensure all connections are tight to prevent leaks, using the provided leak-proof washers.

Quick Set-Up Guide



Mark Mounting Position on Wall



Drill Holes with Proper Bit



Insert Wall Anchors



Secure Bracket with Bolts



Attach Retractable Hose Reel to Bracket with Mounting Pin



Connect Lead-in Hose to Faucet

Note: Includes 6.6 ft leader hose; confirm faucet location before installation



Image: The hose reel securely mounted to a wall, showing the reinforced plastic mounting pin.

Your browser does not support the video tag.

Video: Official VEVOR video demonstrating the installation and features of the retractable hose reel.

6. OPERATING INSTRUCTIONS

Pulling Out the Hose:

- Gently pull the hose out to the desired length.
- To lock the hose, pull it slightly further until you hear a click, then slowly release it. The hose will remain extended.

Rewinding the Hose:

- To retract, pull the hose gently again until the locking mechanism disengages.
- Maintain a light grip on the hose and guide it slowly back into the reel. Do not let go of the hose suddenly, as it can retract quickly and cause injury or damage.

Using the Nozzle:

- Attach the desired nozzle (9-pattern or general) to the end of the hose.
- Turn on the water supply.
- For the 9-pattern nozzle, rotate the head to select the desired spray pattern. Use the trigger or lever for water flow control.

Smooth Pull-Out, No Snagging

Built-In Anti-Tangle
Guide Roller

Adjustable
Stopper




Image: The built-in anti-tangle guide roller ensures smooth hose extension without snagging.

Locks at Any Length

Built-In Any-Position Lock



Image: The hose can be locked at any desired length with a simple click.

Easy to Move Anywhere

Built-In Carry Handle



Image: The built-in carry handle allows for easy portability and storage.

7. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your hose reel.

- **Regular Cleaning:** Wipe down the hose reel housing with a damp cloth to remove dirt and debris.
- **Hose Inspection:** Periodically inspect the hose for any signs of wear, cracks, or leaks. Replace if necessary.
- **Fitting Checks:** Ensure all connections and fittings are tight and free from leaks. Replace washers if they show signs of wear.

- **Winter Storage:** Before the first frost, disconnect the hose reel from the water supply. Drain all water from the hose and the reel mechanism. Store the hose reel in a dry, freeze-proof location to prevent damage from freezing water. The built-in carry handle facilitates easy removal and storage.

Handles Harsh Cold and Sun

PP Housing + Metal Bracket

3-Layer PVC Hose
200 PSI Working Pressure

Protective Layer
Reinforced Layer
Flexible Layer

Brass Fitting with Sealing Washer
3/4"

6.6 ft Lead-in Hose

Image: The hose reel is constructed with durable materials to withstand various weather conditions.

Long-Lasting, Leak-Free Design

200 PSI

Hose Working Pressure

600 PSI

Hose Burst Pressure



Brass Fitting
with Leak-Reducing Washer



Image: The hose features a leak-free design with brass fittings and high working/burst pressure ratings.

8. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Hose does not retract fully.	Hose is tangled or obstructed. Spring mechanism is dirty or damaged.	Pull out the entire hose and carefully guide it back in. Ensure no kinks or obstructions. Clean any visible debris. If the issue persists, contact customer support.
Water leaks from connections.	Loose connections. Worn or missing washers.	Tighten all hose connections. Check and replace any worn or missing leak-proof washers.
Hose does not lock at desired length.	Locking mechanism is dirty or obstructed.	Pull the hose out completely and retract it slowly, listening for the click. Ensure the hose is clean and free of debris that might interfere with the locking mechanism.
Low water pressure from nozzle.	Faucet not fully open. Nozzle clogged. Hose kinked.	Ensure the water faucet is fully open. Check the nozzle for any blockages and clean if necessary. Inspect the hose for kinks.

9. WARRANTY AND SUPPORT

VEVOR products are designed for durability and performance. For specific warranty details, protection plans, or technical support, please refer to the documentation included with your purchase or visit the official VEVOR website. Keep your purchase receipt for warranty claims.

For further assistance, please contact VEVOR customer service.

