Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave Daybed with Pop up Trundle Bed

Bellemave Daybed with Pop-up Trundle Bed and USB Charging Stations

Model: Daybed with Pop up Trundle Bed

Introduction

Thank you for choosing the Bellemave Daybed with Pop-up Trundle Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new daybed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

Important Safety Instructions:

- Always follow the assembly instructions carefully.
- This product should be assembled by two adults to ensure safety and proper construction.
- Keep the area around the daybed clear of heavy items and ensure it is stable before use.
- Do not allow children to play on or around the daybed without supervision.
- The trundle bed should be fully extended and locked in place when in use.
- Do not exceed the weight capacity of 400 lbs per bed.
- Keep the daybed away from heat sources.
- Do not place heavy objects on the backrest or armrests.
- Always use a mattress with a thickness of 6 inches or less for both the daybed and the trundle.

Specifications

Feature	Detail
Bed Material	Pine Wood, MDF, Woven Fabric
Size	Twin

Overall Product Dimension	80.7"L x 78.7"W x 34"H (with trundle extended)
Upper/Down Bed Dimension	76"L x 39.2"W
Total Height	34"
Number of Slats (Daybed/Trundle)	10/10 pcs
Overall Product Weight	130 lbs
Each Bed Weight Capability	400 lbs
Recommended Mattress Thickness	6" (for both daybed and trundle)
Special Features	Pop-up Trundle, USB Charging Stations
Assembly Required	Yes

Product Dimensions Overview:




Image: A detailed diagram showing the various dimensions of the Bellemave Daybed, including the main bed frame, the pull-out trundle, and the overall length, width, and height. Key measurements like 80.7 inches length, 78.7 inches width (with trundle extended), and 34 inches height are clearly indicated.

Package Contents

Before assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Daybed Frame (Upholstered sections: backrest, armrests)
- Pop-up Trundle Bed Frame
- Wooden Slats for Daybed (10 pcs)

- Wooden Slats for Trundle (10 pcs)
- Hardware Pack (screws, bolts, washers, Allen wrench)
- USB Charging Module and Cable
- Assembly Instruction Manual

Setup and Assembly

Assembly is required and is best performed by two adults. Follow the step-by-step instructions provided in the included manual. Ensure all connections are secure before use.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Compare all parts with the provided parts list in your manual.
2. **Assemble Main Daybed Frame:** Attach the side panels to the backrest using the provided hardware. Ensure all bolts are tightened securely but do not overtighten.
3. **Install Daybed Slats:** Place the wooden slats onto the designated support rails of the main daybed frame. Secure them with the provided screws or connectors. Ensure even spacing.
4. **Assemble Trundle Bed Frame:** Construct the trundle frame according to the manual, attaching the wheels and support legs.
5. **Install Trundle Slats:** Place the wooden slats onto the trundle frame and secure them.
6. **Integrate Trundle:** Slide the assembled trundle bed under the main daybed frame.
7. **Connect USB Charging Station:** Locate the pre-drilled hole on the right armrest. Insert the USB charging module and connect the power cable as instructed in your manual. Ensure it is properly seated and functional.
8. **Final Check:** Verify that all bolts and screws are tight and that the daybed and trundle are stable.



Image: The fully assembled Bellemave Daybed in a room setting, with the pop-up trundle bed extended and raised to the same height as the main daybed, creating a larger sleeping surface. Pillows and bedding are shown on both beds.

Operating Instructions

Using the Daybed

The main daybed functions as a comfortable seating area or a twin-size bed. Place a twin-size mattress (maximum 6 inches thick) on the slats.

Operating the Pop-up Trundle Bed

The trundle bed provides an additional sleeping surface. It can be used in two configurations:

1. **Extended on Ground:** Pull the trundle bed out from under the daybed. It will roll on its casters and remain at a lower height, suitable for a separate sleeping area.
2. **Popped Up:** To raise the trundle to the same height as the main daybed, pull it out completely. Then, carefully lift

the trundle frame upwards until the spring mechanism locks it into the raised position. Ensure it is securely locked before use. To lower, release the locking mechanism and gently push down.



Image: The Bellemave Daybed with its trundle fully extended and popped up, showing how it aligns with the main daybed to create a larger sleeping area. The grey upholstered fabric and wooden slats are visible.

Using the USB Charging Stations

The right armrest of the daybed features integrated USB charging ports. Connect your device's USB cable to the port to charge. Ensure the daybed's power cable is plugged into a functional wall outlet.



Image: A close-up view of the right armrest of the Bellemave Daybed, clearly showing the integrated USB charging port. A smartphone is depicted connected to the port, illustrating its function.

Maintenance

- **Cleaning:** Wipe the wooden and upholstered surfaces with a dry cloth. For spills on fabric, blot immediately with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all bolts and screws to ensure they remain tight. Retighten as necessary to maintain stability.
- **Mattress Care:** Rotate and flip mattresses regularly to ensure even wear and prolong their lifespan.
- **USB Port:** Keep the USB ports free from dust and debris. Do not force cables into the ports.

Troubleshooting

- **Squeaking Noises:** Check all hardware connections and tighten any loose bolts or screws. Ensure slats are properly seated.
- **Trundle Not Sliding Smoothly:** Check the casters for any obstructions or debris. Ensure the track is clear. If the trundle is difficult to pop up or down, ensure no bedding or objects are interfering with the mechanism.
- **USB Ports Not Working:** Verify that the daybed's main power cable is securely plugged into a functional wall outlet. Check the connection of the USB module within the armrest. Try a different USB cable or device to rule out device-specific issues.
- **Instability:** Re-check all assembly steps and ensure all components are correctly installed and tightened. Ensure the daybed is on a flat, even surface.

Warranty and Support

Bellemave is committed to customer satisfaction. If you encounter any problems with your daybed, including missing parts, damaged components, or issues during assembly or use, please do not hesitate to contact us. We will endeavor to provide a satisfactory solution.
For support, please refer to the contact information provided with your purchase documentation or visit the Bellemave official store page on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BWN221MB

More documents and user manuals: **https://manuals.plus/**