

Manuals.plus /

› PTHTECHUS /

› PTHTECHUS Kids Smart Watch User Manual

PTHTECHUS Kids Smart Watch (1f9f36b4-c9ca-47b6-ae4b-f98b0507f43e)

PTHTECHUS Kids Smart Watch User Manual

Model: Kids Smart Watch (1f9f36b4-c9ca-47b6-ae4b-f98b0507f43e)

INTRODUCTION

The PTHTECHUS Kids Smart Watch is designed to provide a comprehensive communication and safety solution for children aged 4-12 years. This smartwatch functions similarly to a smartphone, offering a range of features including 4G network connectivity, WiFi, two-way calls, video calls, GPS location tracking, and various safety functions. This manual provides detailed instructions to help you set up, operate, and maintain your child's smartwatch.






Image: The PTHTECHUS Kids Smart Watch in pink, showcasing its video call capability on the display.

KEY FEATURES

The PTHTECHUS Kids Smart Watch is equipped with a variety of features to ensure connectivity, safety, and convenience:

- **4G Network & WiFi Connectivity:** Enables fast and reliable communication.
- **Two-way Calls & Video Calls:** Allows communication with pre-approved contacts.
- **GPS Locator:** Provides accurate real-time location tracking for peace of mind.
- **SOS Function:** A dedicated button for emergency calls to pre-set contacts.
- **HD Camera & Album:** For capturing photos and storing memories.
- **School Mode (Do Not Disturb):** Limits watch functions during school hours to prevent distractions.
- **Pedometer:** Tracks daily steps to encourage physical activity.
- **Alarm Clock & Class Timetable:** Helps children manage their schedule.
- **Voice Message:** Quick and easy communication.

- **Reject Unknown Calls:** Enhances safety by blocking calls from unapproved numbers.

MORE FUNCTION INTRODUCTION




Image: A visual representation of the various functions available on the PTHTECHUS Kids Smart Watch, including communication, tracking, and utility features.

SETUP GUIDE

1. SIM Card Installation

The watch requires a 4G Nano SIM card for full functionality, including calls and network features. Ensure the SIM card is activated and has a data plan. Carefully open the SIM card slot cover on the side of the watch. Insert the

Nano SIM card with the gold contacts facing up and the notched corner aligned correctly. Gently push until it clicks into place. Close the cover securely to ensure water resistance.

2. Initial Charging

Before first use, fully charge the smartwatch. Connect the magnetic charging cable to the charging port on the watch and plug the USB end into a compatible power adapter (not included). A full charge typically takes 2-3 hours. The battery indicator on the screen will show charging status.

3. App Download and Pairing

To manage the watch and access its features, download the companion application on your smartphone. Scan the QR code provided in the watch's packaging or search for the recommended app in your device's app store. Once installed, create an account and follow the in-app instructions to bind the watch to your account. This usually involves scanning a QR code displayed on the watch screen or entering a unique device ID.

OPERATING INSTRUCTIONS

Making and Receiving Calls

Once the SIM card is installed and the watch is paired with the app, you can make and receive calls. Parents can set up a whitelist of contacts through the app. The child can initiate calls to these pre-approved numbers directly from the watch's contact list. For video calls, select the video call option from the menu and choose a contact.

VIDEO CALL

Make communication between
parents and children more convenient



Image: The smartwatch and a smartphone demonstrating a live video call, highlighting the convenience of communication between parent and child.

GPS Tracking

The watch utilizes GPS, WiFi, and LBS positioning for accurate location tracking. Through the companion app on your smartphone, you can view your child's real-time location, set up geofences (electronic fences) for safe zones, and review historical routes.

MULTIPLE POSITIONING

POSITION

POSITION

GPS+WIFI+LBSPOSITIONING, OPEN THE
MOBILE PHONE BACKGROUND APP,
ACCURATELY LOCATE THE CHILD'S POSITION



Image: The smartwatch screen showing a map with location markers, demonstrating its precise positioning feature.

SOS Function

In an emergency, the child can press and hold the SOS button (typically located on the side of the watch) for 3 seconds. The watch will automatically dial pre-set emergency contacts in a loop until one answers, and also send location alerts to these contacts.



Image: A visual guide showing how to activate the SOS function by pressing and holding the dedicated button on the watch.

Using the HD Camera

The watch features a built-in HD camera. Children can take photos directly from the watch and view them in the album. Parents can also remotely control the camera via the app to take pictures.

HD CAMERA

HIGH-DEFINITION FRONT CAMERARECORD
THE WONDERFUL MOMENTS OF LIFE



Image: The smartwatch showcasing a photo on its screen, demonstrating the functionality of its integrated HD camera.

School Mode and Alarm Clock

The School Mode (Do Not Disturb) feature can be set via the parent app to disable most watch functions during specific times, ensuring the child is not distracted during class. Only SOS calls remain active. The alarm clock function allows setting multiple alarms for reminders like waking up or homework time.



Image: Illustrations depicting the alarm clock feature for timely reminders and the class mode for undisturbed learning.

MAINTENANCE

To ensure the longevity and optimal performance of your PTHTECHUS Kids Smart Watch, follow these maintenance guidelines:

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the charging port or SIM slot.
- **Water Resistance:** The watch is designed to be waterproof, but avoid prolonged submersion in water, hot water, or steam. Ensure the SIM card slot cover is always securely closed.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the watch regularly, even if not completely depleted, to prolong battery life. Use only the provided charging cable.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Impact:** While durable, avoid dropping the watch or subjecting it to strong impacts, which can damage internal components or the screen.

TROUBLESHOOTING

If you encounter issues with your PTHTECHUS Kids Smart Watch, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Watch won't turn on or charge.	Low battery; faulty charging cable/adapter; watch bricked.	Ensure the watch is fully charged using the original cable and a working adapter. Try a different USB port or adapter. If still unresponsive, contact customer support.
No network signal / Cannot make calls.	SIM card not inserted correctly; SIM card not activated; no signal in area; incorrect APN settings.	Reinsert the SIM card. Verify the SIM card is active and has a data plan. Check network coverage. Ensure APN settings are correct via the app or watch settings.
GPS location is inaccurate or not updating.	Poor satellite signal (indoors/dense areas); LBS/WiFi positioning active; app not refreshing.	Move to an open outdoor area. Ensure WiFi is enabled on the watch for better indoor positioning. Refresh the location in the companion app.
Cannot hear audio during calls / Microphone not working.	Volume too low; microphone blocked; software issue.	Increase call volume on the watch. Ensure the microphone opening is clear. Restart the watch. If the issue persists, it may indicate a hardware fault.
Watch screen is frozen or unresponsive.	Software glitch; low battery.	Perform a force restart (refer to specific model instructions, usually by holding the power button for 10-15 seconds). Ensure the watch is charged.

SPECIFICATIONS

- **Model Name:** Kids Smart Watch
- **Brand:** PTHTECHUS
- **Screen Size:** 1.54 Inches
- **Shape:** Rectangular
- **GPS:** Built-in GPS
- **Battery Cell Composition:** Lithium Polymer
- **Wireless Communication Standard:** 802.11g 54 Mbps (Wi-Fi)
- **Connectivity Technology:** Wi-Fi
- **Operating System:** Android Wear 2.9
- **Manufacturer:** PTHTECHUS
- **Country of Origin:** China
- **Batteries:** 1 Nonstandard Battery required

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or

visit the official PTHTECHUS website. Warranty terms and conditions may vary by region and retailer. Keep your proof of purchase for any warranty claims.

For technical assistance or further inquiries, please contact PTHTECHUS customer service directly through their official channels.