

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BANTI](#) /
- › [BANTI 55x24 Inch Electric Height Adjustable Standing Desk User Manual](#)

BANTI B-STDJ-55RC

BANTI 55x24 Inch Electric Height Adjustable Standing Desk User Manual

Model: B-STDJ-55RC

[Safety Information](#)

[Setup & Assembly](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Product Specifications](#)

[Warranty & Support](#)

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your BANTI 55x24 inch Electric Height Adjustable Standing Desk. Please read this manual thoroughly before use to ensure proper function and safety. Keep this manual for future reference.

SAFETY INFORMATION

- Ensure proper assembly and anchoring of the desk.
- Do not exceed the maximum weight recommendation of 155 pounds (70 kg) on the desktop.
- Keep children and pets away from the desk during height adjustments.
- Ensure no obstacles are in the path of the desk's movement (up or down).
- Do not sit or stand on the desk.
- Unplug the desk from the power outlet before cleaning, maintenance, or if it will be unused for an extended period.

SETUP & ASSEMBLY

The BANTI Electric Standing Desk requires assembly. Detailed installation instructions and all necessary tools are included in the product package. Follow the steps carefully to ensure correct setup and stable operation.

The desktop is designed with a splice board, meaning it consists of two pieces that need to be joined. The electric lifting mechanism and legs are then attached to the desktop.

Assembly Tip: The assembly steps have been optimized for user convenience. All parts are clearly labeled, and the package contains assembly tools and detailed instructions. Ensure all connections are secure before applying weight or operating the desk.



Figure 1: Fully assembled BANTI 55x24 inch electric standing desk. The desk features a rustic brown top and black frame, with a laptop, lamp, and headphones visible on the surface. A chair is positioned to the left.



Figure 2: Diagram illustrating the dimensions of the BANTI electric standing desk. The desktop measures 55 inches wide by 23.6 inches deep. The adjustable height range is from 28.3 inches to 46.2 inches.

For a visual guide, refer to the assembly video (if available from the manufacturer) or the detailed instructions provided in your package.

OPERATING INSTRUCTIONS

Your BANTI Electric Standing Desk features an intuitive control panel for height adjustment and memory presets, designed for quiet operation (below 50dB).

Height Adjustment

1. Connect the power adapter to the desk and a functional wall outlet.

2. Use the **Up Arrow** button to raise the desk and the **Down Arrow** button to lower it. The desk can be precisely adjusted within the range of 28.3 inches to 46.2 inches.

Memory Presets

The desk includes two preset buttons to save your preferred sitting and standing heights for quick recall.

1. Adjust the desk to your desired height using the Up/Down arrows.
2. Press and hold one of the preset buttons (typically marked with a sitting or standing icon) until the display flashes or a beep is heard. This action saves the current height to that specific preset.
3. To recall a saved height, simply press the corresponding preset button once. The desk will automatically move to the stored position.

Reset Function

A dedicated reset button is available to recalibrate the desk's height settings if needed, or after initial setup.




Figure 3: Close-up of the multi-function intelligent keypad on the BANTI electric standing desk. Buttons include Up, Down, Standing Height Setting, Sitting Height Setting, and Reset. The desk operates quietly, below 50dB.

Included Accessories

The desk comes with practical accessories to help maintain an organized and efficient workspace:

- **Cup Holder:** Attach the cup holder to the side of the desk to keep beverages secure and prevent spills on the desktop.
- **Storage Hook:** Utilize the storage hook for hanging headphones, bags, or other items, keeping your desktop clear and tidy.
- **Cable Management:** The desk includes features like bundle clamps and cable routing options to organize and route power and data cables neatly, preventing clutter and tangles.



Figure 4: Demonstrates the included cup holder and storage hook. The cup holder securely holds a cup, and the storage hook is shown holding a pair of headphones, keeping the desktop clear.

Reliable & Durable

Lifting tested 50,000 times

132 LBS Load Capacity

50,000




Figure 5: Illustrates the cable management features, including a cable organizer clip and a bundle clamp (grommet) for routing wires through the desktop, maintaining a tidy workspace.

MAINTENANCE

To ensure the longevity and optimal performance of your BANTI Electric Standing Desk, follow these maintenance guidelines:

- **Cleaning:** Clean the desk surfaces with a damp or dry cloth as needed. Avoid using harsh chemicals or abrasive cleaners that could damage the laminated wood finish.
- **Inspection:** Periodically check all screws, bolts, and connections to ensure they remain tight and secure. Retighten if necessary.
- **Cable Management:** Regularly inspect all cables to ensure they are not pinched, tangled, or stressed, especially during height adjustments. Proper cable routing prevents damage and ensures

smooth operation.

- **Weight Distribution:** Distribute weight evenly across the desktop to prevent undue stress on the lifting mechanism.

TROUBLESHOOTING

If you encounter any issues with your BANTI Electric Standing Desk, refer to the following common problems and their solutions:

- **Desk Not Moving:**
 - Check if the power cord is securely plugged into both the desk's control box and a functional wall outlet.
 - Ensure no objects are obstructing the desk's movement path.
 - If the control panel displays an error code, refer to the specific error code section in your detailed manual (if provided).
- **Uneven Movement or Desk Tilting:**
 - Perform a reset operation as described in the "Operating Instructions" section to recalibrate the desk's height sensors.
 - Verify that the desk is placed on a level surface.
 - Check for any loose connections in the frame or lifting mechanism.
- **Unusual Noises During Operation:**
 - While the desk is designed for quiet operation, any unusual or loud noises may indicate an issue. Stop operation immediately.
 - Inspect for loose parts, foreign objects, or obstructions within the lifting mechanism.
 - If the issue persists after inspection, contact customer support.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	BANTI
Model Number	B-STDJ-55RC
Product Dimensions (D x W x H)	23.6"D x 55"W x 28.3"H
Adjustable Height Range	28.3" to 46.2"
Maximum Weight Recommendation	155 Pounds (70 kg)
Top Material Type	Wood (Laminated)
Base Material	Alloy Steel
Included Components	Cup Holder, Headphone Hook
Lifting Mechanism	Electric Motor
Assembly Required	Yes (Tools Included)

Color	Rustic Brown Top, Black Frame
Item Weight	45.19 Pounds

WARRANTY & SUPPORT

BANTI stands behind the quality of its products. This electric standing desk comes with the following manufacturer's limited warranty:

- **Motor:** 2 years
- **Frame:** 5 years

For any questions, warranty claims, or technical support during assembly and use, please do not hesitate to contact BANTI customer service. Refer to your purchase documentation for specific contact details.

Returns: This product is eligible for 30-day free returns, refund, or replacement, as per Amazon's policy.