

[Manuals.plus](#) /

› [Rowenta](#) /

› Rowenta Compact Power XXL Bagless Vacuum Cleaner RO4B23EA User Manual

Rowenta RO4B23EA

Rowenta Compact Power XXL Bagless Vacuum Cleaner RO4B23EA User Manual

Model: RO4B23EA

1. INTRODUCTION

Thank you for choosing the Rowenta Compact Power XXL Bagless Vacuum Cleaner. This appliance is designed to provide powerful and efficient cleaning for your home. Its advanced cyclonic technology ensures strong, consistent suction, while the high-level filtration system captures up to 99.98% of fine dust particles, contributing to a healthier indoor environment. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.



A complete view of the Rowenta Compact Power XXL bagless vacuum cleaner, including the main unit, flexible hose, telescopic tube, and floor brush, ready for use.

2. SAFETY INSTRUCTIONS

Please read these safety instructions carefully before using the appliance and keep them for future reference. Incorrect use may lead to electric shock, fire, or serious injury.

- Always ensure the voltage indicated on the rating label corresponds to your mains voltage.
- Do not use the vacuum cleaner to pick up water or any other liquids, hot ashes, large sharp objects, or flammable/explosive substances.
- Never operate the appliance with a damaged power cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Unplug the appliance from the mains socket before cleaning or performing any maintenance.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PRODUCT OVERVIEW

The Rowenta Compact Power XXL vacuum cleaner is designed for ease of use and powerful cleaning. Key components include:

- **Main Unit:** Houses the motor, dustbin, and filtration system.
- **Flexible Hose:** Connects the main unit to the telescopic tube.
- **Telescopic Tube:** Adjustable for comfortable reach.
- **Floor Nozzle:** For general floor cleaning.
- **XXL Dustbin (2.5 L):** Large capacity for extended cleaning without frequent emptying.
- **Integrated Accessories:** Includes a crevice nozzle convertible into a brush for corners and various surfaces.



An image illustrating the compact dimensions of the Rowenta Compact Power XXL vacuum cleaner, with measurements of 40.9 cm length, 29.1 cm width, and 27.6 cm height.

4. SETUP

Follow these steps to assemble your vacuum cleaner:

1. **Attach the Hose:** Insert the flexible hose into the suction inlet on the main unit until it clicks into place.
2. **Connect the Telescopic Tube:** Attach the telescopic tube to the handle of the flexible hose. Adjust the length to your preference by pressing the release button and sliding.
3. **Attach the Floor Nozzle:** Connect the floor nozzle to the end of the telescopic tube. Ensure it is securely fitted.
4. **Power Connection:** Extend the power cord and plug it into a suitable electrical outlet.

5. OPERATION

Using your Rowenta Compact Power XXL vacuum cleaner is straightforward:

1. **Power On/Off:** Press the On/Off button located on the main unit to start or stop the vacuum cleaner.
2. **Adjust Suction Power:** The vacuum cleaner operates at a single power level for optimal efficiency.
3. **Using Accessories:** For specific cleaning tasks, detach the floor nozzle and attach the appropriate accessory (e.g., crevice nozzle for tight spaces, brush for delicate surfaces).
4. **Cleaning Radius:** The vacuum cleaner offers an 8.8-meter operating radius, allowing you to clean large areas without frequently changing power outlets.

Your browser does not support the video tag.

This video demonstrates the Rowenta Compact Power XXL vacuum cleaner's powerful suction (900W max), large 2.5L dustbin capacity, compact design for easy use and storage, high-level filtration system, and an 8.8m operating radius. It highlights the product's key features and benefits.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

6.1. Emptying the Dustbin

The 2.5L XXL dustbin is designed for quick and effortless emptying in just 4 steps:

1. Press the dustbin release button.
2. Carefully remove the dustbin from the main unit.
3. Open the dustbin lid over a waste bin.
4. Empty the contents and close the lid securely.

CAPACITÉ XXL

Capacité de 2.5L
pour plus de praticité



An image demonstrating the large 2.5-liter dustbin of the Rowenta Compact Power XXL vacuum cleaner, emphasizing its generous capacity for extended cleaning sessions.

6.2. Cleaning Filters

The 3-level filtration system requires periodic cleaning:

- **Pre-motor Filter:** Located inside the dustbin. Remove and tap to dislodge dust. Wash with water if heavily soiled and ensure it is completely dry before reinserting.
- **Exhaust Filter:** Located at the rear of the appliance. Remove and clean according to the instructions in the full manual (if available).

For optimal performance, check and clean filters regularly, especially if suction power decreases.



A diagram showing the internal airflow and filtration process of the Rowenta Compact Power XXL vacuum cleaner, highlighting its ability to capture over 99.98% of dust particles.

7. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not start.	No power supply.	Check if the plug is correctly inserted into the socket and if the socket is working.
Reduced suction power.	Dustbin full or filters clogged.	Empty the dustbin. Clean or replace the filters as described in the maintenance section.
Unusual noise during operation.	Obstruction in the hose or nozzle.	Switch off and unplug the appliance. Check the hose, telescopic tube, and nozzle for any blockages and remove them.

8. SPECIFICATIONS

Detailed technical specifications for the Rowenta Compact Power XXL vacuum cleaner:

Feature	Detail
Model Number	RO4B23EA
Power Consumption	900 Watts max
Dustbin Capacity	2.5 Liters
Filtration Level	Captures >99.98% of fine particles (3-level system)
Operating Radius	8.8 meters
Noise Level	69 Decibels
Dimensions (L x W x H)	40.9 x 29.1 x 27.6 cm
Weight	3.8 Kilograms
Power Source	Corded Electric
Filter Type	Foam
Special Feature	Bagless

9. WARRANTY AND SUPPORT

Rowenta is committed to providing durable and repairable products. This appliance benefits from a **15-year repairability commitment at a fair price**, supported by a network of 6200 repairers worldwide. This initiative aims to contribute to environmental protection and waste reduction.

For further assistance, spare parts, or warranty claims, please refer to the official Rowenta website or contact their customer support.



An image detailing Rowenta's 15-year reparability commitment, emphasizing the availability of spare parts at a fair price to support product longevity and reduce waste.

© 2024 Rowenta. All rights reserved.