Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DR.PREPARE DF7

DR.PREPARE Small Tower Fan

User Manual

Product Overview



The DR.PREPARE Small Tower Fan is designed for personal cooling, featuring a sleek black design with two independently adjustable fan heads and an oscillating base. It provides powerful airflow with multiple speed settings and a convenient auto-off timer, making it suitable for various indoor environments.

What's in the Box

- DR.PREPARE Small Tower Fan Unit
- USB-C Power Cable
- 5V/3A Wall Adapter
- User Manual

Setup

Unpacking

Carefully remove all components from the packaging. Ensure all parts listed in the 'What's in the Box' section are present and undamaged.

Power Connection

Place the fan on a stable, flat surface. Connect the USB-C power cable to the input port on the back of the fan's base. Plug the other end of the cable into the included 5V/3A wall adapter, and then plug the adapter into a standard 120V electrical outlet. The fan requires an external power source to function.



Image: Fan base with USB-C input and power adapter.

Operating Instructions

Control Panel Overview



Image: Detailed view of the fan's touch control panel.

Power On/Off and Speed Settings

- Press the **POWER** button once to turn the fan on at the default low speed.
- Press the **POWER** button repeatedly to cycle through Low (L), Medium (M), High (H) speeds.
- Press and hold the **POWER** button to turn the fan off.

Oscillation Function



Image: Fan demonstrating 105° automatic oscillation.

- Press the **SWING** button once to activate 105° automatic oscillation.
- Press the **SWING** button again to stop oscillation.

Adjustable Tilt



Image: Fan heads manually tilting up to 270°.

- Manually adjust each fan head up to 270° to direct airflow precisely where needed.

Timer Function



Image: Fan operating with timer settings visible.

- Press the **TIMER** button repeatedly to set the auto-off timer for 2, 4, or 8 hours.
- The corresponding indicator light will illuminate.
- To cancel the timer, press the **TIMER** button until all indicator lights are off.

Features

- **Dual Adjustable Fan:** Features rotating and oscillation design with 270° tilt for precise airflow and 105° ultra-wide oscillation for accelerated air circulation.
- **Powerful Airflow:** Equipped with two powerful motors providing strong airflow and 3 variable speed settings (Low, Medium, High).
- **Space-Saving Design:** Compact 15-inch size ideal for bedrooms, home offices, desks, bedsides, nightstands, or kitchen counters.
- **USB-Powered:** Convenient USB input port for power, compatible with the included 5V/3A wall adapter or a 5V/3A power bank (not included).
- **3 Auto-Off Timer:** Built-in programmable timer allows automatic shut-off after 2, 4, or 8 hours for restful sleep.

- *Note: This fan does NOT include a remote control.*

Maintenance

Cleaning Instructions



Image: Cleaning the fan's blades.

- Always unplug the fan from the electrical supply source before cleaning.
- To remove persistent dirt, use a damp cloth or sponge with a mild soap solution.
- Wipe the fan dry with a clean, soft cloth.
- Do not use abrasive cleaners, solvents (such as thinners), or harsh chemicals, as these may damage the plastic housing.
- Be sure not to make water or other liquids enter inside the motor.

Troubleshooting

Issue	Solution
Fan not turning on.	Ensure the power cable is securely connected and the 5V/3A wall adapter is properly plugged into a working outlet.
Weak or inconsistent airflow.	Check if fan heads are tilted correctly. Try increasing the speed setting. Ensure there are no obstructions blocking the air intake or outlet.
Unusual noise during operation.	Ensure the fan is placed on a stable, flat surface. Check for any foreign objects or debris that might be caught in the fan blades.
Fan stops unexpectedly.	Verify the timer setting. If a timer is set, the fan will automatically turn off after the selected duration.
Interference with other electronic devices.	If the fan causes interference with other devices (e.g., garage door openers), try repositioning the fan further away from the affected electronics.

Specifications

Feature	Detail
Model Name	Small Tower Fan (DF7)
Input	5V/3A DC
Rated Power	10 watts

Feature	Detail
Speed Settings	Low, Medium, High (3 levels)
Oscillation	105°
Adjustable Tilt	Up to 270°
Timer	2, 4, or 8 hours
Product Dimensions	6.4"D x 5.5"W x 15.7"H
Item Weight	2.9 Pounds
Control Method	Touch

Warranty & Support

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official DR.PREPARE website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BWQDB1QZ

More documents and user manuals: **https://manuals.plus/**