

[Manuals.plus](#) /

› [FEZIBO](#) /

› FEZIBO 63" L-Shaped Electric Standing Desk Instruction Manual

FEZIBO B0BWR3KMYQ

FEZIBO 63" L-Shaped Electric Standing Desk Instruction Manual

Model: B0BWR3KMYQ

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your FEZIBO 63" L-Shaped Electric Standing Desk. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Image 1.1: FEZIBO 63" L-Shaped Electric Standing Desk.

2. SAFETY INFORMATION

- Ensure the desk is properly anchored to the wall for stability if required by local regulations or personal preference.
- Do not exceed the maximum weight recommendation of **175 pounds (79.3 kg)**.
- **Two people are recommended for assembly** to prevent injury and ensure proper setup.
- The desk is equipped with **anti-collision technology**. If the adjustable desk encounters obstacles during movement, it will retract approximately 2 cm in the opposite direction to prevent potential damage or injury.
- Keep children and pets away from the desk during height adjustments.
- Do not sit or stand on the desk.
- Ensure all cables are managed to prevent entanglement during desk movement.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the assembly video for visual identification of parts.



Image 3.1: Overview of desk components and hardware.

4. SETUP AND ASSEMBLY

The FEZIBO L-Shaped Electric Standing Desk is designed for hassle-free installation. All necessary assembly tools are included. For a step-by-step visual guide, please refer to the official installation video below.

Video 4.1: Official FEZIBO L-Shaped Standing Desk Installation Guide. This video demonstrates the assembly process for the desk frame and tabletop components.

General Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Assemble the desk legs and crossbars according to the instructions.
3. Attach the motor and drive shaft mechanisms.

4. Secure the tabletop sections to the frame using the provided hardware.
5. Connect the control panel and power supply.
6. Perform initial calibration as per the operating instructions.

Two people are recommended for lifting and positioning the desk during assembly.

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

The desk features an electric adjustable height mechanism, allowing seamless transitions between sitting and standing positions. The height range is from **28.3 inches to 46.8 inches**.

- Use the **Up (▲)** and **Down (▼)** arrow buttons on the control panel to manually adjust the desk height. The current height is displayed on the LED screen.
- The motor operates with low noise, typically under 48 dB.



Image 5.1: Smooth transition from sitting to standing height.

5.2. Memory Presets

The control panel includes **three preset memory buttons (1, 2, 3)** to save your preferred sitting and standing heights for quick adjustments.

- To **save a height preset**: Adjust the desk to your desired height using the Up/Down arrows. Press the 'S' button, then press the desired memory button (1, 2, or 3) within 3 seconds. The display will confirm the setting.
- To **recall a height preset**: Simply press the corresponding memory button (1, 2, or 3). The desk will automatically move to the saved height.



Image 5.2: Convenient control panel with LED display and memory buttons.

5.3. Child Lock Function

To prevent accidental adjustments, the desk features a child lock function.

- To **lock**: Press and hold both the '2' and '▲' (Up) buttons for 5 seconds. The display will indicate 'LOC'.
- To **unlock**: Press and hold both the '2' and '▲' (Up) buttons for 5 seconds again. The display will return to the current height.



Image 5.3: Child Lock activation and deactivation.

6. MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure cables are neatly organized and secured to prevent interference with the desk's moving parts. The desk includes cable management hooks for this purpose.

PREVENT ACCIDENTALLY TOUCH OF CHILD LOCK

LOCK: Press and hold both the "2" and "A" buttons for 5 seconds.

UNLOCK: Press and hold both the "2" and "A" buttons for 5 seconds again.

No Child Lock Function

✗ Finger pinch injury

✗ Hit the child's head

Image 6.1: Desk hooks for cable management and accessories.

7. TROUBLESHOOTING

If you experience issues with your FEZIBO L-Shaped Electric Standing Desk, consider the following:

- **Desk Not Moving / Unresponsive Control Panel:**
 - Check all power connections to ensure they are securely plugged in.
 - Perform a reset: Unplug the desk from the power outlet for 10-15 seconds, then plug it back in. If the issue persists, consult the manufacturer's support.
- **Uneven Movement / Desk Wobbling:**
 - Ensure the desk is on a level surface. Use the adjustable feet to stabilize the desk if the floor is uneven.
 - Verify that all assembly screws are tightened.
- **Anti-Collision System Triggering Frequently:**
 - Ensure there are no obstructions in the path of the desk's movement.

- The sensitivity of the anti-collision system may be adjustable (refer to specific control panel instructions if available).

8. SPECIFICATIONS

Feature	Detail
Brand	FEZIBO
Model Number	B0BWR3KMYQ
Product Dimensions	55"D x 63"W x 28.3"H
Color	Rustic Brown
Style	Modern
Base Material	Alloy Steel
Top Material Type	FSC-Certified wood
Finish Type	Laminated
Special Feature	Cordless (referring to the desk's ability to be placed freely, not battery-powered), Electric Height Adjustment, Anti-collision, Memory Presets
Recommended Uses	Gaming, Office
Maximum Weight Recommendation	175 Pounds (79.3 kg)
Minimum Height	27.6 Inches (70.1 cm)
Maximum Height	46.9 Inches (119.1 cm)
Noise Level	Under 48 dB
Number of Height Positions	3 (Memory Presets)
Required Assembly	Yes
Recommended Number of People for Assembly	2

9. WARRANTY AND SUPPORT

For any installation assistance, technical issues, or warranty inquiries, please contact FEZIBO customer support. Detailed contact information can typically be found on the product packaging or the official FEZIBO website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question