

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [COSTWAY](#) /

› [COSTWAY HW57754GR-VC 4-Tier Microwave Oven Rack Instruction Manual](#)

COSTWAY HW57754GR-VC

COSTWAY 4-Tier Microwave Oven Rack Instruction Manual

Model: HW57754GR-VC

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your COSTWAY 4-Tier Microwave Oven Rack. Designed for versatile storage, this freestanding metal shelf is suitable for kitchens, home offices, living rooms, and hallways. Its robust construction and adjustable features offer a practical solution for organizing various items.

SAFETY INSTRUCTIONS

- Read all instructions carefully before assembly and use.
- Keep children and pets away during assembly. Small parts can be a choking hazard.
- Ensure all connections are securely tightened before placing items on the rack.
- Do not exceed the maximum load capacity of 25 kg per shelf.
- Place the rack on a flat, stable surface to prevent tipping.
- Avoid climbing or standing on the rack.
- Do not use abrasive cleaners or materials that could damage the finish.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 1 x COSTWAY 4-Tier Microwave Oven Rack (disassembled components)
- 1 x Instruction Manual
- Assembly hardware (screws, nuts, etc.)

SPECIFICATIONS

Model Number	HW57754GR-VC
Brand	COSTWAY
Color	Grey
Material	Iron
Dimensions (L x W x H)	59 cm x 34 cm x 136 cm
Net Weight	5.5 kg
Load Capacity per Shelf	25 kg
Number of Shelves	4
Assembly Required	Yes
Mounting Type	Freestanding, Floor Mounted Stand
Finish Type	Glossy Coated, Rust-resistant
Special Features	Space-saving, Heavy-duty, Adjustable Shelves, Adjustable Feet, Wire Mesh Design

Note: Dimensions are approximate and may vary slightly.




Image: Detailed dimensions of the rack components.

SETUP AND ASSEMBLY

Assembly of the COSTWAY 4-Tier Microwave Oven Rack is required. Please follow the steps below

carefully. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Check against the package contents list to ensure all pieces are present.
2. **Assemble Frame:** Connect the vertical support poles using the provided connectors and screws. Ensure all poles are oriented correctly according to the diagrams.
3. **Attach Shelves:** Slide the wire mesh shelves onto the support poles. The three lower shelves are adjustable; position them at your desired height. Secure each shelf with the locking clips or screws as indicated in the diagram.
4. **Install Top Rail:** Attach the top rail to the uppermost section of the frame.
5. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the rack's legs. Adjust them to ensure the rack is level and stable on your floor.
6. **Final Tightening:** Once all parts are in place, carefully tighten all screws and connections. Do not overtighten.



Image: Key features of the rack, including ease of assembly.

OPERATING AND USAGE

The COSTWAY 4-Tier Microwave Oven Rack is designed for versatile storage in various home environments. Its robust iron frame and wire mesh shelves make it suitable for heavy-duty use.

Placement and Stability

- Place the rack on a flat, level surface. Use the adjustable feet to compensate for any unevenness in the floor, ensuring maximum stability.
- The non-slip pads on the feet protect your floor from scratches.

Storage Capacity

- Each of the four shelves can support up to 25 kg, making it ideal for heavy appliances like microwave

ovens, toasters, and other kitchen equipment.

- The wire mesh design prevents moisture and dust accumulation, making it easy to clean and suitable for kitchen items like dishes and spices.

Adjustable Shelves

The three lower shelves can be adjusted to different heights to accommodate items of various sizes, providing flexible storage solutions.

Multi-functional Use

Beyond the kitchen, this rack can be used in:

- **Living Room:** For books, decorative items, or media.
- **Study/Home Office:** For documents, office supplies, or small equipment.
- **Hallway:** For shoes, bags, or other entryway essentials.



Image: Rack used as a bookshelf, showcasing its versatility.



Image: Rack in a kitchen, storing a microwave and other kitchen items.

Halten Sie Ihr Zuhause ordentlich!



Image: Before and after comparison demonstrating organization with the rack.

MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your microwave oven rack.

- **Cleaning:** Wipe the rack with a dry cloth to remove dust and debris. For tougher stains, use a slightly damp cloth with mild soap, then dry immediately.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the rust-resistant coating.

- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Moisture:** While the finish is rust-resistant, avoid prolonged exposure to excessive moisture to maintain its condition.

TROUBLESHOOTING

If you encounter any issues with your rack, refer to the following common problems and solutions:

- **Rack is Unstable/Wobbly:**
 - Ensure the rack is placed on a flat, level surface.
 - Adjust the leveling feet at the bottom of each leg until the rack is stable.
 - Check all assembly screws and connections to ensure they are fully tightened.
- **Difficulty Assembling:**
 - Review the assembly instructions and diagrams carefully.
 - Ensure all parts are correctly oriented before tightening.
 - Do not force parts together; if they don't fit, recheck the instructions.
- **Missing Parts:**
 - Double-check the packaging and surrounding area for any small components.
 - If parts are genuinely missing, contact COSTWAY customer support with your model number and a description of the missing parts.

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. If you require further assistance or have questions not covered in this manual, please contact COSTWAY customer support through their official website or the contact information provided with your product.