Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

QCY T13 ANC

QCY T13 ANC Active Noise Cancelling Wireless Earbuds

User Manual

Model: T13 ANC | Brand: QCY

Introduction

The QCY T13 ANC Active Noise Cancelling Wireless Earbuds offer an exceptional audio experience with advanced Bluetooth 5.3 technology to ensure a stable and fast connection. Featuring active noise cancellation up to 30dB and crystal-clear call quality with 4 microphones, these earbuds are designed for comfort and extended use, providing up to 30 hours of playtime with the charging case.

What's in the Box

- User Manual
- Charging Case (1)
- Silicone Eartips (XS/S/M/L, 4 pairs)
- Type-C Cable (1)




Figure 1: Package Contents and Product Parameters.

Setup

1. Charging the Earbuds and Case

Before first use, ensure both the earbuds and charging case are fully charged. Connect the provided Type-C cable to the charging case and a power source. The charging case has a battery capacity of 380mAh and takes approximately 1 hour to fully charge. A 10-minute quick charge provides up to 60 minutes of playtime for the earbuds.



Figure 2: QCY T13 ANC Earbuds in their charging case.

2. Initial Pairing and Connection

For the first-time connection, open the lid of the charging case. The earbuds will automatically power on and enter pairing mode. On your smartphone or device, enable Bluetooth and search for "QCY-T13 ANC" in the list of available devices. Tap to connect. Once connected, you will hear a voice prompt confirming the successful pairing.

Your browser does not support the video tag.

Video 1: Demonstrates how to connect the QCY T13 ANC Earbuds to a device (0:05 - 0:17).

3. Choosing and Fitting Eartips

The earbuds come with four different sizes of silicone eartips (XS/S/M/L). Select the size that provides the most comfortable and secure fit for your ears. A proper fit is crucial for optimal sound quality and effective noise cancellation. Ensure the microphone is pointed towards your mouth for clear call quality.




Figure 3: Guide to proper earbud placement for optimal fit and microphone performance.

Operating Instructions

1. Touch Controls Overview

The QCY T13 ANC earbuds feature sensitive touch controls for various functions. Refer to the table below for a quick overview:

Action	Function
Double touch (either earbud)	Pause/Resume playing, Answer/End call
Triple touch (right earbud)	Skip track forward
Triple touch (left earbud)	Summon Voice Assistant
Keep touching for 1.5s (either earbud)	Ignore incoming call
Keep touching left panel for 1.5s	Turn on/off Gaming Mode
Keep touching right panel for 1.5s	Switch among ANC ON, ANC OFF, Transparency Mode (not available in mono mode)




Figure 4: Detailed diagram of touch control functions.

2. Active Noise Cancellation (ANC) and Transparency Mode

The QCY T13 ANC earbuds feature Active Noise Cancellation, which can reduce up to 30dB of background noise, allowing you to focus on your audio. Transparency Mode allows you to hear your surroundings without removing the earbuds. To switch between ANC ON, ANC OFF, and Transparency modes, keep touching the right earbud for 1.5 seconds. You will hear voice prompts for each mode change.
Note: ANC is not available in mono mode.




Figure 5: Active Noise Cancellation and Transparency Mode capabilities.




Figure 6: Noise cancellation performance, even in windy conditions.

Your browser does not support the video tag.

Video 2: Demonstrates how to switch between ANC, Normal, and Transparency modes (0:18 - 0:35).

3. Music Control

When playing music, double-touch either earbud to pause or resume playback. To skip to the next track, triple-touch the right earbud.

Your browser does not support the video tag.

Video 3: Demonstrates music playback controls (0:36 - 0:50).

4. Call Management

To answer an incoming call, double-touch either earbud. Double-touch again to end the call. To ignore an incoming call, keep touching either earbud for 1.5 seconds.



Figure 7: The 4-microphone Environmental Noise Cancellation (ENC) system ensures clear calls.

Your browser does not support the video tag.

Video 4: Demonstrates how to answer, end, or ignore calls (0:51 - 1:03).

5. Voice Assistant

To activate your device's voice assistant (e.g., Siri, Google Assistant), triple-touch the left earbud.

Your browser does not support the video tag.

Video 5: Demonstrates how to summon the voice assistant (1:04 - 1:12).

6. Gaming Mode

The QCY T13 ANC earbuds feature a low-latency Gaming Mode, reducing audio latency to 68ms for a more synchronized experience in gaming and streaming. To turn on/off Gaming Mode, keep touching the left earbud for 1.5 seconds.




Figure 8: Experience low-latency audio with Gaming Mode.

Your browser does not support the video tag.

Video 6: Demonstrates how to activate/deactivate Gaming Mode (1:13 - 1:23).

Maintenance

1. Cleaning

Regularly clean the earbuds and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth to wipe down the surfaces. For the eartips, remove them and clean with a mild soap solution if necessary, then rinse

and dry thoroughly before reattaching. Ensure charging contacts are free of debris.

2. Storage

When not in use, store the earbuds in their charging case to protect them from dust, moisture, and physical damage. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

3. Battery Care

To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly, even if not in constant use. The earbuds offer 7 hours of working time per full charge, and the charging case extends that to 30 hours with ANC mode turned off.



Figure 9: Extended battery life for continuous listening.

Troubleshooting

1. Disconnecting Earbuds from Phone

To disconnect the earbuds from your phone, place both earbuds back into the charging case and keep the lid open. Press and hold the charging case button for 3 seconds until the LEDs on the earbuds blink white once. This will put them back into pairing mode, disconnecting them from the current device.

Your browser does not support the video tag.

Video 7: Demonstrates how to disconnect the QCY T13 ANC Earbuds from a device (1:24 - 1:36).

2. Factory Reset

If you experience persistent connectivity issues or wish to clear all previous pairing records, you can perform a factory reset. Place both earbuds into the charging case and keep the lid open. Press and hold the charging case button for 10 seconds until the LEDs on the earbuds blink red 5 times. This will reset the earbuds to their factory settings.

Your browser does not support the video tag.

Video 8: Demonstrates how to perform a factory reset on the QCY T13 ANC Earbuds (1:37 - 2:00).

Specifications

Feature	Detail
Model Name	QCY T13 ANC
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	15 Meters
Noise Control	Active Noise Cancellation
Audio Driver Type	Dynamic Driver (10mm)
Frequency Range	20 Hz - 20,000 Hz
Battery Life (Earbuds)	7 hours (single charge)
Total Battery Life (with case)	30 Hours (ANC off)
Charging Case Battery Capacity	380 Milliamp Hours
Charging Time (Case)	1 Hour
Water Resistance Level	IPX5 Waterproof
Control Method	Touch
Audio Latency	68 Milliseconds (Gaming Mode)
Item Weight	44 Grams (total)
Product Dimensions	2.17 x 2.17 x 1.15 inches

Warranty and Support

QCY products typically come with a standard warranty. Please refer to the warranty card included in your package for

specific terms and conditions. For further assistance, troubleshooting, or to access the official user manual PDF, please visit the QCY Store on Amazon or download the User Manual (PDF).

© 2024 QCY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BWRBKMCK

More documents and user manuals: **https://manuals.plus/**