

- [Manuals.plus](#) /
- › [IH CASADECOR](#) /
 - › IH CASADECOR Natural Acacia Wood Rectangular Serving Board (Model BKL-1016) User Manual

IH CASADECOR BKL-1016

IH CASADECOR Natural Acacia Wood Rectangular Serving Board
MODEL: BKL-1016 USER MANUAL

1. INTRODUCTION

Thank you for choosing the IH CASADECOR Natural Acacia Wood Rectangular Serving Board. This manual provides essential information for the proper use, care, and maintenance of your new serving board. Please read these instructions carefully before first use and retain them for future reference.

This serving board is designed to enhance your dining and entertaining experience, offering a stylish and functional way to present food items. Crafted from natural acacia wood, it features a polished finish and convenient black handles for easy transport.



Image 1: The IH CASADECOR Natural Acacia Wood Rectangular Serving Board in a kitchen setting.

2. PRODUCT OVERVIEW

The IH CASADECOR serving board is made from durable acacia wood, known for its rich grain and natural resistance. It features a rectangular shape with integrated black handles for comfortable carrying. The board is ideal for serving appetizers, cheeses, desserts, and other culinary delights.

Key Features:

- **Material:** Natural Acacia Wood
- **Design:** Rectangular serving board with black metallic handles
- **Finish:** Polished
- **Dimensions:** Approximately 24 inches (L) x 5 inches (W) x 1 inch (H)



Image 2: Angled view of the serving board, highlighting the black handles and subtle feet.



Image 3: Close-up detail of a handle and the natural acacia wood grain.

3. SETUP AND FIRST USE

Unpacking:

1. Carefully remove the serving board from its packaging.
2. Inspect the board for any signs of damage. If damaged, contact customer support immediately.
3. Dispose of packaging materials responsibly.

Before First Use:

Before using your serving board for the first time, it is important to clean it properly.

- Wash the board thoroughly with mild soap and warm water.
- Rinse completely and dry immediately with a clean cloth.
- Allow the board to air dry completely in an upright position before storing.

4. OPERATING INSTRUCTIONS

This acacia wood board is designed for serving. While durable, it is not intended for heavy-duty cutting or chopping, which can damage the polished surface and wood grain. For best results and to maintain its aesthetic appeal, use it primarily for presenting food.

Using Your Serving Board:

- Place food items directly on the board or use small dishes/liners for wet or oily foods to protect the wood.
- Use the integrated handles to safely transport the board from the kitchen to your serving area.
- Avoid placing extremely hot items directly on the wood surface without a protective barrier.

5. CARE AND MAINTENANCE

Proper care will extend the life and beauty of your acacia wood serving board.

Cleaning:

- **Hand Wash Only:** Wash the board immediately after use with mild soap and warm water.
- **Do Not Soak:** Never submerge the board in water, as this can cause warping, cracking, or splitting.
- **Dry Immediately:** After washing, dry the board thoroughly with a clean towel.
- **Air Dry:** Allow the board to air dry completely in an upright position to ensure all sides dry evenly.
- **Not Dishwasher Safe:** This product is not suitable for dishwasher cleaning.

Maintenance:

- **Oil Regularly:** To prevent the wood from drying out and to maintain its luster, periodically apply a food-grade mineral oil or wood conditioner. Apply a generous amount, let it soak in for several hours or overnight, then wipe off any excess.
- **Avoid Extreme Temperatures:** Do not place the board in an oven, microwave, or expose it to direct heat sources. It is also not oven safe.
- **Storage:** Store the board in a dry area away from direct sunlight or extreme temperature changes. Storing it flat or upright in a rack is recommended.

6. TROUBLESHOOTING

Common Issues and Solutions:

- **Wood Drying Out/Fading:** This is normal for natural wood. Apply food-grade mineral oil regularly to restore moisture and shine.
- **Minor Scratches:** Light scratches can often be minimized by applying mineral oil. For deeper scratches, light sanding with fine-grit sandpaper followed by oiling may be necessary (use caution to maintain finish).
- **Warping:** Usually caused by improper drying or exposure to excessive moisture/heat. Always dry immediately and thoroughly, and store in a stable environment.

7. SPECIFICATIONS

Attribute	Detail
Brand	IH CASADecor
Model Number	BKL-1016
Material	Acacia Wood
Color	Brown

Attribute	Detail
Shape	Rectangular
Finish Type	Polished
Dimensions (L x W x H)	24 in x 5 in x 1 in (approx.)
Product Care Instructions	Hand Wash Only
Dishwasher Safe	No
Oven Safe	No
UPC	626711045514



Image 4: Illustrative image showing approximate dimensions. Please refer to the specifications table for exact product dimensions (24" L x

8. WARRANTY AND SUPPORT

For information regarding warranty, returns, or product support, please refer to the retailer's policy where the product was purchased or contact IH CASADECOR customer service directly through their official website or contact channels provided at the time of purchase.

Always provide your model number (BKL-1016) and proof of purchase when contacting support.

© 2023 IH CASADECOR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BWRCKBT7>

More documents and user manuals: <https://manuals.plus/>