

[Manuals.plus](#) /

› [Naturehike](#) /

› Naturehike Mongar 2-Person Ultralight Backpacking Tent Instruction Manual

Naturehike Mongar

Naturehike Mongar 2-Person Ultralight Backpacking Tent Instruction Manual

INTRODUCTION

Thank you for choosing the Naturehike Mongar 2-Person Ultralight Backpacking Tent. This tent is designed for outdoor enthusiasts seeking a lightweight, durable, and comfortable shelter for cycling, hiking, and camping across three seasons. Its innovative design and high-quality materials ensure reliability in various outdoor conditions.

- **Spacious Design:** Offers ample room for two occupants and their gear, with additional space for a pet.
- **Superior Weather Protection:** Constructed from 210T polyester fabric with a silicone coating, providing up to PU 3000mm waterproofing, excellent wind resistance, and UV protection.
- **Insect Shield:** Features high-density B3 mesh for optimal breathability and air circulation, effectively preventing insect bites for a comfortable sleeping environment.
- **Free-Standing Structure:** Unique design allows for easy and quick setup, packing, and repositioning. The outer flysheet can also be used independently.
- **Lightweight Portability:** Built with a robust aluminum frame, making it highly portable for all your adventures.

SAFETY INFORMATION

Please read and understand these safety guidelines before using your tent to ensure a safe and enjoyable outdoor experience.

- **Fire Safety:** Keep all flame and heat sources away from the tent fabric. The tent is made of flammable material and can burn if exposed to open flames. Do not use candles, matches, or other open flames inside or near the tent.
- **Ventilation:** Ensure adequate ventilation to prevent suffocation and condensation. Do not block tent vents.
- **Site Selection:** Choose a flat, clear area free of sharp objects, rocks, and debris. Avoid pitching under trees with dead branches or in areas prone to flash floods.
- **Weather Conditions:** While the tent offers excellent weather resistance, extreme weather conditions (severe storms, heavy snow, strong winds) can damage the tent and pose a risk. Seek appropriate shelter if conditions become too severe.
- **Children:** Keep children away from the tent during setup and takedown. Do not allow children to play with tent poles or stakes.

PACKAGE CONTENTS


Verify that all components are present in your package:

- Tent Body (Inner Tent)
- Rainfly (Outer Tent)
- Tent Poles (Aluminum Frame)
- Stakes
- Ropes (Guy-lines)
- Footprint (Groundsheet)
- Storage Bag

SETUP INSTRUCTIONS

Follow these steps to set up your Naturehike Mongar tent:

1. **Unpack and Lay Out:** Remove the tent from its storage bag. Lay the footprint on your chosen campsite, followed by the inner tent on top of the footprint.
2. **Assemble Poles:** Connect the aluminum pole sections. The Mongar features a double Y free-standing structure.
3. **Attach Poles to Inner Tent:** Insert the ends of the assembled poles into the grommets or eyelets located at the corners of the inner tent.
4. **Secure Inner Tent:** Attach the inner tent to the poles using the clips and hooks provided. Ensure all clips are securely fastened to the pole structure.
5. **Drape Rainfly:** Place the rainfly over the inner tent, aligning the doors and vestibules.
6. **Fasten Rainfly:** Secure the rainfly to the tent poles and the inner tent's corners using the buckles, straps, or hooks.
7. **Stake Out:** Use the provided stakes to secure the tent corners, vestibules, and guy-lines. This enhances stability and wind resistance.



Weight:2.4kg/5.29 lbs



15cm/5.9in

50cm/19.7in



2 person

Image: Tent dimensions (210cm L x 135cm W x 105cm H) and packed size (50cm L x 15cm W) with a packed weight of 2.4kg.



Image: Detailed view of the tent pole connections, including the tight tee joint, cross bracing, and two-way swivel hook for secure assembly.

OPERATING INSTRUCTIONS

Maximize your comfort and the tent's performance with these usage tips:

- **Ventilation:** Utilize the high-density B3 mesh and adjustable vents to maintain airflow and minimize condensation. Open vestibule zippers partially for cross-ventilation when weather permits.
- **Interior Space:** The tent is designed to comfortably accommodate two people and their gear. Use the internal pockets for organizing small items.
- **Vestibules:** The two vestibules provide sheltered storage for backpacks, boots, and other equipment, keeping the inner tent clean and dry.
- **Independent Flysheet Use:** In fair weather, the rainfly can be pitched alone with the footprint and poles, offering a lightweight shelter option.



Image: Interior view of the Naturehike Mongar tent, showing two individuals comfortably seated, highlighting the spaciousness for occupants.



Image: The Naturehike Mongar tent fully set up in a natural outdoor environment, demonstrating its compact and stable profile.

MAINTENANCE

Proper care extends the life of your tent:

- **Cleaning:** Clean the tent with water and mild soap. Avoid harsh detergents or abrasive cleaners, which can damage the fabric's waterproof coating.
- **Drying:** Always ensure the tent is completely air-dried before packing it away. Storing a damp tent can lead to mildew, odor, and fabric degradation.
- **Storage:** Store the tent in a cool, dry place, away from direct sunlight and extreme temperatures. Loosely stuff the tent into its bag rather than folding it tightly to prevent creasing and prolong fabric life.
- **Pole Care:** Inspect tent poles for any damage or bends after each use. Clean off any dirt and ensure elastic cords are in good condition.
- **Zipper Care:** Keep zippers clean and free of debris. Lubricate them periodically with a silicone-based zipper lubricant to ensure smooth operation.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Possible Cause	Solution
Condensation inside tent	Lack of ventilation, high humidity, temperature difference	Increase ventilation by opening vents or partially unzipping doors. Ensure proper airflow.
Water leakage	Improper setup, damaged fabric/seams, heavy rain exceeding waterproof rating	Ensure rainfly is taut and properly staked. Check for tears or seam damage; apply seam sealer if needed.
Tent unstable in wind	Insufficient staking, loose guy-lines, incorrect orientation	Fully stake out all points and use all guy-lines. Orient the narrowest part of the tent into the wind.
Zipper sticking	Dirt/debris, fabric caught in zipper	Clean zipper teeth. Gently pull fabric away from zipper. Apply zipper lubricant.




Image: Diagram illustrating the tent's rainproof and windproof capabilities, highlighting the 20D nylon and PU waterproof layer.

SPECIFICATIONS

- **Model:** Mongar
- **Occupancy:** 2 persons
- **Seasons:** 3 seasons
- **Dimensions (L x W x H):** 210 cm x 135 cm x 105 cm (82.7 in x 53.2 in x 41.3 in)
- **Packed Weight:** 2500 Grams (2.5 kg / 5.5 lbs)
- **Carry Weight:** 2400 Grams (2.4 kg / 5.29 lbs) (inner tent, flysheet, and poles)
- **Floor Area:** 13650 cm²
- **Rainfly Material:** 210T Polyester with Silicone Coating
- **Inner Tent Material:** B3 Mesh, Polyester
- **Floor Material:** 210T Polyester with Silicone Coating
- **Water Resistance Rating:** PU 3000mm

- **Pole Material:** Aluminum
- **UV Protection:** Anti-UV
- **Number of Doors:** 1
- **Number of Pockets:** 1
- **Included Components:** Footprint, Stakes, Ropes, Tent Poles

WARRANTY AND SUPPORT

Naturehike provides a warranty for its products. For the Naturehike Mongar tent, spare parts are available in the EU for a duration of 3 years from the date of purchase.

If you encounter any issues with your tent or require assistance, please contact Naturehike customer support through the retailer where you purchased the product or visit the official Naturehike website for contact information. Please have your purchase receipt and product model information ready when contacting support.