

[Manuals.plus](#) /

› [AROEVE](#) /

› AROEVE Air Purifier MK01 Black User Manual

AROEVE MK01

AROEVE Air Purifier

MODEL: MK01 BLACK USER MANUAL

[Introduction](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Specifications](#)

1. Introduction

The AROEVE MK01 Black Air Purifier is designed to provide comprehensive air purification for your living space. This model features dual-channel and 360-degree air inlets, effectively cleaning air in rooms up to 287 ft² / 25 m². It operates with a low noise level, making it suitable for bedrooms and offices. The purifier includes a specialized 4-in-1 filter system and an aroma pad for essential oils.

Filter Air Particles

Breathe The Fresh Air, Enjoy Your Good Life

Multi-layer filtration, continuously purify air particles such as dust, hair, pollen, smell, smoke, etc. in the indoor environment

5 times/h
Air Change

Image 1.1: AROEVE MK01 Black Air Purifier, front view.

Key Features:

- **Advanced Filtration:** Utilizes a 4-in-1 filter system to capture smoke, pollen, pet dander, hair, and odors.
- **High Air Circulation:** Refreshes air up to 5 times per hour in rooms up to 215 ft² / 20 m².
- **Quiet Operation:** Features a sleep mode with noise levels as low as 22 dB.
- **Timer Function:** Offers 6, 12, and 24-hour timer options for automatic shut-off.
- **Aroma Pad:** Integrated pad for adding essential oils to diffuse fragrance.
- **Energy Efficient:** Operates at a low power consumption of 17W.

2. Setup

Before first use, ensure the filter is properly installed and the protective packaging is removed.

2.1 Filter Installation

1. Turn the air purifier upside down.

2. Twist the base cover counter-clockwise to unlock and remove it.
3. Remove the filter from its plastic packaging.
4. Insert the filter into the base of the purifier.
5. Replace the base cover and twist clockwise to lock it securely.

Keep Hair And Dander Out Of Purifier

Capture large particles such as dust, hair, dander, lint and fibers.



Image 2.1: Bottom Air Filter Base Cover and Sensitive Operation Panel.

2.2 Placement

Place the air purifier on a flat, stable surface. Ensure there is adequate space around the unit for optimal air circulation. Avoid placing it directly against walls or furniture that might obstruct the air inlets or outlets.

3. Operating Instructions

The AROEVE Air Purifier features a touch-sensitive control panel located on the top of the unit.

High Air Circulation

Small Machine, Impressive Filtration



Built-In Essential Oil Sponge

Sensitive Operation Panel



Bottom Air Filter Base Cover

Image 3.1: Air Purifier operating in a bedroom, highlighting silent purification.

3.1 Power On/Off

- To turn on the purifier, touch the power symbol on the control panel.
- To turn off the purifier, touch the power symbol again.

3.2 Fan Speed Settings

The purifier offers multiple fan speed settings:

- **Speed 1:** Low fan speed for quiet operation.
- **Speed 2:** Medium fan speed for general purification.
- **Sleep Mode:** Activates the lowest fan speed and turns off all indicator lights for undisturbed sleep. Touch the moon symbol to activate/deactivate.

3.3 Timer Function

Set the purifier to automatically turn off after a specified period:

- Touch the clock symbol to cycle through timer options: 6 hours, 12 hours, or 24 hours.

- The corresponding indicator light will illuminate to confirm the selected timer setting.

3.4 Light Control

The purifier includes an optional UV light and a bottom ambient light:

- Touch the light bulb symbol to turn the UV light on or off.
- Touch the sun/moon symbol to control the bottom ambient light.

3.5 Aroma Pad Usage

To add essential oils:

1. Locate the aroma pad compartment on the top of the purifier (marked 'OPEN').
2. Open the compartment and add 4-5 drops of your preferred essential oil to the pad.
3. Close the compartment. The purifier will diffuse the fragrance as it cleans the air.

4. Maintenance

4.1 Filter Replacement

The air purifier is equipped with a 2000-hour cartridge replacement reminder. A red indicator light will illuminate when the filter needs to be replaced. For optimal performance and health, it is recommended to replace the filter cartridge every 2-4 months, depending on usage and air quality.

Small Machine Impressive Filtration

Impressive filtration air filter traps pollutants from every direction.



Small Machine, Impressive Filtration

Multi-layer Filtration,continuously Purify Air Particles,dust,hair,pollen,smell, smoke,etc.in The Indoor Environment

Image 4.1: Visual comparison of a new filter versus a filter after 3 months of use.

To replace the filter, follow the steps outlined in Section 2.1 Filter Installation, using a new AROEVE replacement filter.

4.2 Cleaning the Unit

Wipe the exterior of the air purifier with a soft, dry cloth. Do not use abrasive cleaners or immerse the unit in water.

5. Specifications

Feature	Detail
Brand	AROEVE
Model	MK01 Black
Power Source	Corded Electric

Control Method	Touch Button Control
Filter Type	HEPA (4-in-1 specialized filters)
Floor Area Coverage	Up to 215 Square Feet (20 m²)
Noise Level	22 Decibels (in Sleep Mode)
Special Features	Bundle of 3 specialized filters (1 basic, 2 pet dander), Aroma pad for essential oils
Unit Count	3.0 Count (including filters)
Certification	AHAM Certified