

[manuals.plus](#) /› [Auusda](#) /› [Auusda 14.1" Laptop Computer User Manual](#)

Auusda A23

Auusda 14.1" Laptop Computer User Manual

Model: A23

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new Auusda 14.1" Laptop Computer. Please read it thoroughly to ensure optimal performance and longevity of your device.

What's in the Box

- Laptop
- Charger
- User Manual (this document)



Figure 1.1: Aussda 14.1" Laptop and included accessories.

2. SAFETY INFORMATION

To avoid the risk of fire, electric shock, injury, or damage, please read and follow these safety precautions before using this product:

- Do not use the product near water, heat sources, flammable materials, or magnetic fields.
- Do not expose the product to direct sunlight, high temperatures, humidity, or dust.
- Do not drop, hit, bend, or puncture the product or the battery.
- Do not open, disassemble, modify, or repair the product or the battery by yourself.
- Use only the original charger and cable that came with the product. Do not use any other adapters or accessories that are not compatible with the product.
- Charge the product in a well-ventilated area. Do not cover the product or the charger while charging. Do not charge the product if the charger or the cable is damaged.

- Stop using the product and disconnect the charger immediately if you notice any abnormality, such as smoke, odor, leakage, overheating, noise, or deformation.
- Keep the product and the battery out of reach of children and pets. Do not let them play with or swallow the product or the battery.
- Dispose of the product and the battery properly according to local regulations. Do not throw them in the trash or fire.

If you have any questions or concerns about the product safety, please email us at amazon dot service at sign forwelltek dot com. Thank you for choosing Auusda!

3. SETUP

Initial Power On

Follow these steps to power on your laptop for the first time:

1. Unpack the laptop and all accessories from the box.
2. Connect the charger to the laptop's DC 3.5mm charging port and plug it into a power outlet.
3. Open the laptop lid. The screen may turn on automatically, or you may need to press the power button located on the keyboard.
4. Follow the on-screen instructions to complete the Windows 11 Pro setup, including language, region, network connection, and user account creation.

Massive Memory, Huge Storage

Expand SSD up to 2TB and Micro SD card up to 1TB to meet all your storage needs.

8GB

RAM

512GB

SSD

3TB

Expansion



Figure 3.1: Laptop powered on and ready for initial setup.

Visual Guide: Laptop Overview

Your browser does not support the video tag.

Video 3.1: An overview of the Auusda 14.1" Laptop, highlighting its features and portability. This video demonstrates the physical aspects of the laptop.

4. OPERATING YOUR LAPTOP

Keyboard and Touchpad

The laptop features a full-sized keyboard and a responsive touchpad for navigation. Familiarize yourself with the key layout and touchpad gestures for efficient use.

Perfect Travel Companion

Never run out of power on the go! Enjoy extended hours of productivity.



Dual-band WiFi



Bluetooth 4.2



4000mAh Battery



Figure 4.1: Detailed view of the keyboard and touchpad.

Connecting Peripherals (Ports)

Your laptop is equipped with various ports for connecting external devices:

- **USB-A Ports (x2):** For connecting USB devices like external hard drives, mice, or keyboards.
- **Mini HDMI Port (x1):** For connecting to external displays or projectors.
- **MicroSD Card Slot (x1):** Supports up to 1TB for expanded storage.
- **Headphone Port (x1):** For connecting headphones or external speakers.
- **DC 3.5mm Charging Port (x1):** For connecting the power adapter.

MEET YOUR MORE NEEDS

Office

Leisure

Video

Design




Office meeting




Fund shares



online class



easy code



Film and television drama



speech template

Figure 4.2: Overview of the laptop's connectivity ports.

Display Features

The 14.1-inch IPS screen offers a Full HD resolution (1920x1080) for clear and vibrant visuals. Its ultra-slim 0.2-inch border maximizes screen space, and the 180-degree opening design provides flexibility for various viewing angles.



Figure 4.3: The laptop's IPS display and flexible hinge design.

5. MAINTENANCE

Cleaning

- Use a soft, lint-free cloth to clean the screen and exterior.
- For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution.
- Avoid harsh chemicals, abrasives, or aerosol sprays.

Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place when not in use for extended periods.
- Use only the provided charger.

Storage

- When storing the laptop, ensure it is turned off and not just in sleep mode.
- Protect it from extreme temperatures and humidity.
- Use a protective sleeve or bag to prevent scratches and impacts.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your laptop. If the problem persists, please contact customer support.

| Problem | Possible Solution |
|--------------------------------|--|
| Laptop does not power on. | Ensure the charger is securely connected and the power outlet is working. Try holding the power button for 10-15 seconds to force a restart. |
| Wi-Fi connectivity issues. | Check if Wi-Fi is enabled in Windows settings. Restart your router and modem. Ensure you are within range of the Wi-Fi signal. |
| Slow performance. | Close unnecessary applications. Check for Windows updates. Run a disk cleanup. Consider upgrading SSD if frequently low on storage. |
| Screen is blank or flickering. | Restart the laptop. Check display settings in Windows. Ensure no external display cables are loose if connected. |

7. SPECIFICATIONS

Detailed technical specifications for your Auusda A23 Laptop:

| Feature | Specification |
|-------------------|---|
| Brand | Auusda |
| Model Name | A23 |
| Screen Size | 14.1 Inches |
| Screen Resolution | 1920 x 1080 pixels (Full HD IPS) |
| Processor | Intel Celeron J4105 (2.5 GHz burst frequency) |
| RAM | 8 GB DDR4 |

| Feature | Specification |
|----------------------|--|
| Hard Drive | 512GB M.2 SATA SSD (upgradable to 2TB) |
| Graphics Coprocessor | Intel UHD Graphics 600 |
| Operating System | Windows 11 Pro |
| Wireless Type | 802.11bgn (Dual-band WiFi), Bluetooth 4.2 |
| Ports | 2 USB-A, 1 Mini HDMI, 1 MicroSD Slot (up to 1TB), 1 Headphone, 1 DC 3.5mm Charging |
| Item Weight | 2.68 pounds |
| Product Dimensions | 13 x 0.84 x 8 inches |
| Average Battery Life | 5 Hours (30400mWh battery) |

8. WARRANTY AND SUPPORT

Warranty Information

The laptop is covered by a **2-year limited warranty** from the date of purchase. This warranty applies only to the original purchaser and does not cover any unauthorized modifications, misuse, abuse, accidents, or improper maintenance. The warranty does not include any accessories, software, or peripherals that come with the laptop. We reserve the right to repair, replace, or refund the laptop at our sole discretion.

Customer Support

For any support inquiries, technical assistance, or warranty claims, please contact us directly:

- **Email:** Auusda.ltd@gmail.com
- When contacting support, please include your order number and a detailed description (video, if applicable) of the issue.