

[Manuals.plus](#) /

› [Urmet](#) /

› Urmet Bibus Signo Intercom System User Manual

Urmet 20117255

Urmet Bibus Signo Intercom System User Manual

Model: 20117255

1. INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, and maintenance of your Urmet Bibus Signo Intercom System, Model 20117255. This unit is designed as a replacement intercom for existing Bibus systems, offering reliable communication and door control. Please read this manual carefully before use to ensure proper functionality and longevity of the device.

2. PRODUCT OVERVIEW

The Urmet Bibus Signo Intercom is a comfortable replacement intercom unit featuring a sleek design and essential functions. It is equipped with three distinct buttons and an LED indicator for clear status feedback.



Figure 2.1: Front view of the Urmet Bibus Signo Intercom System. The unit is white, with a handset on the left side and the main base on the right. The base features a speaker grille, a microphone, three circular buttons, and an LED indicator. A coiled cord connects the handset to the base.

2.1. Components

- **Handset:** Used for audio communication.
- **Base Unit:** Contains the main circuitry, speaker, microphone, and control buttons.
- **Call Button:** Activates the call to the central unit.
- **Special Decoding Button:** Activates a specific decoding function (e.g., for additional services).
- **Automatic Door Opener Button:** Activates the automatic door opening mechanism.
- **LED Indicator:** Provides visual feedback on the intercom's status.

3. SETUP AND INSTALLATION

Installation of the Urmet Bibus Signo Intercom System should ideally be performed by a qualified technician. Ensure power is disconnected before beginning any installation work.

3.1. Mounting

1. Identify the appropriate mounting location, typically near the entrance or a central point within the dwelling.
2. Secure the mounting bracket (if supplied separately) to the wall using appropriate screws and wall plugs.
3. Connect the necessary wiring from your existing intercom system to the terminals on the back of the Urmet Bibus Signo unit. Refer to the wiring diagram provided with your specific Bibus system for correct connections.
4. Carefully attach the intercom unit to the mounted bracket, ensuring all connections are secure and the unit is firmly in place.

3.2. Initial Power-Up

Once installation is complete, restore power to the intercom system. The LED indicator may illuminate briefly during the initial power-up sequence.

4. OPERATING INSTRUCTIONS

4.1. Answering a Call

- When an incoming call is detected, the intercom will ring.
- Lift the handset to establish communication with the caller.
- Speak clearly into the microphone on the handset.
- Replace the handset to end the call.

4.2. Using the Buttons

- **Call Button:** Press this button to initiate a call to the central intercom unit or concierge.
- **Special Decoding Button:** Press this button to activate a pre-programmed special function, such as controlling an additional gate or light. Refer to your building's specific system configuration for details on this function.
- **Automatic Door Opener Button:** Press this button to remotely open the main entrance door. This function is typically active during an ongoing call or after a successful identification.

4.3. LED Indicator

The LED indicator provides visual status of the intercom. Its behavior (e.g., solid, blinking, color) may vary depending on the system's state (e.g., active call, busy line, error). Consult your building's intercom system documentation for specific LED indications.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Urmet Bibus Signo Intercom, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the exterior of the unit with a soft, dry cloth. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by drying. Do not use abrasive cleaners, solvents, or excessive moisture.
- **Avoid Obstructions:** Ensure the speaker and microphone openings are free from dust and debris.
- **Handle with Care:** Avoid dropping the handset or subjecting the unit to strong impacts.

6. TROUBLESHOOTING

If you encounter issues with your intercom system, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from speaker/microphone	Loose wiring connection; Speaker/microphone obstruction; System fault.	Check wiring connections (if accessible and safe); Clear any visible obstructions; Contact a qualified technician if the issue persists.
Door opener not working	Not in active call; System fault; Wiring issue.	Ensure you are in an active call with the visitor; Verify system status; Contact a qualified technician.
Intercom not ringing	System fault; Wiring issue.	Check if other units in the building are ringing; Contact a qualified technician.

For issues not listed above or if solutions do not resolve the problem, please contact a qualified technician or your building management.

7. SPECIFICATIONS

Model:	20117255
Brand:	Urmet
Dimensions (L x H x P):	80 x 225 x 40 mm (approximately 3.15 x 8.86 x 1.57 inches)
Surface Finish:	Polished
Color:	White
Item Weight:	500 g (approximately 1.1 lbs)

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, please refer to the purchase documentation or contact your supplier. Urmet products are designed for reliability and durability.

For technical support or service inquiries, please contact your installer, building management, or the authorized Urmet distributor in your region.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BWTCQ845>

More documents and user manuals: <https://manuals.plus/>