

CLABEL CT221D

CLABEL CT221D Label Printer User Manual

Model: CT221D

1. INTRODUCTION

The CLABEL CT221D is a compact and lightweight desktop Bluetooth barcode label printer designed for efficient direct thermal printing. It is ideal for various applications in small businesses and homes, including printing barcodes, address labels, shipping labels, and more.

This printer supports label widths ranging from 0.78 inches (20mm) to 2.28 inches (58mm) and offers extensive customization options through its powerful "clabel trade" mobile application and PC software. With no need for ink or toner, it provides a cost-effective and convenient labeling solution.



Image: The CLABEL CT221D label printer, a compact device for various labeling needs.

2. PACKAGE CONTENTS

Please verify that all items are present in your product package:

- CLABEL CT221D Label Printer
- Power Adapter
- USB Cable
- User Manual
- One roll of 1.57x1.18" address labels

3. SETUP

3.1 Physical Setup and Label Loading

Before operating the printer, ensure it is connected to a power source and labels are properly loaded.

1. Connect one end of the power adapter to the printer and the other end to a power outlet.
2. Toggle the power switch to the 'I' position to turn on the printer.
3. Open the lid of the printer by gently lifting it with your hand.
4. Prepare the label roll: Only remove the left baffle from the label spool. Load the paper roll onto the

spool, ensuring the tabs on the baffle face outward.

5. Insert the assembled label roll into the printer.
6. Push the movable baffle to the left to secure the label roll. Ensure the thermal surface of the label faces downwards.
7. Close the printer lid securely.

Your browser does not support the video tag.

Video: Instructions on how to install and load paper into the CLABEL CT221D printer.

Your browser does not support the video tag.

Video: Demonstrates preparations before printing and how to open the printer cover.





3.2 Software and App Installation

The CLABEL CT221D printer can be operated via PC software or a mobile application.

For PC (Windows/Mac):

1. Visit the official CLABEL website or scan the QR code provided in the user manual to download the

Related Documents - CT221D

	<p>Clabel CT221B Label Printer User Manual - Setup and Operation Guide</p> <p>Explore the Clabel CT221B Label Printer with this comprehensive user manual. Learn about packing, components, functions, paper loading, mobile/computer printing, and troubleshooting. Available in multiple languages.</p>
	<p>CLABEL Label Printer Driver and Software Installation Guide</p> <p>A comprehensive guide for installing CLABEL label printer drivers and the OpenLabel+ editing software on macOS, covering download, installation, configuration, and printing steps.</p>
	<p>Clabel CT221D Label Printer Quick Installation Guide</p> <p>This document provides a quick installation guide for the Clabel CT221D label printer. It covers unpacking, component identification, step-by-step installation, key functions, indicator light meanings, software download instructions, and important usage precautions. Includes FCC compliance information.</p>
	<p>CLABEL 220B Portable Label Maker: FAQ and Usage Guide</p> <p>Get answers to common questions about the CLABEL 220B portable label maker, including setup, printing, app connectivity, and troubleshooting. Learn how to load paper, improve print quality, and contact support.</p>

Scan the QR code to install the "Clabel trade"APP.



[Clabel Trade Label Printer Setup and Usage Guide](#)

A comprehensive guide to setting up and using the Clabel Trade label printer, including paper loading, app connection, printing, and customer support information.

For Android

- Scan the QR code below with a mobile phone to download "Clabel trade".
- Please follow the software instructions below to operate the software.



Click to get

Download and install the app "Clabel trade" from Google Play Store or scan the QR code and install it.

▲ Mobile phone pairing (BLE) for Bluetooth version.

Windows

Visit website <https://lps.clabel.com> to download "Clabel trade" and drivers.

▲ Download the drivers from the above url and read the instructions, read user instructions/software installation on the website.

[CLABEL Label Maker: Installation Guide for Clabel Trade App and Drivers](#)

Comprehensive guide to installing the Clabel Trade app and drivers for iOS, Android, and Windows devices. Learn how to connect your CLABEL label printer for seamless operation.