

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR V-695 Professional Hair Clipper Instruction Manual](#)

VGR V 695

VGR V-695 Professional Hair Clipper Instruction Manual

Model: V 695 | Brand: VGR

1. INTRODUCTION

Thank you for choosing the VGR V-695 Professional Hair Clipper. This manual provides essential information for the safe and effective use, maintenance, and care of your new hair clipper. Please read these instructions thoroughly before first use and retain them for future reference.

2. PRODUCT OVERVIEW

The VGR V-695 is a professional-grade hair clipper designed for precise and comfortable trimming. It features a durable ceramic and powder metallurgic blade, adjustable cutting lengths, multiple motor speeds, and a waterproof design for easy cleaning.

2.1 Package Contents

- VGR V-695 Hair Clipper
- Guide Combs (various sizes)
- USB Charging Cable
- Cleaning Brush
- Oil Bottle
- Instruction Manual



Figure 1: VGR V-695 Hair Clipper and included accessories.

2.2 Key Features

- **Ceramic & Powder Metallurgic Blade:** Self-sharpening blades designed for smooth cutting of dry and wet hair. R-shaped blades protect the skin.
- **Zoom Wheel Adjustments:** Integrated wheel for precise cutting length adjustments from 0.5mm to 2.5mm without guide combs.
- **Multiple Guide Combs:** Includes 5 attachment guides (3/4-6/7-9/10-12/16-18mm) for a total trimming range of 0.5mm to 18mm.
- **IPX7 Waterproof:** Fully washable body for easy and hygienic cleaning.

- **3 Motor Speeds:** Adjustable motor speeds (5000/6000/7000 RPM) for varied cutting needs.
- **Cordless/Corded Operation:** Can be used cordlessly for up to 300 minutes after a 4-hour charge, or while plugged in.
- **LED Digital Display:** Shows battery charge status, power level, travel lock, charging status, washing reminder, and oil reminder.
- **Rubber Grip:** Provides enhanced handling and control.
- **One-Key Lock:** Press and hold for 3 seconds to activate/deactivate the travel lock.



Figure 2: Detailed view of the VGR V-695 Hair Clipper's main features.



Figure 3: Explanation of the LED Digital Display icons.

2.3 Product Video Overview



Video 1: A comprehensive overview of the VGR V-695 Professional Hair Clipper's features and capabilities.

3. SETUP

3.1 Charging the Clipper

1. Ensure the clipper is switched off.
2. Connect the USB charging cable to the clipper's charging port.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
4. The LED display will indicate the charging status. A full charge takes approximately 4 hours and provides up to 300 minutes of cordless operation.

3.2 Attaching and Detaching Guide Combs

1. To attach a guide comb, align the comb with the clipper blade and push it firmly until it clicks into place.
2. To detach, gently pull the comb away from the blade.
3. Always ensure the clipper is switched off before attaching or detaching guide combs.



Figure 4: VGR V-695 Hair Clipper with guide combs.



Video 2: Unboxing and demonstration of VGR V-695 Hair Clipper features, including attaching combs.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

- To turn on the clipper, press the ON/OFF button.
- To turn off the clipper, press the ON/OFF button again.

4.2 Adjusting Cutting Length (Zoom Wheel)

- The integrated zoom wheel allows for fine-tuning of cutting length from 0.5mm to 2.5mm in 0.5mm increments without a guide comb.
- Rotate the zoom wheel to select your desired length.



Figure 5: Blade length adjustment using the zoom wheel.

4.3 Adjusting Motor Speed

- The clipper offers three motor speeds: 5000 RPM, 6000 RPM, and 7000 RPM.
- Press the speed adjustment button (often integrated with the power button or a separate button) to cycle through the available speeds. The LED display will show the current speed setting.
- The turbo function provides extra power when needed.

4.4 Using Guide Combs

- For longer cutting lengths, attach one of the provided guide combs. The available sizes are 3mm, 4-6mm, 7-9mm, 10-12mm, and 16-18mm.
- The total trimming range with guide combs is 0.5mm to 18mm.



Figure 6: Guide comb sizes for varied cutting lengths.

4.5 Travel Lock

- To prevent accidental activation during travel, press and hold the ON/OFF button for 3 seconds to engage the travel lock.
- The travel lock icon will appear on the LED display.
- To unlock, press and hold the ON/OFF button for 3 seconds again.

5. MAINTENANCE AND CLEANING

5.1 Waterproof Cleaning (IPX7)

- The VGR V-695 is IPX7 waterproof, allowing for easy cleaning under running water.
- Ensure the clipper is switched off before cleaning.
- Rinse the blades and the clipper head thoroughly under tap water.
- Do not immerse the entire clipper in water for extended periods.
- After rinsing, shake off excess water and allow the clipper to air dry completely before storage or next use.



Figure 7: The VGR V-695 Hair Clipper is IPX7 waterproof for easy cleaning.

5.2 Oiling the Blades

- Regular oiling of the blades ensures optimal performance and longevity.
- After cleaning and drying, apply a small drop of the included oil to the blades.
- Turn on the clipper for a few seconds to distribute the oil evenly.
- Wipe off any excess oil with a soft cloth. The LED display will show an oil reminder icon when oiling is recommended.

5.3 General Cleaning

- Use the provided cleaning brush to remove loose hairs from the blades and inside the clipper head after each use.
- For thorough cleaning, the blade assembly can be carefully detached. Refer to the unboxing video for guidance on blade removal and reattachment.

6. TROUBLESHOOTING

If you encounter any issues with your VGR V-695 Hair Clipper, please refer to the following common solutions:

Problem	Possible Cause	Solution
Clipper does not turn on.	Low battery or travel lock engaged.	Charge the clipper fully. Press and hold the ON/OFF button for 3 seconds to disengage travel lock.
Poor cutting performance.	Blades are dull, dirty, or not oiled.	Clean the blades thoroughly and apply oil. Ensure blades are properly aligned.
Clipper makes unusual noise.	Blades require oiling or are obstructed.	Clean and oil the blades. Check for any hair or debris obstructing the blade movement.
Battery drains quickly.	Battery not fully charged or aging battery.	Ensure a full 4-hour charge. If the issue persists, contact customer service.

7. SPECIFICATIONS

Feature	Detail
Model Number	V 695
Blade Material	Ceramic & Powder Metallurgic
Cutting Length Adjustment	0.5mm - 2.5mm (via Zoom Wheel)
Guide Comb Lengths	3mm, 4-6mm, 7-9mm, 10-12mm, 16-18mm
Total Trimming Range	0.5mm - 18mm
Motor Speeds	5000 RPM, 6000 RPM, 7000 RPM
Battery Type	2600mAh Li-ion Battery
Charging Time	Approx. 4 hours
Runtime	Up to 300 minutes
Waterproof Rating	IPX7
Power Source	Cordless/Corded (110-220V Dual-Voltage)
Product Dimensions	23.3 x 13.3 x 7 cm
Item Weight	700 g

8. WARRANTY AND SUPPORT

The VGR V-695 Professional Hair Clipper comes with a **12-month quality warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets its specified performance standards.

For any warranty claims, technical assistance, or product inquiries, please contact our customer service. Our team is committed to providing a satisfactory resolution within 24 hours.

Customer Service Contact: Please refer to the contact information provided on the product packaging or the official VGR website.

	<p>VGR V-085 Professional Hair Trimmer Manual and Safety Instructions</p> <p>This document provides comprehensive safety instructions, components list, usage guidelines, cleaning and maintenance procedures, and technical specifications for the VGR V-085 Professional Hair Trimmer.</p>
	<p>VGR V-282 Professional Hair Clipper User Manual and Specifications</p> <p>Comprehensive user manual for the VGR V-282 Voyager Professional Hair Clipper. Includes detailed information on components, safety instructions, usage, charging, maintenance, technical features, and disposal guidelines.</p>
	<p>VGR V-906 Professional Hair Trimmer User Manual</p> <p>Comprehensive user manual for the VGR V-906 electric hair trimmer, detailing features, operation, charging, maintenance, and troubleshooting for professional and home grooming.</p>
	<p>VGR V-085 Professional Hair Trimmer User Manual & Safety Instructions</p> <p>This document provides comprehensive safety instructions, component descriptions, usage guidelines, charging, cleaning, and maintenance information for the VGR V-085 Professional Hair Trimmer.</p>
	<p>VGR V-990 Cordless Hair Trimmer User Guide</p> <p>Comprehensive guide to using the VGR V-990 professional cordless hair trimmer, featuring 8000RPM, barber-grade performance, and easy hair cutting for men.</p>
	<p>VGR V-930 Professional Hair Trimmer User Manual with AFA Endorsement</p> <p>Comprehensive user manual for the VGR V-930 Professional Hair Trimmer, featuring AFA endorsement with player imagery. Covers safety instructions, components, usage, charging, cleaning, maintenance, and technical specifications for this personal grooming device.</p>