

UPULTRA B0BWXMDSQ

UPULTRA Light Bulb Security Camera User Manual

Model: B0BWXMDSQ

INTRODUCTION

Thank you for choosing the UPULTRA Light Bulb Security Camera. This manual provides detailed instructions for the installation, operation, and maintenance of your new security camera. This device offers 360° panoramic surveillance, motion detection, two-way audio, and night vision capabilities, designed for both indoor and outdoor home security.

SETUP

1. Physical Installation

The UPULTRA Light Bulb Security Camera is designed for easy installation into a standard E27 bulb base (110V~240V). No complex wiring is required.

1. Ensure the power to the light fixture is turned off before installation.
2. Carefully screw the camera into an E27 bulb socket. Ensure it is securely tightened.
3. Turn on the power to the light fixture. The camera will power on and initiate its startup sequence.

— Easy and Quick Inastallation —



Image: The camera screws directly into a standard E27 light bulb socket for quick setup. It can be used indoors or outdoors in a protected fixture.

2. App Download and Account Creation

To operate the camera, you need to download the compatible mobile application.

1. Scan the QR code provided in the camera's packaging or search for the recommended app (e.g., 'YI IoT' or similar smart home app) in your device's app store (iOS App Store or Google Play Store).

2. Download and install the application.
3. Open the app and create a new user account. Follow the on-screen instructions to complete registration.

3. Camera Connection to Wi-Fi

Connect your camera to your home Wi-Fi network using the mobile application.

1. Ensure your mobile device is connected to a 2.4GHz Wi-Fi network. The camera supports 2.4GHz Wi-Fi only.
2. In the app, tap 'Add Device' or the '+' icon.
3. Select 'Light Bulb Camera' or a similar option from the device list.
4. Follow the app's instructions to reset the camera if necessary (usually by pressing a reset button until an audible prompt is heard).
5. The app will generate a QR code. Position your phone's screen in front of the camera lens (approximately 15-20 cm away) for the camera to scan it.
6. Once the camera successfully scans the QR code, it will connect to your Wi-Fi network. Follow any final prompts in the app to complete the setup.

OPERATING INSTRUCTIONS

1. Live View and Pan/Tilt Control

Access the live video feed and control the camera's viewing angle directly from the mobile app.

- Open the app and select your camera from the device list.
- The live video feed will appear. Use the on-screen joystick or swipe gestures to pan (horizontal rotation up to 355°) and tilt (vertical movement up to 180°) the camera, eliminating blind spots.

355°Panorama Security Surveillance

355 pan & 180 tilt, without blind spots



Image: The camera offers 355 degrees of horizontal pan and 180 degrees of vertical tilt for comprehensive surveillance.

2. Motion Detection and Real-time Alerts

The camera features a highly sensitive motion sensor to detect activity in its field of view.

- Enable motion detection in the app's settings for your camera.
- When motion is detected, the camera will automatically record the event and send a real-time notification to your mobile device.

- You can customize alert sensitivity and notification preferences within the app.



Image: Motion detection triggers mobile notifications, and can activate a spotlight or siren for deterrence.

3. Two-Way Audio

Communicate with individuals near the camera using the built-in microphone and speaker.

- While viewing the live feed, tap the microphone icon in the app to speak. Your voice will be transmitted through the

camera's speaker.

- The camera's microphone will capture audio from its surroundings, allowing you to hear what is happening.



Two-Way Talk

Two way communications allows you to interact with those on camera. Communicate with your loved ones when you are away from home.

Image: The two-way talk feature allows interaction with people near the camera via the mobile app.

4. Night Vision

The camera provides clear images even in low-light or complete darkness.

- The camera automatically switches to night vision mode when ambient light is insufficient.

- Equipped with infrared LEDs, it captures clear black and white video in dark conditions.

5. Remote Viewing

Access your camera's live feed and recorded footage from anywhere, anytime.

- As long as your camera is connected to Wi-Fi and your mobile device has internet access, you can remotely view your property.
- The app is compatible with iPhone, Android phones, and iPads.

2MP *Light Bulb Security Camera*

2MP Resolution



Standard Resolution



MAINTENANCE

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth to remove dust and smudges. Avoid using harsh chemicals or abrasive materials.
- **Firmware Updates:** Regularly check the mobile app for available firmware updates. Keeping your camera's firmware up-to-date ensures optimal performance, security, and access to new features.
- **Power Cycle:** If the camera experiences minor issues, try power cycling it by turning off the light fixture's power for a few seconds, then turning it back on.

TROUBLESHOOTING

Camera Not Connecting to Wi-Fi

- Ensure your Wi-Fi network is 2.4GHz. The camera does not support 5GHz networks.
- Verify that your Wi-Fi password is entered correctly in the app.
- Make sure the camera is within range of your Wi-Fi router. Obstacles like thick walls can interfere with the signal.
- Try resetting the camera and repeating the connection process.

Poor Image Quality

- Check if the camera lens is clean and free from dust or smudges.
- Ensure a stable Wi-Fi connection. A weak signal can result in lower video quality.
- In night vision mode, ensure there are no reflective surfaces too close to the camera that could cause glare.

Motion Detection Not Working or Too Sensitive

- Verify that motion detection is enabled in the app settings.
- Adjust the motion detection sensitivity levels within the app. High sensitivity may trigger alerts from minor movements like shadows or insects.
- Ensure the camera's field of view is clear and not obstructed.

Two-Way Audio Issues

- Check your phone's volume and the camera's speaker volume settings in the app.
- Ensure there is no excessive background noise near the camera or your phone that could interfere with communication.
- Verify a stable internet connection for both the camera and your mobile device.

SPECIFICATIONS

Feature	Detail
Brand	UPULTRA
Model	B0BWXMJJSQ

Connectivity Technology	Wireless (Wi-Fi 2.4GHz)
Recommended Uses	Indoor, Outdoor (protected environment)
Special Features	Motion Sensor, Night Vision, Two-Way Audio
Video Capture Resolution	1080p Full HD
Viewing Angle	360 degrees (Pan/Tilt)
Power Source	Corded Electric (E27 bulb base, 110-240V)
Compatible Devices	Smartphone (Android, iPhone)
Alert Type	Motion Only
Night Vision Type	Night Color (Infrared)

WARRANTY AND SUPPORT

UPULTRA provides lifetime technical support and services for this product. For any questions, issues, or assistance, please contact our customer support team.

CUSTOMER SUPPORT

If you encounter any problems or have questions regarding your UPULTRA Light Bulb Security Camera, please refer to the contact information provided with your product packaging or visit the official UPULTRA website for support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question