

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [RESHABLE](#) /

› [RESHABLE Wall Mount Salon Station with Mirror Instruction Manual](#)

RESHABLE Salon Station with Mirror

RESHABLE Wall Mount Salon Station with Mirror Instruction Manual


Model: Salon Station with Mirror (B0BWXSTZP6)

1. SAFETY INFORMATION

Please read all safety instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Secure Wall Mounting:** The unit must be securely mounted to a wall to prevent tipping. Use appropriate hardware for your wall type.
- **Weight Capacity:** Do not exceed a weight of 66 lbs (30 kg) on the tabletop. Each shelf can hold up to 22 lbs (10 kg).
- **Assembly:** Follow all assembly instructions precisely. Ensure all fasteners are tightened correctly.
- **Mirror Handling:** The mirror is made of high-definition glass with smooth edging. Handle with care to avoid breakage or injury.
- **Transportation:** The item is transported in two packages. The mirror is secured in foam to prevent damage. Inspect all components upon arrival.

Use Safety



Featuring smooth and polished edges to avoid scratching

Figure 1: Mirror edge detail, highlighting the smooth and polished finish designed to prevent scratching.

Safe Transportation

The item is transported in two packages. The mirror will be placed in a foam model and secured with tape to prevent damage



Figure 2: Packaging illustration, showing the product is shipped in two separate packages with the mirror protected by foam.

2. PRODUCT OVERVIEW

The RESHABLE Wall Mount Salon Station with Mirror is a versatile workstation designed for professional salon, barber, spa, or home use. It features a wall-mounted design to optimize space and includes various storage solutions.





Figure 3: The RESHABLE Wall Mount Salon Station with Mirror.

Key Components:

- **Mirror:** A half-body, high-definition glass mirror with smooth edges.

- **Shelves:** Three open shelves for displaying products or easy access to tools.
- **Drawers:** Two drawers, one of which is lockable for securing valuables.
- **Cabinet:** A two-tier cabinet with an adjustable inner shelf for dust-proof storage.
- **Tabletop:** A wide surface for styling activities.
- **Tool Holders:** Three reinforced holders integrated into the tabletop for heated styling tools like blow-dryers and irons.



Figure 4: Detailed view of the station's storage features.

3. SPECIFICATIONS

Feature	Detail
Brand	RESHABLE

Feature	Detail
Model	Salon Station with Mirror
Product Dimensions	13.4"D x 40.6"W x 66.9"H (34 cm D x 103 cm W x 170 cm H)
Item Weight	22 pounds (10 kg)
Frame Material	Wood (Particleboard)
Mirror Material	High-definition Glass
Color	Black
Tabletop Weight Capacity	66 lbs (30 kg)
Shelf Weight Capacity	22 lbs (10 kg) per shelf
Assembly Required	Yes



Figure 5: Product dimensions.

4. SETUP AND ASSEMBLY

Assembly of the RESHABLE Wall Mount Salon Station is required. All necessary parts are pre-drilled and pre-labeled for ease of installation. Please ensure you have adequate space and the appropriate tools before beginning.

Before You Begin:

1. **Unpack:** Carefully unpack all components and verify against the parts list provided in your package.
2. **Inspect:** Check all parts for any damage. If any parts are damaged or missing, contact customer support.

3. **Tools Required:** You will need basic household tools for assembly and wall mounting (e.g., screwdriver, hammer, level, drill).
4. **Location:** Choose a suitable wall location that can support the weight of the station and its contents. Ensure there are no electrical wires or plumbing behind the wall where you plan to drill.

Assembly Steps:

Refer to the detailed manual included in your product packaging for step-by-step assembly instructions and diagrams. The general process involves:

1. Assembling the base cabinet and drawers.
2. Attaching the upper shelf unit.
3. Mounting the mirror to the main structure.
4. Securing the entire unit to the wall using appropriate wall anchors and screws (refer to your specific manual for included hardware or recommendations).
5. Installing the tool holders.

Important: Ensure the unit is securely fastened to the wall to prevent tipping and potential injury. Professional installation is recommended if you are unsure about wall mounting procedures.

5. OPERATING INSTRUCTIONS

The RESHABLE Wall Mount Salon Station is designed for efficient organization and use of salon tools and products.

Storage Compartments:

- **Open Shelves:** Use the three upper open shelves for frequently accessed items, display products, or decorative elements.



Figure 6: Three open shelves for easy access.

- **Drawers:** The two drawers provide enclosed storage. The lockable drawer is ideal for securing personal items or valuable tools. Use the provided key to lock and unlock.
- **Cabinet:** The lower cabinet features an adjustable shelf, allowing you to customize storage space for larger items or supplies.



Figure 7: Lower cabinet with adjustable shelf.

- **Tool Holders:** The three reinforced holders on the tabletop are designed to safely store hot styling tools such as hair dryers, curling irons, and flat irons. Ensure tools are cooled before storing for extended periods.



Figure 8: Integrated tool holders for styling equipment.

6. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your salon station.

- **Cleaning:** Wipe surfaces with a dry cloth. For stubborn marks, use a slightly damp cloth with a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the finish.
- **Mirror Care:** Clean the mirror with a standard glass cleaner and a soft, lint-free cloth.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.
- **Spills:** Wipe up spills immediately to prevent damage to the wood finish.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your salon station.

- **Unit feels unstable after assembly:**
 - Ensure all assembly screws are fully tightened.
 - Verify that the unit is securely mounted to the wall using appropriate anchors for your wall type.
 - Check that the wall surface is flat and even.
- **Drawers do not slide smoothly:**
 - Check for any obstructions in the drawer slides.
 - Ensure the drawer slides are properly aligned and installed according to the assembly instructions.
- **Mirror appears distorted or scratched:**
 - Ensure the protective film (if any) has been removed from the mirror surface.
 - Clean the mirror with a soft cloth and glass cleaner. If scratches are present, they may be permanent.

If you experience issues not covered here, please contact RESHABLE customer support for assistance.

8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact RESHABLE customer service directly. Keep your proof of purchase for warranty claims.

Customer Support: For assistance with assembly, parts, or product inquiries, please visit the official RESHABLE website or contact their customer support channels as provided in your product packaging.

You can also visit the [RESHABLE Store on Amazon](#) for more information.